

[Manuals.plus](#) /

› [Unbranded](#) /

› The Line (La Linea) Blu-Ray Disc User Manual - Model B00E3PRE7U

Unbranded B00E3PRE7U

The Line (La Linea) Blu-Ray Disc User Manual

Model: B00E3PRE7U

1. INTRODUCTION

This manual provides instructions for the proper use and care of your "The Line (La Linea)" Blu-Ray disc. Please read this manual thoroughly before attempting to play the disc to ensure optimal performance and to avoid potential issues.



Image 1: Front cover of "The Line (La Linea)" Blu-Ray disc.

About the Product

The "The Line (La Linea)" Blu-Ray disc is an Australian release, encoded for Region B. This means it is designed to play on Blu-Ray players compatible with Region B discs. It will **not** play on standard Region A (USA/Canada) Blu-Ray players or regular DVD players. A multi-region Blu-Ray player is required for playback in Region A territories.

The film features English audio (DTS 5.1 and DTS-HD Master Audio) and is presented in WIDESCREEN (1.78:1) format. Special features include an Interactive Menu and Scene Access.

Synopsis: The story centers around veteran assassin Mark Shields as he tracks down Pelon, the elusive head of the Salazar Crime Cartel. Through twists of fate, Shields ends up with a local woman, Olivia, who is also fighting her own demons for the sake of her daughter. Set in the rich and atmospheric backdrop of Tijuana, Mexico, La Linea (The Line) is full of action, drama and finds its soul in the plight of the characters that inhabit the most dangerous city in North America.

2. SETUP

- 1. Verify Player Compatibility:** Ensure your Blu-Ray player is compatible with Region B discs. If you are in a Region A territory (e.g., USA, Canada), you will need a multi-region Blu-Ray player.
- 2. Inspect Disc:** Before insertion, visually inspect the disc for any visible scratches, smudges, or damage.
- 3. Clean Disc (if necessary):** If smudges are present, gently wipe the disc from the center outwards with a soft, lint-free cloth. Do not use abrasive materials or circular motions.
- 4. Insert Disc:** Carefully insert the Blu-Ray disc into your compatible Blu-Ray player's disc tray or slot, ensuring the label side is facing up.

3. OPERATING INSTRUCTIONS

- 1. Power On:** Turn on your Blu-Ray player and your television/display.
- 2. Select Input:** Select the correct input source on your television/display that corresponds to your Blu-Ray player.
- 3. Automatic Playback:** The disc should load automatically and display the main menu or begin playback.
- 4. Navigate Menu:** Use your Blu-Ray player's remote control to navigate the interactive menu. Typically, arrow keys are used for selection and the "Enter" or "OK" button to confirm.
- 5. Select Play:** Choose "Play Movie" or a similar option from the main menu to start the film.
- 6. Access Special Features:** If available, select "Special Features" or "Bonus Content" from the menu to view additional material.
- 7. Scene Selection:** Use the "Scene Access" feature to jump to specific chapters of the movie.

4. MAINTENANCE AND CARE

- Handling:** Always hold the Blu-Ray disc by its edges or by placing a finger in the center hole. Avoid touching the playback surface.
- Cleaning:** For smudges or fingerprints, gently wipe the disc with a soft, lint-free cloth (e.g., microfiber) from the center outwards. Do not use paper towels, abrasive cloths, or harsh cleaning chemicals.
- Storage:** Store the disc in its original case, away from direct sunlight, extreme temperatures, and high humidity. Keep it in a vertical position to prevent warping.
- Avoid Damage:** Do not bend the disc, apply stickers, or write on the playback surface with anything other than a specialized disc marker.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Disc will not play or displays "Incorrect Region" error.	Your Blu-Ray player is not compatible with Region B discs.	Ensure you are using a Region B compatible or multi-region Blu-Ray player. This disc is a Region B import.
Disc skips or freezes during playback.	Disc surface is dirty or scratched. Player lens may be dirty.	Clean the disc gently with a soft, lint-free cloth. If the problem persists, try playing another disc to determine if the issue is with the player.
No audio or video.	Incorrect input selected on TV. Cables are loose. Player settings.	Check TV input. Ensure all cables (HDMI, audio) are securely connected. Verify player's audio/video output settings.
Remote control not working.	Dead batteries. Obstruction.	Replace remote batteries. Ensure no obstructions between remote and player.

6. SPECIFICATIONS

ASIN: B00E3PRE7U
Media Format: Blu-ray, Import, Widescreen
Region Code: B
Run time: 95 minutes
Language: English (Dolby Digital 2.0, DTS 5.1, DTS-HD Master Audio)
Director: James Cotten
Actors: Andy Garcia, Armand Assante, Bruce Davison, Jason Connery, Ray Liotta, Esai Morales, Joe Morton, Jordi Vilasuso, Kevin Gage, Valerie Cruz
Number of discs: 1
Genre: Drama
MPAA rating: Unrated (Not Rated)
Package Dimensions: 7.1 x 5.42 x 0.58 inches; 2.93 ounces
Studio: Unbranded

7. WARRANTY AND SUPPORT

This product is a media disc. Specific warranty information is typically provided by the original distributor or retailer at the time of purchase. Please refer to your purchase documentation for details regarding returns or exchanges. For technical issues related to your Blu-Ray player, please consult your player's user manual or contact its manufacturer. If you believe the disc itself is defective upon arrival, please contact the seller from whom you purchased the item for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00E3PRE7U>

More documents and user manuals: **<https://manuals.plus/>**