

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sharp](#) /
- › [Sharp R-959SLMAA 40L 900W Combination Microwave Oven User Manual](#)

## Sharp R959SLMAA

# Sharp R-959SLMAA 40L 900W Combination Microwave Oven User Manual

## 1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Sharp R-959SLMAA 40L 900W Combination Microwave Oven. Please read this manual thoroughly before using the appliance and retain it for future reference.

The Sharp R-959SLMAA is a versatile 3-in-1 appliance featuring microwave, convection oven, and grill functions, designed for domestic use.

## 2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy. Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.

Ensure the appliance is properly grounded. Do not immerse the cord, plug, or the appliance in water or other liquid. Close supervision is necessary when the appliance is used by or near children.

## 3. SETUP AND INSTALLATION

### 3.1 Unpacking

Carefully remove all packaging materials from the oven and its accessories. Check the oven for any damage, such as dents or a misaligned door. If any damage is present, do not operate the oven and contact your retailer.

### 3.2 Placement

Place the oven on a flat, stable surface that can support its weight (approximately 27 kg). Ensure there is adequate ventilation around the oven. Maintain a minimum clearance of 20 cm on the top, 10 cm on the rear, and 5 cm on the sides for proper airflow. The oven is designed for freestanding installation.

**SHARP**

# 1 YEAR MANUFACTURERS PARTS & LABOUR WARRANTY INCLUDED

You can have peace of mind that if anything does go wrong, you're covered

Image: The Sharp R-959SLMAA microwave oven with its dimensions indicated: 550mm width, 368mm height, and 537mm depth. This illustrates the space required for installation.

### **3.3 Electrical Connection**

Connect the oven to a properly grounded electrical outlet. The oven operates on 230.24 Volts (AC). Do not use extension cords or adapters.

### **3.4 Initial Cleaning**

Before first use, wipe the interior and exterior surfaces of the oven with a soft, damp cloth. Ensure all accessories, such as the turntable and racks, are clean.

## **4. OPERATING INSTRUCTIONS**

### **4.1 Control Panel Overview**

The Sharp R-959SLMAA features a touch control panel for easy operation. Familiarize yourself with the various buttons and display indicators.



Image: A close-up view of the Sharp R-959SLMAA microwave oven's control panel, showing the digital display and various touch buttons for microwave, grill, convection, and auto-cook functions.

## 4.2 Basic Microwave Operation

1. Place food in a microwave-safe container on the turntable.
2. Close the oven door securely.
3. Select the desired microwave power level (up to 900 Watts).
4. Set the cooking time using the time input buttons (e.g., 10 min, 1 min, 10 sec). The oven also features an automatic minute start function.
5. Press the 'Start' button to begin cooking.

## 4.3 Convection Oven Operation

The convection oven function allows for versatile cooking, similar to a conventional oven.

1. Place food on the appropriate rack or baking dish.
2. Select the 'Convection' mode and set the desired temperature.
3. Set the cooking time.
4. Press 'Start'. The oven will preheat to the set temperature before cooking begins.

## 4.4 Grill Operation

Utilize the powerful 1300W quartz grill for browning and crisping food.

1. Place food on the grill rack.
2. Select the 'Grill' mode.
3. Set the grilling time.
4. Press 'Start'.

## 4.5 Combination Modes

The oven offers 3-in-1 combination cooking, allowing you to combine microwave, convection, and grill functions for optimized results. Refer to the control panel for specific combination programs, including 4-step cooking options.



Image: The Sharp R-959SLMAA microwave oven with its door open, showing muffins on a rack inside, illustrating its combination microwave capabilities.

## 4.6 Defrost Function

The electric defrost function allows for efficient thawing of frozen foods. Select the 'Express Defrost' option and input the weight of the food, or manually set a low microwave power level and time for controlled defrosting.

## 4.7 Auto Cook Menus

The oven includes pre-programmed auto-cook menus for various food types. Select the desired menu and input the food weight or quantity, then press 'Start'.

# 5. MAINTENANCE AND CLEANING

## 5.1 Interior Cleaning

The oven interior features a glass coating for easy cleaning. After each use, wipe the interior with a damp cloth to remove food splatters. For stubborn stains, use a mild detergent and a soft sponge. Never use abrasive cleaners or scouring pads.

## 5.2 Exterior Cleaning

Clean the exterior surfaces with a soft, damp cloth. Avoid using harsh chemicals or solvents that could damage the finish.

## 5.3 Turntable and Racks

The glass turntable and metal racks can be removed for cleaning. Wash them in warm, soapy water or in a dishwasher if suitable.

## 6. TROUBLESHOOTING

If your oven is not functioning correctly, please check the following before contacting service:

- **Oven not starting:** Ensure the power cord is securely plugged in and the door is fully closed. Check your household fuse or circuit breaker.
- **Food not heating:** Verify that the cooking time and power level are set correctly. Ensure the door is closed properly.
- **Unusual noise:** Check that the turntable is correctly positioned and not obstructed.
- **Display not working:** Unplug the oven for a few minutes, then plug it back in to reset the system.

For issues not resolved by these steps, please contact customer support.

## 7. SPECIFICATIONS

Feature	Specification
Brand	Sharp
Model Number	R959SLMAA
Dimensions (L x W x H)	55 x 37 x 54 cm
Weight	27 kg
Capacity	40 Litres
Installation Type	Freestanding
Cooking Mode	Convection, Microwave, Grill
Color	Silver
Voltage	230.24 Volts (AC)
Microwave Power	900 Watts
Grill Power	1300 Watts (Quartz)
Defrost Type	Electric Defrost
Material	Glass, Metal
Interior Coating	Glass
Control Type	Touch



Image: A visual summary of the Sharp R-959SLMAA's key features, including 900W power, 3-in-1 combination cooking, various cooking modes, variable power, and a 1-year warranty.

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

Your Sharp R-959SLMAA Combination Microwave Oven comes with a **1 Year Manufacturer's Parts & Labour Warranty**. This warranty covers manufacturing defects and ensures that if anything goes wrong due to faulty materials or workmanship, you are covered for repair or replacement as per the terms and conditions.



Image: A graphic indicating a '1 Year Manufacturers Parts & Labour Warranty Included', assuring customers of coverage for potential issues.

## 8.2 Customer Support

For technical assistance, warranty claims, or to order spare parts, please contact Sharp customer support. Refer to the contact information provided with your purchase documentation or visit the official Sharp website for your region.