

Tivoli Audio MSYBTCLA

Tivoli Audio Music System MSYBTCLA User Manual

Model: MSYBTCLA

1. INTRODUCTION

Welcome to the user manual for your Tivoli Audio Music System MSYBTCLA. This versatile audio system combines classic design with modern functionality, offering AM/FM radio, a CD player, and Bluetooth connectivity. This manual provides detailed instructions to help you set up, operate, and maintain your device, ensuring optimal performance and enjoyment.



Figure 1: Front view of the Tivoli Audio Music System MSYBTCLA.

2. PRODUCT OVERVIEW

2.1. Front Panel Controls

The front panel of your Music System MSYBTCLA features intuitive controls for easy operation.



Figure 2: Close-up of the front panel controls, including source selection, tuning knob, and display.

- **Power/Source Knob:** Turns the unit on/off and selects input source (FM, AM, BT, AUX, CD).
- **Tuning Knob:** Adjusts radio frequency for AM/FM or navigates menus.
- **Volume Knob:** Controls the audio output level.
- **Display:** Shows current mode, station frequency, track information, and time.
- **CD Slot:** For inserting and ejecting audio CDs.
- **Alarm 1/2 Buttons:** For setting and activating alarms.
- **Snooze Button:** Temporarily silences the alarm.

2.2. Rear Panel Connections

The rear panel provides various connection ports for external antennas and audio devices.



Figure 3: Rear panel of the Tivoli Audio Music System MSYBTCLA with various input/output ports.



Figure 4: Detailed view of the rear panel connections, including antenna inputs and auxiliary ports.

- **FM Antenna Input (75 Ohm):** Connects to the external FM antenna.
- **AM Antenna Input:** Connects to the external AM antenna.
- **AUX IN:** 3.5mm stereo input for connecting external audio devices.
- **Headphone Output:** 3.5mm stereo output for private listening.
- **REC OUT:** Audio output for recording.
- **12VDC 800mA:** Power input for the unit.

3. SETUP

3.1. Unpacking

Carefully remove all components from the packaging. Ensure you have the main unit, remote control, power cord, external FM antenna, and external AM antenna.

3.2. Power Connection

1. Connect the power cord to the 12VDC 800mA input on the rear panel.
2. Plug the other end of the power cord into a suitable wall outlet.

3.3. Antenna Connection

1. For FM reception, connect the external FM antenna to the FM Antenna Input (75 Ohm) on the rear panel. Extend the antenna for best reception.
2. For AM reception, connect the external AM antenna to the AM Antenna Input on the rear panel. Position the antenna for optimal signal.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off and Source Selection

1. To power on the unit, rotate the Power/Source knob clockwise from the 'OFF' position.
2. Continue rotating the Power/Source knob to select your desired audio source: FM, AM, BT (Bluetooth), AUX, or CD.
3. To power off, rotate the Power/Source knob counter-clockwise to the 'OFF' position.

4.2. Radio Operation (AM/FM)

1. Select either 'FM' or 'AM' using the Power/Source knob.

2. Use the Tuning knob to scan for radio stations. The display will show the current frequency.
3. Adjust the position of the external antennas for improved reception if needed.

4.3. CD Player Operation

1. Select 'CD' using the Power/Source knob.
2. Gently insert an audio CD into the CD slot with the label side facing up. The unit will automatically load the CD.
3. Playback should begin automatically. Use the remote control or front panel buttons for Play/Pause, Skip Track, and Stop functions.
4. To eject the CD, press the Eject button (usually located near the CD slot or on the remote).

4.4. Bluetooth Operation

The Music System MSYBTCLA features Bluetooth 2.1 plus EDR with A2DP profile for high-quality wireless audio streaming.

1. Select 'BT' (Bluetooth) using the Power/Source knob. The unit will enter pairing mode, indicated on the display.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select 'Tivoli Audio MSYBTCLA' from the list of devices to pair.
4. Once paired, you can stream audio wirelessly from your device to the Music System.

4.5. Auxiliary Input

1. Select 'AUX' using the Power/Source knob.
2. Connect your external audio device (e.g., MP3 player, older audio source) to the 'AUX IN' port on the rear panel using a 3.5mm stereo audio cable.
3. Play audio from your connected device.

4.6. Setting the Clock and Alarm

The unit features an auto-set digital clock with battery backup and dual alarms.

- Refer to the full instruction manual for detailed steps on setting the clock and configuring Alarm 1 and Alarm 2, including snooze functionality.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the unit's exterior. Avoid abrasive cleaners or solvents.
- **CD Player Care:** Keep the CD slot free of dust and debris. Use a CD lens cleaner periodically if playback issues occur.
- **Ventilation:** Ensure adequate ventilation around the unit to prevent overheating. Do not block any ventilation openings.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not active.	Check power cord connection; try a different outlet.
Poor radio reception	Antenna not properly connected or positioned.	Adjust external FM/AM antennas; ensure secure connection.

Problem	Possible Cause	Solution
CD not playing	CD inserted incorrectly; dirty/scratched CD.	Re-insert CD correctly; clean or try a different CD.
Bluetooth pairing failure	Device too far; Bluetooth not enabled on source.	Ensure device is within range; enable Bluetooth on source device.
No sound from AUX IN	Cable not connected; incorrect source selected.	Check AUX cable connection; ensure 'AUX' source is selected.

7. SPECIFICATIONS


- **Brand:** Tivoli Audio
- **Model:** MSYBTCLA
- **Color:** Walnut
- **Product Dimensions:** 35.89 x 24.13 x 13.34 cm (L x W x H)
- **Item Weight:** 5.9 kg (13 Pounds)
- **Power Source:** Corded Electric (12VDC, 800mA)
- **Audio Output Mode:** Stereo
- **Speaker Configuration:** 2.0
- **Supported Audio Formats:** CD, MP3
- **Compatible Media Type:** CD
- **Bluetooth:** Version 2.1 + EDR with A2DP profile
- **Included Accessories:** External AM Antenna, External FM Antenna, Power Cord, Remote Control






8. WARRANTY AND SUPPORT

Tivoli Audio products are designed for durability and performance. For specific warranty information, please refer to the warranty card included with your product or visit the official Tivoli Audio website. For technical support or service inquiries, please contact Tivoli Audio customer service.

- **Manufacturer:** Lenbrook Canada (Audio)
- **Support Contact:** 1-877-297-9479
- **Email:** info@tivolioaudio.com

Related Documents - MSYBTCLA

<div><div><div>Owner's Manual</div><div>Music System</div><div></div><div>Tivoli Audio</div></div></div>	<div>Tivoli Audio Music System Owner's Manual Setup, Features, Safety, Warranty</div> <div>Discover how to operate and maintain your Tivoli Audio Music System with this comprehensive owner's manual. Learn about setup, features, safety guidelines, specifications, and warranty information for your digital AM/FM/CD Hi-Fi system.</div>
---	---

	<p>Tivoli Audio Music System+ Owner's Manual and User Guide</p> <p>Comprehensive guide to the Tivoli Audio Music System+, a DAB/DMB/FM/CD Hi-Fi system with Bluetooth. Includes setup, operation, features, safety, and specifications.</p>
	<p>Tivoli Audio Music System Owner's Manual</p> <p>This comprehensive owner's manual for the Tivoli Audio Music System provides essential information on setup, features, operation, safety, and maintenance for this stereo CD table radio.</p>
	<p>Tivoli Audio Music System Owner's Manual - Setup, Features, and Warranty</p> <p>Comprehensive owner's manual for the Tivoli Audio Music System, covering setup, front and rear panel features, remote control functions, CD player notes, reception, placement, cleaning, and limited warranty information.</p>
	<p>Tivoli Audio Music System BT Owner's Manual and Features</p> <p>Discover the Tivoli Audio Music System BT, a digital AM/FM/CD Hi-Fi system with Bluetooth. This owner's manual details its features, operation, safety instructions, and specifications for high-quality audio playback.</p>
	<p>Tivoli Audio NetWorks Radio with FM: Owner's Manual and Setup Guide</p> <p>Comprehensive owner's manual for the Tivoli Audio NetWorks Radio with FM, covering setup, features, troubleshooting, and specifications. Learn how to connect to WiFi, tune internet radio stations, use music player modes, and more.</p>



[pdf]

Music System Three

Li ION MSY3 Battery Tivoli Audio 7 4V 5200mAh MSY3BATB

Timsy3WHT MSY3BAT ACC 9969 MSY3WHT 01

Tarifa 01blog kakaocdn net dn H976i

btrBmvDr2j8 hj0Ik5Lbx5gyqzV6Gqv8k attach 1 knm tfile |||

Tarifa 2021 MODEL ONE DIGITAL GENERATION 2 Wi-Fi / FM / DAB / Bluetooth

Table radio NEW 11,4 ... de ecualizacin de tonos Conexin auxiliar Conexin para

auricular estero PVP 699 Walnut/Beige **MSYBTCLA** Black/Silver MSYBTBLK

White/Silver MSYBTWHT Cherry/Taupe MSYBTTPPE MUSIC SYSTEM Bluetoo...

lang:es **score:18** filesize: 947.21 K page_count: 10 document date: 2021-10-05