

[Manuals.plus](#) /

› [Wenko](#) /

› WENKO Noble Standing WC Set - Toilet Brush Holder and Paper Holder, Chrome/White Instruction Manual

Wenko 20486100

WENKO Noble Standing WC Set - Toilet Brush Holder and Paper Holder, Chrome/White

INTRODUCTION

Thank you for choosing the WENKO Noble Standing WC Set. This elegant and functional 2-in-1 bathroom accessory combines a toilet paper holder with a hygienic toilet brush holder, designed to save space and enhance your bathroom's aesthetic. This manual provides essential information for the proper assembly, use, and maintenance of your new WC set.



Image: The WENKO Noble Standing WC Set in Chrome/White, showcasing its sleek design and combined functionality.

COMPONENTS

Before assembly, please ensure all components listed below are present in your package. Refer to the diagram for visual

identification of each part.

- **Base Plate:** Made of high-quality polyester resin, providing stability.
- **Main Frame/Stand:** Chrome-plated steel structure for the toilet paper holder and brush container.
- **Toilet Paper Holder Arm:** Integrated into the main frame.
- **Toilet Brush Container:** Steel container for hygienic storage of the toilet brush.
- **Toilet Brush:** Includes a chrome-plated handle and a black, replaceable brush head (Ø 8 cm).
- **Assembly Hardware:** Screws and tools (if required, usually pre-assembled or simple screw-in).



Image: An exploded diagram illustrating all individual components of the WENKO Noble Standing WC Set for easy identification.

SETUP INSTRUCTIONS

The WENKO Noble Standing WC Set is designed for straightforward assembly. Follow these steps to set up your unit:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the "Components" list.
2. **Attach Main Frame to Base:** Secure the chrome-plated steel main frame to the polyester resin base plate. Ensure it is firmly seated and stable. *(Note: Some models may have pre-attached frames or simple screw-in mechanisms. Refer to specific packaging inserts if provided.)*
3. **Insert Toilet Brush Container:** Place the steel toilet brush container into its designated slot on the main frame.
4. **Assemble Toilet Brush:** If the brush head is separate, screw the black plastic brush head onto the chrome-plated handle. Then, place the assembled toilet brush into its container.
5. **Place Toilet Paper:** Mount a roll of toilet paper onto the toilet paper holder arm.



Image: A diagram highlighting the key parts of the assembled WC set, including the toilet paper holder and brush container.

OPERATING INSTRUCTIONS

Using your WENKO Noble Standing WC Set is straightforward:

- **Toilet Paper Dispensing:** Simply pull the desired length of toilet paper from the roll mounted on the holder arm.
- **Toilet Cleaning:** Remove the toilet brush from its container. Use the brush to clean the toilet bowl. After use, allow excess water to drip off before returning the brush to its container for hygienic storage.

MAINTENANCE AND CARE

To ensure the longevity and hygienic condition of your WENKO Noble Standing WC Set, follow these maintenance guidelines:

- **Cleaning the Stand:** Wipe the chrome-plated steel frame and polyester resin base with a soft, damp cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive sponges, which can damage the finish.
- **Cleaning the Brush Container:** Regularly empty and clean the interior of the toilet brush container with a disinfectant cleaner to maintain hygiene.
- **Replacing the Brush Head:** The toilet brush features a replaceable head (Ø 8 cm). To replace, unscrew the old brush head from the handle and screw on a new one. Replacement brush heads can be purchased separately.
- **General Hygiene:** Always return the toilet brush to its container after use to prevent the spread of germs.

TROUBLESHOOTING

If you encounter any issues with your WENKO Noble Standing WC Set, consider the following:

- **Instability:** Ensure the main frame is securely attached to the base plate. Check that the unit is placed on a flat, even surface.
- **Brush Head Wear:** If the brush head becomes worn or ineffective, replace it with a new Ø 8 cm brush head.

For further assistance, please contact WENKO customer support.

SPECIFICATIONS

Brand	Wenko
Model Number	20486100
Color	Chrome/White
Materials	Polyester resin (base), Chrome-plated steel (frame, container, brush handle), Plastic (brush head)
Product Dimensions (W x H x D)	20 x 74 x 15 cm (approximately 7.9 x 29.1 x 5.9 inches)
Item Weight	2200 Grams (2.2 kg / 4.85 lbs)
Brush Head Diameter	8 cm (replaceable)
Special Feature	Reusable, Space-saving 2-in-1 design
Surface Recommendation	Porcelain, Ceramic



Image: The WENKO Noble Standing WC Set with key dimensions indicated, showing its compact footprint.

WARRANTY AND SUPPORT

WENKO products are manufactured to high-quality standards. For any questions regarding your product, warranty claims, or technical support, please refer to the contact information provided with your purchase or visit the official WENKO website.
WENKO Official Website: www.wenko.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question