

Fujifilm INSTAX MINI Twin Pack

FUJIFILM Instax Mini Instant Film Twin Pack User Manual

1. INTRODUCTION AND OVERVIEW

The FUJIFILM Instax Mini Instant Film is an ISO 800 wide picture format integral daylight color film designed for use with FUJIFILM Instax Mini-series cameras. This glossy film produces clear results in various lighting conditions, including daylight and electronic flash. It is suitable for snapshots and portraits, offering improved picture quality and ease of use. The film's compact size is convenient for storage and archival purposes.

FUJIFILM

mini

FUJIFILM



SIMULATED IMAGE / IMAGE SIMULÉE /
IMAGEN SIMULADA

10×2
Sheets/
Feuilles/
Hojas
Packs/
Paquets/
Paquetes

instax mini™

INSTANT FILM/FILM INSTANTANÉ/
PELÍCULA INSTANTÁNEA

Image 1: Front view of the FUJIFILM Instax Mini Instant Film Twin Pack packaging, showing two smiling individuals on a developed photo.

2. SAFETY INFORMATION AND IMPORTANT NOTICES

- **X-Ray Inspection:** To prevent fogging of unexposed film during X-ray inspection of luggage at airports, always carry the film in hand baggage. Do not place film in checked luggage.
- **Temperature Range:** Use the film within a temperature range of 41°F to 104°F (5°C to 40°C).
- **Storage:** Store film in cool and dry conditions. Do not freeze.
- **Film Handling:** Avoid exposing the film to direct sunlight or high temperatures. Do not open the film pack until ready to load into the camera.
- **Chemicals:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Handle with care and avoid contact with skin or eyes. If contact occurs, immediately wash with water and consult a doctor if irritation persists.



www.fujifilm.com

• instax mini Film is designed for use with the INSTAX MINI instant print devices.
• Les films instax mini sont conçus pour l'utilisation avec les dispositifs d'impression instantanée INSTAX MINI. • La película Instax mini está diseñada para usarse con dispositivos de impresoras instantáneas INSTAX MINI.

Attention : Store film in dry, cool place. Use of damaged/expired film may damage INSTAX® camera. Film contains small amount of highly caustic paste; paste can remain active up to 10 minutes after picture is taken. Keep away from children & animals. Do not cut, peel apart or puncture new or newly used film. In case of skin, eye or mouth contact, immediately wash liberally with water to avoid burns & consult doctor. To prevent fogging of unexposed film during X-ray inspection of luggage at airports, carry in hand baggage. Use at 5-40°C (41-104°F).

Limited 90-day warranty (for original buyer only) : Fujifilm will replace non-expired film defective upon purchase as buyer's sole warranty & remedy. Buyer statutory remedies may apply. Canada buyers contact FUJIFILM Canada, 600 Suffolk Ct Mississauga ON L5R 4G4 at fcancustservice@fujifilm.com. U.S. and Latin American buyers contact FUJIFILM North America Service & Support, at Digitalinfo@fujifilm.com. **Fujifilm's liability limited to film price; Fujifilm is not liable for indirect or consequential damages.**

Attention : À conserver dans un endroit frais et sec. L'utilisation d'un film endommagé ou périmé pourrait endommager l'appareil INSTAX^{MD}. Ces films contiennent une faible quantité de pâte à haute causticité; cette pâte peut rester active jusqu'à 10 minutes après la saisie de la photo. Tenir hors de la portée des enfants et des animaux. Ne pas couper, séparer ou perforer un film neuf ou nouvellement utilisé. En cas de contact avec la peau, les yeux ou la bouche, laver immédiatement à grande eau pour éviter toute brûlure puis consulter un médecin. Pour éviter qu'ils soient voilés par les rayons X lors des inspections dans les aéroports, les films non exposés devraient être placés dans un bagage à main. À utiliser à 5-40°C (41-104°F).

Garantie limitée de 90 jours (acheteur initial seulement) : Fujifilm remplacera tout film non expiré s'il est défectueux au moment de l'achat. Cette garantie est l'unique recours de l'acheteur. D'autres recours en droit peuvent s'appliquer. Les acheteurs du Canada peuvent communiquer avec FUJIFILM Canada au 600 Suffolk Ct Mississauga ON L5R 4G4 ou à fcancustservice@fujifilm.com. Aux États-Unis et en Amérique latine, l'acheteur peut s'adresser à FUJIFILM North America Service & Support à Digitalinfo@fujifilm.com. **La responsabilité de Fujifilm ne dépasse pas le prix des films, et Fujifilm n'est pas responsable des dommages indirects ou consécutifs.**

Atención : Almacene la película en un lugar seco y fresco. El uso de una película dañada/vencida puede dañar la cámara INSTAX[®]. La película contiene una pequeña cantidad de pasta altamente cáustica; la pasta puede permanecer activa hasta 10 minutos después de tomar la foto. Mantenga alejado de niños y animales. No corte, despegue ni perforo una película nueva o recién utilizada. En caso de contacto con la piel, los ojos o la boca, lave inmediatamente abundantemente con agua para evitar quemaduras y consulte al Médico. Para evitar el empañamiento de la película no expuesta durante la inspección de rayos X del equipaje en los aeropuertos, llévela en el equipaje de mano. Usar a 5-40°C (41-104°F).

Garantía limitada de 90 días (para el comprador original solamente) : Fujifilm reemplazará la película no expirada defectuosa al momento de la compra como única garantía y reparación del comprador. Se pueden aplicar los recursos legales del comprador. Para los compradores de Canadá el servicio de atención es FUJIFILM Canada, 600 Suffolk Ct Mississauga ON L5R 4G4 en fcancustservice@fujifilm.com. Los compradores en los EE. UU. y América Latina deben comunicarse con el servicio y soporte de FUJIFILM North America en Digitalinfo@fujifilm.com. **La responsabilidad de Fujifilm se limita al precio de la película; Fujifilm no es responsable por daños indirectos o consecuentes.**

MADE IN JAPAN / FABRIQUÉ AU JAPON / HECHO EN JAPÓN by / par / por FUJIFILM Corporation
7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN/JAPON/JAPÓN

Image 2: Back of the film packaging showing safety warnings and handling instructions in multiple languages, including advice on X-ray exposure and chemical contact.

3. SETUP: LOADING THE FILM CARTRIDGE

Each film cartridge is designed for easy loading into compatible FUJIFILM Instax Mini cameras. Each pack contains 10 credit card-sized instant prints. Follow your camera's specific instructions for loading film.

1. Ensure your Instax Mini camera is turned off.
2. Open the film compartment cover on your camera.
3. Align the yellow mark on the film cartridge with the yellow mark inside the camera's film compartment.
4. Gently insert the film cartridge until it clicks into place. Do not force it.
5. Close the film compartment cover. The camera will automatically eject the dark slide (protective sheet).
6. Your camera is now ready to take photos. The counter on your camera should indicate the number of remaining exposures.



Image 3: A single FUJIFILM Instax Mini film cartridge, showing the packaging and barcode (UPC: 0074101944686). This cartridge is loaded into the camera.

4. OPERATING: TAKING AND DEVELOPING PHOTOS

Once the film is loaded, you can begin taking instant photos with your Instax Mini camera. The film is designed for quick development.

- **Taking a Photo:** Aim your camera and press the shutter button. The photo will automatically eject from the camera.
- **Development Process:** After ejection, the image will begin to develop in front of your eyes. This process typically takes about one minute, with full development occurring over several minutes. Avoid bending or shaking the film during development.
- **Image Quality:** The film features ISO 800 sensitivity, providing vibrant colors and natural skin tones. It performs well in low-light conditions.
- **Film Size:** Each developed photo has a picture size of 2.4" x 1.8" (6.2 cm x 4.6 cm) and a film size of 3.4" x 2.1" (8.6 cm x 5.4 cm), similar to a credit card. The white frame can be left blank or

personalized.

instax[®] mini



Get the
Right Film

Choisissez
les bons films




Image 4: Diagram illustrating the dimensions of a developed FUJIFILM Instax Mini photo, showing a film size of 85mm (3.35 inches) in height and 54mm (2.13 inches) in width.

5. MAINTENANCE: STORAGE AND HANDLING OF DEVELOPED PHOTOS

Proper storage of both unused film and developed photos helps maintain their quality and longevity.

- **Unused Film:** Store film packs in a cool, dry place, away from direct sunlight and high humidity. Do not freeze.
- **Developed Photos:** Once developed, store photos in an album or frame to protect them from light, moisture, and physical damage. Avoid prolonged exposure to direct sunlight, which can cause fading over time.
- **Cleaning:** If a photo gets dirty, gently wipe it with a soft, dry cloth. Avoid using liquids or abrasive materials.



Image 5: Packaging detail showing instructions to store the film in cool and dry conditions and not to freeze it, along with a warning to protect from X-ray.

6. SPECIFICATIONS

Product Name	FUJIFILM Instax Mini Instant Film Twin Pack
Model Number	INSTAX MINI Twin Pack
Brand	Fujifilm
Film Type	Instant Color Film
Film Format	Instax Mini
Film Speed	ISO 800
Exposures per Pack	10 (Twin Pack contains 2 packs, totaling 20 exposures)
Picture Size	6.2 cm x 4.6 cm (2.4" x 1.8")
Film Size	8.6 cm x 5.4 cm (3.4" x 2.1")
Product Dimensions (Packaging)	2.6 x 1.9 x 4 inches
Item Weight	0.634 ounces

7. TROUBLESHOOTING

Most issues related to instant film are often linked to improper handling or camera malfunction rather than the film itself. Consider the following if you encounter problems:

- **Blank or Underexposed Photos:** Ensure your camera's flash is working correctly and that you are shooting in appropriate lighting conditions. Check camera settings.
- **Overexposed Photos:** Avoid shooting in excessively bright conditions without proper camera settings.

- **Film Not Ejecting:** Verify the film cartridge is loaded correctly and that your camera's batteries are sufficiently charged.
- **Streaks or Marks on Photos:** This can sometimes be caused by pressure on the film during development or issues with the camera's rollers. Ensure the film is not bent or obstructed during ejection.
- **Expired Film:** Always check the expiration date on the film packaging. Using expired film can lead to unpredictable results.

If problems persist, consult your FUJIFILM Instax Mini camera's instruction manual or contact FUJIFILM customer support.

8. WARRANTY AND SUPPORT


FUJIFILM offers a 90-day limited warranty for this product, covering manufacturing defects. For warranty claims or technical support, please retain your original purchase receipt.

For further assistance, you may contact FUJIFILM customer support:

- **North America:** FUJIFILM North America Corporation, 200 Summit Lake Drive, Valhalla, NY 10595, U.S.A.
- **Canada:** FUJIFILM Canada Inc., 600 Suffolk Ct, Mississauga ON L5R 4G4, Canada.
- You can also visit the official FUJIFILM website for support resources and contact information: www.fujifilm.com

Related Documents - INSTAX MINI Twin Pack

	Fujifilm instax mini 41 Instant Camera User Guide and Safety Precautions Comprehensive user guide and safety precautions for the Fujifilm instax mini 41 instant camera, covering setup, operation, troubleshooting, and important safety information.
	FUJIFILM instax mini Evo Hybrid Instant Camera User Guide This guide provides essential information for operating the FUJIFILM instax mini Evo hybrid instant camera, including setup, features, printing, safety, and care instructions.
	Fujifilm Instax Mini LiPlay Hybrid Instant Camera User's Guide This user's guide provides comprehensive instructions for operating the Fujifilm Instax Mini LiPlay Hybrid Instant Camera, covering setup, shooting, playback, printing, and troubleshooting.
	Fujifilm Instax Mini LiPlay User Guide A comprehensive guide to the Fujifilm Instax Mini LiPlay hybrid instant camera, covering its features, functions, and safety precautions.

	FUJIFILM instax WIDE Evo Hybrid Instant Camera User's Guide Comprehensive user guide for the FUJIFILM instax WIDE Evo hybrid instant camera, covering setup, basic operations, advanced shooting features, effects, playback, settings, and smartphone app integration. Learn how to take photos, use creative effects, manage storage, and connect with the instax WIDE Evo app.
	FUJIFILM instax mini LiPlay Hybrid Instant Camera User Guide Explore the FUJIFILM instax mini LiPlay, a compact hybrid instant camera with digital technologies. This guide provides essential information on features, usage, and care for your instant photo printing experience.