

[Manuals.plus](#) /

› [LELO](#) /

› LELO LIV 2 G-Spot Vibrator Instruction Manual

LELO LIV 2

LELO LIV 2 G-Spot Vibrator Instruction Manual

PRODUCT OVERVIEW

About the LELO LIV 2

The LELO LIV 2 is a body-contoured personal massager designed for intimate pleasure. Its smooth form and powerful vibrations offer an enhanced experience for both new and experienced users. This device is fully waterproof, rechargeable, and features multiple intensity patterns.

What's in the Box

- LELO LIV 2 Device
- USB Charging Cord
- Satin Storage Pouch
- Warranty Registration Card
- Detailed Instruction Manual



The LELO LIV 2 device shown with its complete set of accessories.

SETUP GUIDE

Initial Charging

Before first use, charge your LELO LIV 2 for 2 hours.

1. Insert the small plug of the USB charging cord into the DC port at the base of your LIV 2.
2. Insert the main USB plug into any USB port (e.g., computer, smartphone charger).

The LED on the device interface will pulse to indicate charging. Once fully charged, the LED will emit a steady glow.

Important:

- Use only the LELO charging cable to prevent battery damage.
- Do not leave the device charging overnight.

If the LED does not light up immediately upon connecting the charger, the battery may be completely depleted. It will take a few minutes for the device to begin charging and for the light to appear.

Unlocking for First Use

Your LELO LIV 2 is locked for transportation.

- **To unlock:** Press and hold the '+' and '-' buttons simultaneously for 5 seconds until the lights turn on.
- **To lock for travel:** Repeat the same procedure.

Your browser does not support the video tag.

Instructional video demonstrating the unboxing, charging, unlocking, operation, and cleaning of the LELO LIV 2.

OPERATING INSTRUCTIONS

Turning On/Off

- **To turn on:** Press the '+' button.
- **To turn off:** Press and hold the '-' button.

Adjusting Vibration Strength

- Once turned on, press the '+' button again to increase vibration strength.
- Use the '-' button to decrease vibration strength.

Changing Vibration Patterns

To switch between different vibration patterns, use the up and down buttons. Experiment to find your preferred pattern.

CARE AND MAINTENANCE

Cleaning

The LELO LIV 2 is fully waterproof, making cleaning simple. Always clean the device thoroughly before and after each use.

- The safest method is to use LELO Premium Cleaning Spray. Rinse the device, apply the spray, and then rinse again before allowing it to air dry.
- If the spray is unavailable, you can wash the silicone with lukewarm water and antibacterial soap. Rinse with clean water and pat dry with a lint-free cloth or towel.

Caution:

- Never use cleaners containing alcohol, petrol, or acetone, as these can damage the silicone.

Storage

After cleaning and drying, store your LELO LIV 2 in the provided satin pouch. Keep it in a dry and safe place, away from direct heat or sunlight.

The charging port is vacuum-sealed, so you do not need to worry about water damaging your device, but always ensure the port is dry before connecting the charger for next use.

WARRANTY AND SUPPORT

Product Registration

To claim your warranty, you must register your product on [LELO.com](https://www.lelo.com).

1. Visit [LELO.com](https://lelo.com) and click on "REGISTER/LOG IN" at the top right-hand corner.
2. Create an account or log in.
3. Click "Register Product" and fill in the requested details, including the serial number found on your Product Authenticity Card.

If purchased from a retailer, retain your receipt for warranty purposes.

LELO offers a 1-Year Warranty for faulty products and a 10-Year Quality Guarantee.

Contact Support

For any further questions or assistance, please contact LELO Customer Service at customercare@lelo.com.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Number	7908
ASIN	B00EOX45LY
Color	Cerise
Material	Silicone
Dimensions	6.85 x 1.38 x 1.14 inches
Weight	3.17 ounces
Battery	1 Lithium Polymer battery (rechargeable)
Waterproof	Yes
Manufacturer	LELO
First Available	December 15, 2011

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00EOX45LY>

More documents and user manuals: <https://manuals.plus/>