

[Manuals.plus](#) /

› [Toysmith](#) /

› Toysmith Batman Bendable Figure (5-Inch) Instruction Manual

Toysmith 3907

Toysmith Batman Bendable Figure (5-Inch) Instruction Manual

Model: 3907

INTRODUCTION

Thank you for choosing the Toysmith Batman Bendable Figure. This 5-inch figure allows for creative play and display, featuring a bendable and poseable design. This manual provides important information for safe and enjoyable use.

IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise young children during play.
- Inspect the figure regularly for any damage or loose parts.
- Keep away from extreme temperatures and open flames.
- This product is made using safe and high-quality materials, designed for durability.

SETUP

The Toysmith Batman Bendable Figure comes ready for play directly out of its packaging. No assembly is required.

1. Carefully remove the figure from its packaging.
2. Dispose of packaging materials responsibly.
3. The figure is now ready for use.



Image: The Toysmith Batman Bendable Figure, still sealed in its blister packaging, showcasing the 'Bendable' and 'Poseable' features, along with the DC Comics logo and a choking hazard warning.

OPERATING INSTRUCTIONS

The Batman Bendable Figure is designed for flexible posing and imaginative play.

- **Bending and Posing:** Gently bend the figure's limbs and torso to achieve desired poses. The internal wire structure allows for various positions.
- **Creative Play:** Use the figure for imaginative scenarios, desktop display, or as part of a larger toy collection.
- Avoid excessive force or sharp bending angles to prevent damage to the figure's internal structure or exterior paint.

CARE AND MAINTENANCE

- **Cleaning:** To clean the figure, wipe it gently with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent material degradation or color fading.
- **Inspection:** Periodically check the figure for any signs of wear, tear, or damage. Discontinue use if significant damage is observed.

TROUBLESHOOTING

This section addresses common observations and concerns regarding the bendable figure.

Issue	Possible Cause	Solution
Figure does not hold pose well.	Repeated bending or extreme angles may reduce flexibility over time.	Gently adjust the pose. Avoid forcing the figure into unnatural positions. Note that some flexibility may be inherent to the bendable design.
Paint chipping or wear.	Normal wear and tear from play, especially with frequent bending or rough handling.	This is a common occurrence with bendable figures. To minimize, handle with care and avoid abrasive surfaces.

PRODUCT SPECIFICATIONS

- **Model Number:** 3907
- **Product Dimensions:** 1.25 x 5.5 x 8 inches
- **Item Weight:** 2.4 ounces
- **Recommended Age:** 36 months - 15 years
- **Material:** Safe and high-quality materials
- **Brand:** Toysmith

WARRANTY AND SUPPORT

For any questions or concerns regarding your Toysmith Batman Bendable Figure, please contact Toysmith customer support. Specific warranty details may vary; please refer to the product packaging or Toysmith's official website for the most current information.

This product is designed for durability and enjoyment when used as intended.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question