

[Manuals.plus](#) /

> [Vileda](#) /

> Vileda Glitzi Plus Sponge 9-Pack Instruction Manual

Vileda Glitzi Plus

Vileda Glitzi Plus Sponge Instruction Manual

Model: Glitzi Plus

Brand: Vileda

1. PRODUCT OVERVIEW

The Vileda Glitzi Plus Sponge is designed for thorough cleaning with an integrated anti-bacterial effect. This 9-pack provides multiple sponges for various household cleaning needs. Each sponge features two distinct sides for different cleaning tasks: a black abrasive side for removing stubborn dirt and a blue cloth side for gentle wiping and drying. The ergonomic grip is designed to protect hands and fingernails during use. The Vileda anti-bac effect inhibits bacterial growth on the scrubbing surface by 99.9%, contributing to a more hygienic cleaning environment.



Image 1.1: Vileda Glitzi Plus Sponges, illustrating both the abrasive and gentle cleaning sides.

2. SETUP

The Vileda Glitzi Plus Sponge requires minimal setup. Simply remove a sponge from its packaging. For optimal performance, moisten the sponge with water before applying cleaning solution or using it for scrubbing.

3. OPERATING INSTRUCTIONS

Follow these guidelines for effective cleaning with your Vileda Glitzi Plus Sponge:

- **Black Abrasive Side:** Use this side for tackling tough, dried-on food, grease, and stubborn stains on durable surfaces. Apply moderate pressure as needed.
- **Blue Cloth Side:** Utilize this side for gentle cleaning, wiping surfaces, and drying. It is suitable for delicate items and general surface cleaning.
- **Grip Protection:** The sponge features a practical grip design to enhance comfort and protect your hands and fingernails during extended cleaning tasks.
- **Recommended Surfaces:** This sponge is suitable for cleaning glass, ceramic, melamine, plastic, and stainless steel surfaces. Always test on an inconspicuous area first if unsure about surface compatibility.



Image 3.1: Demonstrating the sponge in use for cleaning a kitchen faucet.



Image 3.2: Demonstrating the sponge in use for scrubbing a dirty pot.

4. MAINTENANCE

To maintain the effectiveness and hygiene of your Vileda Glitzi Plus Sponge:

- **Rinse After Use:** Always rinse the sponge thoroughly with clean water after each use to remove food particles and cleaning solution residue.
- **Air Dry:** Allow the sponge to air dry completely between uses to prevent odors and maintain its anti-bacterial properties.
- **Anti-Bac Effect:** The integrated anti-bac effect helps to inhibit bacterial growth on the sponge surface, but regular rinsing is still essential.

5. TROUBLESHOOTING

If you experience reduced cleaning performance or notice excessive wear:

- **Reduced Effectiveness:** Over time, the abrasive and cloth surfaces may wear down. If the sponge no longer cleans effectively, it is time to replace it.
- **Odor Development:** If the sponge develops an unpleasant odor despite rinsing, it indicates bacterial

buildup. Replace the sponge immediately to maintain hygiene.

6. SPECIFICATIONS

Model Name	Vileda Glitzi Plus
Item Number	142596
Material	Foam (100% Polyurethane), Abrasive (17% Polyamide, 7% Polyester, 24% Resin, 51% Quartz, 1% Silicon Carbide), Cloth (80% Viscose, 20% Polypropylene)
Product Dimensions	9 x 6.8 x 4.5 cm
Product Weight	99.79 g
Color	Yellow (sponge body)
Special Feature	Anti-bacterial effect (Silver Chloride)
Number of Items	9
Recommended Use	Cleaning
Recommended Surfaces	Glass, Ceramic, Melamine, Plastic, Stainless Steel
Manufacturer	VILEDA GMBH
Country of Origin	Slovenia

7. WARRANTY AND SUPPORT

Specific warranty information for the Vileda Glitzi Plus Sponge is not provided in the product details. For any product-related inquiries or support, please refer to the manufacturer's official website or contact their customer service directly. Contact details are typically available on the product packaging or the Vileda brand website.