

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Petra](#) /

› [Petra Electric Pro Blender MX 26.35 User Manual](#)

Petra MX 26.35

Petra Electric Pro Blender MX 26.35 User Manual

Model: MX 26.35 | Brand: Petra Electric

INTRODUCTION

Thank you for choosing the Petra Electric Pro Blender MX 26.35. This powerful 800W appliance is designed to help you create delicious smoothies and milkshakes with ease. Featuring two speed settings, a pulse function, and a unique 'Splash Guard' system, it ensures consistent results. Please read this manual carefully before first use to ensure safe and optimal operation of your blender. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Keep hands and utensils out of the container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate the blender with the lid in place.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the parts of your Petra Electric Pro Blender MX 26.35.

- Motor Base (Stainless Steel)
- Glass Blending Jar (1.5 L capacity)
- Lid with Filling Opening
- Stainless Steel Blade Assembly (6 cutting blades)
- Control Knob (2 speeds + Pulse function)
- Splash Guard System



Image 1: The Petra Electric Pro Blender MX 26.35, showing the stainless steel motor base, the glass blending jar with handle, and the lid. A separate glass tube accessory is also visible next to the main unit.



Image 2: A close-up view of the clear glass blending jar, highlighting its sturdy handle and the internal design for efficient blending.



Image 3: A detailed view of the control knob on the blender's stainless steel base, illuminated with a blue light, indicating power or operational status.



Image 4: A slender glass tube accessory with a black base, designed for specific blending tasks or as a personal blending cup.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Clean:** Before first use, wash the glass blending jar, lid, and blade assembly in warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Assemble Blade:** Ensure the stainless steel blade assembly is securely attached to the bottom of the glass blending jar.
4. **Place Jar:** Position the assembled glass jar onto the motor base. Ensure it is seated correctly and locked into place (locking function).

5. **Power Connection:** Plug the power cord into a suitable electrical outlet (220-240V).

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut ingredients into small pieces (approximately 2-3 cm) for optimal blending.
2. **Add Ingredients:** Place ingredients into the glass blending jar. Do not exceed the maximum level indicator (1.5 L). For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.
3. **Secure Lid:** Place the lid firmly onto the blending jar. Ensure the filling opening is closed or used for adding ingredients during blending if necessary.
4. **Select Speed:** Turn the control knob to your desired speed setting (Speed 1 or Speed 2). Speed 1 is suitable for lighter blending tasks, while Speed 2 is for tougher ingredients.
5. **Pulse Function:** For short bursts of power or to chop ingredients, turn the control knob to the 'Pulse' setting and hold it. Release to stop.
6. **Blending:** Allow the blender to run until desired consistency is achieved. Do not operate continuously for more than 60 seconds to prevent overheating. Allow a short break between cycles.
7. **Stop:** Turn the control knob back to the 'OFF' position when blending is complete.
8. **Remove Jar:** Carefully remove the blending jar from the motor base.

Tip: The unique 'Splash Guard' system helps prevent spills and ensures a more homogeneous blend.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Remove the blending jar from the motor base. Carefully detach the blade assembly from the jar. Remove the lid.
3. **Cleaning Jar and Lid:** The glass blending jar, lid, and blade assembly are dishwasher-safe. Alternatively, wash them in warm, soapy water using a brush for the blades. Rinse thoroughly and dry.
4. **Cleaning Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid. Do not use abrasive cleaners or scouring pads.
5. **Storage:** Ensure all parts are completely dry before reassembling or storing the blender. Store in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your blender, please refer to the following common problems and solutions:

- **Blender does not turn on:**
 - Ensure the power cord is securely plugged into a working outlet.
 - Check if the blending jar is correctly seated and locked onto the motor base. The blender has a locking function that prevents operation if not properly assembled.
- **Ingredients are not blending smoothly:**
 - Ensure ingredients are cut into small pieces.
 - Add more liquid if the mixture is too thick.
 - Use the pulse function to break up larger pieces or dislodge ingredients stuck around the blades.
 - Do not overload the blender beyond the 1.5 L capacity.
- **Blender stops during operation:**
 - The blender may have overheated. Turn it off, unplug it, and let it cool down for at least 15-20 minutes before

attempting to use it again.

- Check for any obstructions around the blades.

- **Leakage from the bottom of the jar:**

- Ensure the blade assembly is tightly secured to the bottom of the glass jar.
- Check the seal/gasket for proper placement and any damage.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Brand	Petra
Model Number	MX 26.35
Manufacturer	Petra Electric
Power	800 Watts
Voltage	220-240 Volts
Capacity	1.5 Liters
Number of Speeds	2 + Pulse Function
Material	Stainless Steel (body), Glass (jar), Plastic (components)
Product Dimensions (L x W x H)	17.5 x 15.5 x 37 cm
Item Weight	3.04 Kilograms
Dishwasher Safe Parts	Yes (Jar, Lid, Blade Assembly)
Special Feature	Smoothie function, Splash Guard, Locking function

WARRANTY AND SUPPORT

Your Petra Electric Pro Blender MX 26.35 comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or inquiries regarding spare parts, please contact Petra Electric customer service. Please have your model number (MX 26.35) and proof of purchase available when contacting support.

Note: Information regarding the availability of spare parts is currently unavailable.