

[Manuals.plus](#) /

› [Soundfreaq](#) /

› Soundfreaq SFQ-07WW Sound Spot Compact Bluetooth Speaker User Manual

Soundfreaq SFQ-07WW

Soundfreaq SFQ-07WW Sound Spot Compact Bluetooth Speaker User Manual

Model: SFQ-07WW

INTRODUCTION

The Soundfreaq SFQ-07WW Sound Spot is a compact Bluetooth speaker designed for portable audio. It features wireless Bluetooth connectivity, a rechargeable battery, and a universal USB power port for charging. This manual provides instructions for setting up, operating, maintaining, and troubleshooting your Sound Spot speaker.

Key Features:

- Bluetooth wireless connectivity for audio streaming.
- Integrated rechargeable battery for portable use (up to 7 hours playtime).
- USB power port for charging the speaker and other devices.
- Compact design.
- Easy one-touch pairing.




Figure 1: Front view of the Soundfreaq SFQ-07WW Sound Spot speaker, showcasing its wood and white design with a circular speaker grille.

SETUP

1. Charging the Speaker

Before initial use, fully charge your Sound Spot speaker. Connect the provided USB cable to the speaker's USB power port and the other end to a compatible USB power adapter (not included) or a computer's USB port.

- The charging indicator light will illuminate during charging.
- A full charge typically takes approximately 3-4 hours.
- The speaker can be used while charging.

2. Powering On/Off

Press and hold the Power button (usually marked with a power symbol) located on the top panel of the speaker until the indicator light illuminates or extinguishes.



Figure 2: Top panel of the Sound Spot speaker, displaying the power, pair, track control, and volume buttons.

3. Bluetooth Pairing

To connect your Sound Spot speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on.
2. Press the "PAIR" button on the top panel of the speaker. The Bluetooth indicator light will begin to flash, indicating it is in pairing mode.
3. On your audio device (smartphone, tablet, computer), navigate to the Bluetooth settings.
4. Select "Sound Spot" from the list of available devices.
5. Once connected, the Bluetooth indicator light on the speaker will become solid.
6. If prompted for a passcode, enter "0000".

The speaker will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Audio Playback

Once paired via Bluetooth, you can control audio playback directly from your connected device or using the buttons on the speaker's top panel:

- **Play/Pause:** Press the Play/Pause button (||) to start or pause audio.
- **Next Track:** Press the Next Track button (>>) to skip to the next song.
- **Previous Track:** Press the Previous Track button (<<) to go to the beginning of the current song or the previous song.
- **Volume Up:** Press the "+" button to increase the volume.

- **Volume Down:** Press the "-" button to decrease the volume.

Charging External Devices

The Sound Spot speaker features a universal USB power port that allows you to charge your smartphone or other USB-powered devices, even when the speaker is running on its internal battery.

- Connect your device's USB charging cable to the USB port on the Sound Spot speaker.
- Charging will begin automatically.

MAINTENANCE

Cleaning

To maintain the appearance and functionality of your speaker:

- Wipe the exterior surfaces with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, waxes, or solvents.
- Avoid exposing the speaker to excessive moisture. The speaker is not waterproof.

Battery Care

To prolong battery life:

- Charge the speaker fully before first use.
- Avoid completely draining the battery frequently.
- If storing the speaker for an extended period, charge it to approximately 50% every few months.
- Do not expose the battery to extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted.	Connect the speaker to a power source using the USB cable and allow it to charge.
Cannot pair via Bluetooth	Speaker is not in pairing mode; device's Bluetooth is off; speaker is already connected to another device.	• Ensure the speaker is powered on and press the "PAIR" button. • Verify Bluetooth is enabled on your device. • Disconnect the speaker from any other paired devices. • Move your device closer to the speaker.
No sound or low volume	Volume on speaker or device is too low; speaker is not properly connected.	• Increase volume on both the speaker and your connected device. • Ensure the speaker is successfully paired and connected to your device.

Problem	Possible Cause	Solution
Short battery life	Battery is old or not fully charged; high volume usage.	• Ensure the speaker is fully charged before use. • Battery performance may degrade over time with repeated charge cycles. • Lowering the volume can extend battery life.
Distorted audio	Volume too high; weak Bluetooth signal; audio source quality.	• Reduce the volume on both the speaker and your device. • Move the connected device closer to the speaker to improve signal strength. • Try a different audio source or file.

SPECIFICATIONS

Feature	Detail
Model Number	SFQ-07WW
Brand	Soundfreaq
Connectivity Technology	Bluetooth
Speaker Maximum Output Power	25 Watts
Audio Output Mode	Stereo
Battery Average Life	7 Hours
Power Source	Battery Powered, USB Powered
Control Method	Touch
Item Weight	1 Pound
Color	Wood & White
Built-In Media	USB cable
Is Waterproof	FALSE

WARRANTY INFORMATION

The Soundfreaq SFQ-07WW Sound Spot speaker comes with a **1-year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. The warranty does not cover:

- Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes.

- Damage caused by operating the product outside the permitted or intended uses described by Soundfreaq.
- Damage caused by service performed by anyone who is not a representative of Soundfreaq.
- Products or parts that have been modified.
- Consumable parts, such as batteries, unless damage occurred due to a defect in materials or workmanship.

For detailed warranty terms and conditions, please refer to the official Soundfreaq website or contact customer support.

SUPPORT

For further assistance, technical support, or warranty claims, please visit the official Soundfreaq website or contact their customer service department.

Online Resources:

- [Soundfreaq Store on Amazon](#)
- Refer to the product packaging or Soundfreaq's official website for direct contact information.

When contacting support, please have your product model number (SFQ-07WW) and purchase information readily available.

© 2023 Soundfreaq. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question