

[Manuals.plus](#) /

› [Outsunny](#) /

› Outsunny Multifunctional Folding Camping Cot Instruction Manual

Outsunny B2-0006

Outsunny Multifunctional Folding Camping Cot

Model: B2-0006 | Brand: Outsunny

INTRODUCTION

The Outsunny Multifunctional Folding Camping Cot provides a versatile and comfortable sleeping solution for outdoor adventures. This all-in-one portable set includes a tent with cover, a comfortable camp bed, an air mattress with matching covers, a foot pump, a pillow, and a sleeping bag. Designed for easy transport and storage, this elevated tent system keeps you off the ground, offering enhanced comfort and protection from the elements. The components can be used together as a complete unit or separately, providing flexibility for various camping needs.



Figure 1: Fully assembled Outsunny Multifunctional Folding Camping Cot.

COMPONENTS

Your Outsunny Multifunctional Folding Camping Cot package includes the following items:

- **Tent with Cover:** Provides shelter and privacy.
- **Camping Cot:** Elevated bed frame for off-ground sleeping.
- **Air Mattress:** Inflatable mattress for added comfort.
- **Air Mattress Cover:** Protects the air mattress.
- **Foot Pump:** For inflating the air mattress.
- **Pillow:** Small inflatable pillow.
- **Sleeping Bag:** For warmth and comfort.
- **Carry Bag:** For easy transport and storage of all components.



Figure 2: The 4-in-1 camping combo components.

SETUP GUIDE

1. Air Mattress Inflation

Unroll the air mattress and locate the inflation valve. Connect the provided foot pump to the valve. Use the foot pump to inflate the mattress to your desired firmness. Ensure the valve is securely closed after inflation to prevent air leakage.



INFLATABLE MATTRESS



easy to fold



soft and comfortable

Figure 3: Inflating the air mattress with the foot pump.

2. Camping Cot Assembly

Unfold the cot frame completely. Ensure all legs are extended and locked into place. The cot features a sturdy aluminum alloy structure with non-slip feet for stability on various terrains. Insert the side rods into the designated holes on the cot frame, ensuring they are securely fastened. This step may require some force to create proper tension in the cot fabric.



Figure 4: Assembling the camping cot frame.

3. Tent Assembly

Assemble the tent poles by connecting the segments. The poles are typically connected by an elastic cord for easy assembly. Locate the central plastic connector piece, which is crucial for holding the tent poles together at the top. Thread the assembled poles through the sleeves on the tent fabric, starting from the bottom and working your way up to the central connector. Insert the pole ends into the connector to form the tent's dome shape.

4. Integrating Tent with Cot

Once the cot is assembled and the air mattress is placed on it (with its cover), carefully position the assembled tent over the cot. The tent is designed to sit on top of the cot, with straps or loops to secure it to the cot frame. Ensure the tent is centered and all attachment points are fastened to prevent movement. The air mattress will fit snugly inside the tent, providing a sealed sleeping area.

Your browser does not support the video tag.

Video 1: Official Outsunny B2-0006 Camping Cot Assembly Guide. This video demonstrates the assembly process for the camping cot and tent components.

OPERATING INSTRUCTIONS

The Outsunny Multifunctional Folding Camping Cot is designed for ease of use in various outdoor conditions.

- **Access:** The tent features a large zippered door for easy entry and exit.
- **Ventilation:** Two two-layer windows with mesh screens provide airflow and protection from insects. These can be opened or closed as needed.
- **Elevated Design:** The cot's elevated design keeps you off the cold or damp ground, enhancing comfort and insulation.
- **Versatility:** The tent, cot, air mattress, and sleeping bag can be used together for a complete camping setup or individually depending on your specific needs.



Figure 5: Interior view showing the mesh window for ventilation.

MAINTENANCE

- **Cleaning:** Clean the tent and cot fabric with a damp cloth and mild soap. Avoid harsh chemicals that could damage the material.
- **Drying:** Ensure all components are completely dry before packing away to prevent mold and mildew.
- **Storage:** Store the product in its carry bag in a cool, dry place away from direct sunlight when not in use.
- **Waterproofing:** For prolonged use in wet conditions, consider applying a fabric waterproofing spray to the tent material.

TROUBLESHOOTING

- **Air Mattress Deflation:** If the air mattress deflates overnight, check the inflation valve for a secure seal. Ensure there are no punctures in the mattress.
- **Tent Pole Connector Issues:** The central plastic connector for the tent poles is a critical component. If it breaks or is lost, the tent cannot be properly assembled. Contact customer support for replacement parts.
- **Wind Stability:** In windy conditions, the tent may require additional securing. Consider using guy lines (not included) and stakes to anchor the tent more firmly to the ground.

SPECIFICATIONS

Feature	Detail
Product Dimensions	10 x 10 x 39.5 inches (Packed)
Item Weight	29 pounds
Manufacturer	Outsunny
Model Number	B2-0006
Country of Origin	China
Cot Weight Capacity	Up to 250 lbs
Materials	Polyester, Canvas, Aluminum Alloy



Figure 6: Product dimensions.

SAFETY INFORMATION

- Always set up the tent on level ground.
- Do not use in extreme weather conditions (e.g., severe winds, heavy snow).
- Keep away from open flames and heat sources.
- Ensure adequate ventilation, especially if using any heating devices inside (not recommended).
- Regularly inspect all components for wear and tear before each use.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or any product-related inquiries, please contact Outsunny customer

support directly. Refer to the contact information provided on the product packaging or the official Outsunny website.