

[Manuals.plus](#) /

› [Akribos XXIV](#) /

› Akribos XXIV Grandiose Diamond Watch AK613SS User Manual

Akribos XXIV AK613SS

Akribos XXIV Grandiose Diamond Watch AK613SS User Manual

Model: AK613SS

INTRODUCTION

This manual provides instructions for the proper use and care of your Akribos XXIV Grandiose Diamond Watch, model AK613SS. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

SETUP AND INITIAL ADJUSTMENT

Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. The watch should arrive in a protective box.




Image: The Akribos XXIV watch box, black with gold lettering.

Setting the Time

1. Locate the crown on the right side of the watch case.
2. Pull the crown out to the furthest position (Position 2). The second hand may stop moving.
3. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.

Ensure to account for AM/PM if your watch has an AM/PM indicator.

4. Once the time is set, push the crown back into its normal operating position (Position 0).



Image: Side view of the watch, highlighting the crown used for setting time and date.

Setting the Date, Day, Month, and AM/PM

Your watch features sub-dials for day, date, month, and an AM/PM indicator. These are typically adjusted using the crown in an intermediate position or via small pushers on the watch case.

1. Pull the crown out to the first position (Position 1).
2. Turn the crown in one direction to adjust the date. Turn it in the other direction to adjust the day. (Specifics may vary; refer to the movement's detailed instructions if available).
3. For month and AM/PM sub-dials, small recessed pushers may be present on the watch case. Use a small, non-sharp tool (like a toothpick) to gently press these pushers to advance the respective indicators.
4. After setting, push the crown back to Position 0.

Bracelet Adjustment

The stainless steel bracelet can be adjusted by removing links. This procedure typically requires specialized tools and is best performed by a qualified jeweler or watch technician to avoid damage.



Image: Rear view of the watch, showing the stainless steel bracelet and the deployment clasp in an open position.



Image: A visual guide illustrating various watch case diameters on a wrist for size comparison.

OPERATING YOUR WATCH

Timekeeping

Your Akribos XXIV Grandiose Diamond Watch is a quartz timepiece, known for its accuracy. Once set, it will maintain time reliably.



Image: Front view of the Akribos XXIV Grandiose Diamond Watch, showcasing the dial, sub-dials, and diamond-set bezel.

Using the Sub-Dials

- **Day Sub-Dial:** Indicates the current day of the week.
- **Date Sub-Dial:** Displays the current day of the month.
- **Month Sub-Dial:** Shows the current month.
- **AM/PM Indicator:** Helps distinguish between morning and afternoon hours, especially useful when setting the time to ensure the date changes at midnight, not noon.



Image: The Akribos XXIV Grandiose Diamond Watch displayed on a wrist, showing its size and appearance when worn.

Water Resistance

This watch is water resistant to 165 feet (50 meters). This rating means it is suitable for short periods of recreational swimming and showering. It is **not** suitable for diving, snorkeling, or prolonged water immersion. Always ensure the crown is fully pushed in before any contact with water.

MAINTENANCE AND CARE

Cleaning

To clean your watch, wipe the case and bracelet with a soft, damp cloth. For the stainless steel bracelet, a mild soap solution can be used, followed by rinsing with clean water and thorough drying. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

Your watch is powered by a quartz battery. When the watch stops running, the battery will need to be replaced. It is recommended to have battery replacement performed by a professional watchmaker to ensure proper sealing and maintain water resistance.

Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.

TROUBLESHOOTING

- Watch Not Running:**
Check if the crown is fully pushed in (Position 0). If it is, the battery may need replacement. Consult a professional watchmaker.
- Incorrect Time/Date:**
Refer to the "Setting the Time" and "Setting the Date, Day, Month, and AM/PM" sections to reset the watch. Ensure the crown is fully pushed in after adjustment.
- Condensation Under Crystal:**
This may indicate a loss of water resistance. Avoid further contact with water and have the watch inspected by a professional immediately.

SPECIFICATIONS

Feature	Detail
Model Number	AK613SS
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	47 Millimeters
Case Thickness	12 Millimeters
Band Material	Stainless Steel
Band Width	22 Millimeters
Crystal Material	Mineral
Water Resistance	165 Feet (50 Meters)
Special Features	Day, Date, Month, AM/PM Sub-dials, Diamond Accents

WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. For specific details regarding the warranty period, coverage, and terms, please refer to the warranty card included with your purchase or visit the official

Akribos XXIV website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you require further assistance, have questions not covered in this manual, or need to initiate a warranty claim, please contact Akribos XXIV customer support. Contact information can typically be found on the manufacturer's website or on the warranty card.

For more information, you may visit the official Akribos XXIV website: www.akribos.com