

## Bajaj 1701 MT

# Bajaj 1701 MT 17L Solo Microwave Oven User Manual

Model: 1701 MT

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your new Bajaj 1701 MT 17L Solo Microwave Oven. Please read these instructions carefully before using the appliance and retain them for future reference. This microwave oven is designed for reheating, defrosting, and cooking various food items.

## 2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not operate the oven if the door is damaged, or if the oven is malfunctioning.
- Do not attempt to service or repair the oven yourself. Contact qualified service personnel.
- Ensure proper ventilation around the oven.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Do not use corrosive chemicals or vapors in this appliance.
- Always use microwave-safe cookware.
- Supervise children closely when the oven is in use.

## 3. PRODUCT OVERVIEW

### 3.1 Components

The Bajaj 1701 MT Solo Microwave Oven includes the following main components:

- Microwave Oven Unit
- Glass Turntable Tray
- Roller Ring
- Instruction Manual

- Warranty Card



Figure 1: Front view of the Bajaj 1701 MT Solo Microwave Oven. This image displays the compact white microwave oven with its black door and control dials on the right side.

### 3.2 Control Panel

The control panel features two jog dials for easy operation:

- **Power Level Dial:** Used to select one of the five available power levels.
- **Timer Dial:** Used to set the cooking time, up to a maximum of 30 minutes.



Figure 2: Close-up of the control dials. The image shows the two jog dials for power level selection and timer setting, designed for intuitive use.

## 4. SETUP AND INSTALLATION

---

### 4.1 Unboxing

Upon receiving your microwave oven, carefully unbox it. Ensure all components listed in Section 3.1 are present and undamaged. Remove any protective tape or packaging materials from the interior and exterior of the oven, including the tape securing the turntable mechanism.

Your browser does not support the video tag.

Video 1: Unboxing the Bajaj 1701 MT Microwave Oven. This video demonstrates the unboxing process, showing how to remove the microwave and its accessories from the packaging, including the glass tray and roller ring.

### 4.2 Placement

Place the microwave oven on a flat, stable surface that is strong enough to hold its weight. Ensure there is adequate space for ventilation around the unit (at least 10 cm at the back, 15 cm on top, and 5 cm on the sides). Do not block any ventilation openings.

### 4.3 Electrical Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage and frequency of your power supply match the specifications of the oven.

## 5. OPERATING INSTRUCTIONS

---

The Bajaj 1701 MT features user-friendly jog dials for controlling cooking functions.

### 5.1 Basic Operation

To begin cooking or reheating:

1. Place the food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. **Select Power Level:** Turn the upper jog dial (Power) to your desired power setting. The oven offers 5 power levels.
4. **Set Cooking Time:** Turn the lower jog dial (Time) to set the required cooking duration, up to 30 minutes.
5. The oven will start automatically. A cooking complete alarm will sound when the set time has elapsed.



Figure 3: Overview of key features including 17L capacity, 5 cooking levels, multiple power levels, and a 30-minute timer. This graphic highlights the main functionalities of the microwave.

## 5.2 Reheating

For reheating leftovers or pre-cooked meals, place the food in a microwave-safe dish. Select a medium to high power level and set the timer for 1-3 minutes, checking periodically until desired temperature is reached.

## 5.3 Defrosting

The oven features an auto defrost system. To defrost frozen food:

1. Place the frozen food on the glass turntable.
2. Turn the Power dial to the defrost setting (indicated by a snowflake symbol or lowest power).
3. Set the desired defrosting time using the Timer dial.
4. Turn the food over halfway through the defrosting time for even results.

## 5.4 Cooking

For cooking, refer to specific microwave recipes for recommended power levels and cooking times. Always ensure food is cooked thoroughly before consumption.

## 6. CARE AND MAINTENANCE

### 6.1 Cleaning the Interior

Regularly clean the oven interior to prevent food particles from accumulating. Wipe the inside with a damp cloth and mild detergent after each use. For stubborn stains, place a bowl of water with lemon slices inside and microwave for a few minutes, then wipe clean.

### 6.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals. Ensure the ventilation openings are free from dust and debris.

## 7. TROUBLESHOOTING

If you encounter issues with your microwave oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown.	Check power plug; Close door firmly; Check household fuse/circuit breaker.
Food not heating	Incorrect power level or cooking time set; Microwave-safe cookware not used.	Adjust power/time settings; Use appropriate cookware.
Unusual noise during operation	Turntable not correctly placed; Food container touching oven walls.	Ensure turntable and roller ring are correctly seated; Adjust food placement.

## 8. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Bajaj
Model	1701 MT
Capacity	17 Litres
Oven Cooking Mode	Microwave
Wattage (Output)	700 Watts
Power Consumption	1200 Watts
Control Type	Jog Dials
Special Features	Auto Cook, Auto Defrost
Colour	White
Item Weight	2 kg 490 g
Item Dimensions (LxWxH)	110.2 x 158.3 x 83.5 Centimeters

## 9. WARRANTY AND CUSTOMER SUPPORT

---

Your Bajaj 1701 MT 17L Solo Microwave Oven comes with a **1-year warranty on the product and 1 year on the magnetron** from the date of purchase. Please retain your purchase receipt and warranty card for any claims.

For customer support, service requests, or to report any issues, please contact Bajaj Electricals Ltd. at the following details:

- **Contact:** Bajaj Electricals Limited
- **Address:** 45/47, Veer Nariman Road, Mumbai, 400001
- **Telephone:** 022 - 41280000
- **Email:** [consumercare@bajajelectricals.com](mailto:consumercare@bajajelectricals.com)

In case you receive a damaged or defective product, a 10-day return/replacement policy may be applicable. Refer to your purchase terms for details.