Bajaj 1000T

Bajaj 1000T Oven Toaster Grill (10 Liter) Instruction Manual

Important Safety Instructions

- Read all instructions carefully before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The Bajaj 1000T Oven Toaster Grill (OTG) is a versatile 10-liter kitchen appliance designed for baking, toasting, and grilling. It features a durable stainless steel body and a transparent glass door, allowing for easy monitoring of your cooking. With an 800W heating element and a temperature range of 0-250 degrees Celsius, it provides efficient and precise cooking for various dishes.



Image: Front view of the Bajaj 1000T Oven Toaster Grill, showcasing its compact design and transparent glass door.

What's in the Box

Your Bajaj 1000T OTG comes with the following accessories to enhance your cooking experience:

- Cooking Tray (Crumb Tray)
- Tong
- Pizza Tray
- Wire Grill Rack



Image: The Bajaj 1000T OTG with its various accessories, including the cooking tray, pizza tray, and wire grill, along with key features like 10L capacity and 60-minute timer.

Initial Setup

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the OTG on a stable, heat-resistant, and level surface. Ensure there is adequate ventilation around the appliance (at least 10-15 cm clearance on all sides). Do not place it near flammable materials or under cabinets.
3. **Initial Cleaning:** Before first use, wipe the interior and exterior of the oven with a damp cloth. Wash all accessories (cooking tray, pizza tray, wire grill, tong) with warm, soapy water, rinse thoroughly, and dry.
4. **First Use Burn-off:** It is recommended to run the oven empty for about 10-15 minutes at maximum temperature (250°C) with the timer set. This helps to burn off any manufacturing residues and odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.

Controls and Features

The Bajaj 1000T OTG is equipped with user-friendly controls for precise cooking:

- **Temperature Control Knob:** Located on the front panel, this knob allows you to select the desired cooking temperature from 0°C to 250°C.
- **Timer Knob:** Also on the front panel, this knob sets the cooking duration up to 60 minutes. It includes a 'Stay On' function for continuous operation.
- **Power Indicator Light:** A red light illuminates when the appliance is powered on and operating.
- **Heating Elements:** The OTG features two heating elements, one at the top and one at the bottom, ensuring even heat distribution for baking, grilling, and toasting.



Image: A close-up view of the control panel on the Bajaj 1000T OTG, showing the temperature and timer knobs, and the power indicator light.

Operating Instructions

Follow these steps for optimal use of your Bajaj 1000T OTG:

1. **Preheating:** Always preheat the OTG to the required temperature before placing food inside. Turn the temperature knob to the desired setting and the timer knob to approximately 10-15 minutes. The power indicator light will turn on.
2. **Baking:** For baking items like cakes or cupcakes, place the food on the cooking tray (crumb tray). Once the OTG is preheated, carefully slide the tray into the tray slot. Close the door, set the temperature and timer according to your recipe.
3. **Grilling:** For grilling items like chicken or vegetables, place the marinated food on the wire grill rack. You may place the crumb tray below to catch any drippings. Once preheated, carefully slide the wire grill into the appropriate slot. Close the door, set the temperature and timer as required.
4. **Toasting:** For toasting bread or small items, place them directly on the wire grill rack. For items like pizza, use the pizza tray. Once preheated, carefully place the food inside. Close the door, set the temperature and timer as needed.
5. **Monitoring:** Use the transparent glass door to monitor the cooking process without opening the oven, which can cause heat loss.
6. **Removal:** Once cooking is complete and the timer rings, carefully remove the hot food using the provided tong or oven mitts.

Demonstration Video

Your browser does not support the video tag.

Video: An official demonstration of the Bajaj Majesty OTG 1000 TSS, showing its features and how to use it for baking cupcakes, grilling chicken, and toasting pizza.

Cleaning and Maintenance

Regular cleaning ensures the longevity and optimal performance of your OTG:

- **Before Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
- **Interior:** Clean the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive oven cleaner can be used, but ensure it is safe for OTG interiors and rinse thoroughly.
- **Accessories:** Wash the cooking tray, pizza tray, wire grill, and tong with warm, soapy water. Rinse and dry thoroughly before storing.
- **Heating Elements:** Do not attempt to clean the heating elements directly. Any food residue on them will burn off during operation.
- **Glass Door:** Clean the glass door with a glass cleaner or a damp cloth.

Troubleshooting

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; timer not set.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Turn the timer knob to the desired cooking time.

Problem	Possible Cause	Solution
Food not cooking evenly.	Incorrect temperature or time setting; food placed too close to heating elements; uneven food distribution.	Adjust temperature and time according to recipe. Ensure food is centered and not touching heating elements. Rotate food halfway through cooking if necessary.
Excessive smoke during operation.	Food residue or grease buildup; highly fatty food.	Clean the interior and accessories thoroughly. Use a drip tray for fatty foods. Ensure proper ventilation.
Timer not working.	Timer knob faulty.	Contact customer support for assistance.

If the problem persists after attempting these solutions, please contact customer support.

Technical Specifications

Feature	Specification
Brand	Bajaj
Model Number	420059
Capacity	10 Liters
Power Consumption	800 Watts
Voltage	230 Volts
Temperature Range	0-250 Degrees Celsius
Timer	60 Minutes with 'Stay On' function
Control Type	Knob
Body Material	Stainless Steel
Door Material	Tempered Glass
Product Dimensions (D x W x H)	28D x 38.3W x 20.3H Centimeters
Item Weight	3.63 kg



Image: Diagram illustrating the dimensions of the Bajaj 1000T Oven Toaster Grill (28 cm D x 38.3 cm W x 20.3 cm H).

Warranty and Customer Support

Your Bajaj 1000T Oven Toaster Grill comes with a**2-year warranty** from the date of purchase, covering manufacturing defects under normal household use.

For warranty claims, technical assistance, or any product-related inquiries, please contact Bajaj customer support. Keep your purchase receipt and warranty card handy when contacting support.

Manufacturer: Bajaj Electricals Ltd.

Address: 45/47, Veer Nariman Road, Mumbai, 400001

For the most current contact information, please refer to the official Bajaj website or the documentation included with your product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question