MEDIACOM ME-HDTV

Mediacom ME-HDTV Multimedia Player and Audio Recorder User Manual

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Mediacom ME-HDTV Multimedia Player and Audio Recorder. Please read this manual thoroughly before using the device to ensure optimal performance and longevity. Keep this manual for future reference.

Image of the Mediacom ME-HDTV multimedia player and its remote control. The player is a black rectangular device with silver trim, featuring control buttons on the front left side. The remote control is silver-grey with numerous buttons.

1. SETUP

1.1 Unpacking

Carefully remove all components from the packaging. Verify that all items listed in the product contents are present and undamaged. Retain the packaging for potential future transport or service.

1.2 Hard Drive Installation (Optional)

The Mediacom ME-HDTV supports a 3.5-inch internal hard drive (SATA or ATA parallel). To install a hard drive:

1. Ensure the device is powered off and disconnected from the power outlet.
2. Locate the hard drive bay on the device (refer to the diagram in the full manual if available).

3. Carefully slide the 3.5-inch hard drive into the bay, ensuring it connects securely to the internal connectors.
4. Secure the hard drive with the provided screws, if applicable.
5. Close the hard drive bay cover.

1.3 Connecting to a Display

Connect the ME-HDTV to your television or display using an appropriate cable. Common connection types include HDMI for high-definition video and audio, or composite video/audio cables for standard definition.

- **HDMI Connection:** Connect one end of an HDMI cable to the HDMI output port on the ME-HDTV and the other end to an HDMI input port on your television.
- **Analog A/V Connection:** Connect the yellow, white, and red RCA cables from the ME-HDTV's A/V output to the corresponding input ports on your television.

1.4 Power Connection

Connect the power adapter to the DC input port on the ME-HDTV, then plug the adapter into a standard AC power outlet (220-240V).

1.5 Connecting USB Devices

You can connect external USB storage devices (e.g., USB flash drives, external hard drives) to the USB 2.0 port on the ME-HDTV to access additional media files.

2. OPERATING INSTRUCTIONS

2.1 Powering On/Off

Press the power button on the front panel of the device or on the remote control to turn the ME-HDTV on or off. The 3.5" LCD screen will illuminate upon startup.

2.2 Navigating the Interface

Use the remote control to navigate through the on-screen menus. The directional buttons (up, down, left, right) are used to select options, and the 'OK' or 'Enter' button confirms selections. The 'Back' or 'Return' button typically navigates to the previous menu.

2.3 Media Playback

The ME-HDTV supports a wide range of media formats. Navigate to the desired media type (Video, Music, Photo) from the main menu. Select the storage location (internal HDD, USB device, or network share if configured) and browse for your files.

- **Supported Video Formats:** DIVX, MPEG1, MPEG2, MPEG4, VOB, XVID.
- **Supported Audio Formats:** AIFF, ALAC, FLAC, WAV, MP3, DSD.
- **Supported Image Formats:** JPG.

2.4 Audio Recording

The ME-HDTV functions as an audio recorder. Connect an audio source to the appropriate input ports (if available, refer to device ports) and select the recording function from the main menu. Follow the on-screen prompts to configure recording settings and start recording.

3. MAINTENANCE

3.1 Cleaning

To clean the device, disconnect it from the power source. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials, as these can damage the finish or internal components.

3.2 Firmware Updates

Periodically check the manufacturer's website for available firmware updates. Firmware updates can improve performance, add new features, or resolve known issues. Follow the instructions provided with the update package carefully.

3.3 Hard Drive Management

If an internal hard drive is installed, regularly back up important data to prevent loss. The device may offer options for formatting the hard drive; exercise caution when using such features as they will erase all data.

4. TROUBLESHOOTING

If you encounter issues with your Mediacom ME-HDTV, refer to the following common problems and solutions:

- **No Power:**
  Ensure the power adapter is securely connected to both the device and a working power outlet. Verify the power outlet is active.

- **No Picture/Sound on TV:**
  Check all video and audio cable connections between the ME-HDTV and your television. Ensure your television is set to the correct input source (e.g., HDMI 1, AV).

- **Remote Control Not Responding:**
  Check the batteries in the remote control and replace them if necessary. Ensure there are no obstructions between the remote and the device's IR receiver.

- **Media Files Not Playing:**
  Verify that the media files are in a supported format (refer to Section 2.3). Ensure the storage device (internal HDD, USB) is properly connected and recognized by the ME-HDTV.

- **Device Freezes or Crashes:**
  Try restarting the device by disconnecting and reconnecting the power. If the issue persists, consider performing a factory reset (consult the full manual for instructions, as this will erase settings).

5. SPECIFICATIONS

| Feature	Specification
Model Number	ME-HDTV
Brand	MEDIACOM
Supported Hard Drive	3.5 inch SATA / ATA Parallel (up to 1000 GB)
USB Ports	1 x USB 2.0
Video Output	HDMI, Composite A/V
Audio Output	Stereo RCA, Digital Audio (Coaxial/Optical - assumed based on typical media players)

Feature	Specification
Supported Video Formats	DIVX, MPEG1, MPEG2, MPEG4, VOB, XVID
Supported Audio Formats	AIFF, ALAC, FLAC, WAV, MP3, DSD
Supported Image Formats	JPG
D/A Audio Converter	24 bits/192 kHz
Display	3.5 inch LCD
Power Input	AC 220-240V
Power Consumption	19 W (Operating), 0.19 W (Standby)
Dimensions (L x W x H)	21 x 12.5 x 3.8 cm
Weight	1.3 kg

6. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Mediacom website. Keep your proof of purchase for warranty claims.

Related Documents - ME-HDTV

[PHD-VRX HDTV Recorder & Media Center: Owner's Manual for Full HD 1080p Dual Tuner](#)
Owner's manual for the PHD-VRX Full HD 1080p Dual Tuner Digital HDTV Recorder, Receiver, and Media Center Box. Learn about setup, features, and operation.

[ZvPro 250 HD MPEG2 Encoder / QAM Modulator Get Going Guide](#)
A guide to installing and operating the ZeeVee ZvPro 250, a 1U combination HD MPEG2 Encoder and frequency agile QAM Modulator for converting HD video sources into HDTV cable channels. Includes safety instructions, panel descriptions, installation steps, and warranty information.

[Mediacom Xtream Welcome Guide: Internet, TV, Phone & Smart Home Services](#)
A comprehensive welcome guide from Mediacom covering Xtream services including internet, WiFi360pro, Xumo streaming, Mediacom Mobile, Xtream Hotspots, TV features, Xtream TV App, On Demand, Home Phone services, Digital Home smart systems, Xpert tech support, and customer care.

	[AEVYVKV 3x1 HD Switcher User Manual - 4K Resolution Support](#) User manual for the AEVYVKV 3x1 HD Switcher, detailing its specifications, features, connection, and operation for high-definition video and audio switching up to 4K resolution.
	[BRobotix 043169 ATSC Digital TV Decoder User Manual - Setup and Operation](#) Comprehensive user manual for the BRobotix 043169 ATSC Digital TV Decoder. Learn how to install, configure, and operate your digital TV receiver for optimal performance.
	[Toshiba LCD TV Owner's Manual: Integrated High Definition 19SL410U, 24SL410U, 32SL410U](#) Comprehensive owner's manual for Toshiba Integrated High Definition LCD Televisions (models 19SL410U, 24SL410U, 32SL410U). Covers setup, safety precautions, features, connections, troubleshooting, and maintenance for optimal viewing experience.

Documents - MEDIACOM – ME-HDTV

no relevant documents