Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CorningWare P-1-3/4-B

CorningWare P-1-3/4-B 'Cornflower' Casserole Baking Dish User Manual

Model: P-1-3/4-B | Capacity: 1.75 Quart

Introduction

This manual provides essential information for the safe and effective use and care of your Vintage CorningWare P-1-3/4-B 'Cornflower' Casserole Baking Dish. Designed for versatility, this 1.75-quart dish with its distinctive blue cornflower pattern is suitable for baking, serving, and storing food.

Setup and First Use

Before using your CorningWare casserole dish for the first time, it is important to prepare it properly.

1. **Unpack:** Carefully remove the casserole dish and its lid from all packaging materials.
2. **Inspect:** Examine the dish and lid for any signs of damage or imperfections.
3. **Clean:** Wash the casserole dish and lid thoroughly with warm, soapy water. Rinse completely and dry with a soft cloth.



Image: The CorningWare P-1-3/4-B 'Cornflower' casserole dish with its clear glass lid. This 1.75-quart dish features the iconic blue cornflower pattern on its white ceramic surface, designed for both functionality and aesthetic appeal in the kitchen.

Operating Instructions

The CorningWare casserole dish is designed for versatile use in your kitchen.

- **Oven Use:** This casserole dish is oven safe. It can be used for baking various dishes, from casseroles to roasts. Ensure the dish is placed on a stable, level surface within the oven.
- **Microwave Use:** The ceramic dish is microwave safe. The glass lid may also be used in the microwave, but always check for manufacturer recommendations if available.
- **Serving:** The attractive 'Cornflower' design makes this dish suitable for direct serving from oven to table. Use appropriate heat protection for surfaces.
- **Storage:** The dish with its lid can be used for storing leftovers in the refrigerator or freezer. Allow hot food to cool before refrigerating.
- **Capacity:** The dish has a capacity of 1.75 quarts, ideal for small to medium-sized meals.

Important Safety Note: Avoid extreme temperature changes. Do not place a hot dish directly into cold water or on a cold surface, and vice-versa, as this can cause thermal shock and breakage. Do not use on stovetop burners unless specifically designed for it (this model is primarily for oven/microwave use).

Maintenance and Care

Proper care will ensure the longevity of your CorningWare casserole dish.

- **Cleaning:** The dish is technically dishwasher safe, but *hand washing is recommended* for best preservation of the

finish and pattern, especially for vintage items. Use a soft sponge or cloth and mild dish soap. Avoid abrasive cleaners or scouring pads that could scratch the surface or pattern.

- **Stains:** For stubborn food stains, soak the dish in warm, soapy water before cleaning. A paste of baking soda and water can also be used for gentle scrubbing.
- **Lid Care:** The glass lid should be washed similarly. Ensure no food particles are trapped in the rim.
- **Storage:** Store the dish and lid carefully to prevent chipping or breakage. Avoid stacking heavy items directly on the glass lid.

Troubleshooting

Lid Does Not Fit Properly

If the lid appears to not sit level or fit correctly on the casserole dish, consider the following:

- **Surface Level:** Ensure the surface on which the casserole dish is placed is completely level. An uneven surface can cause the dish to tilt slightly, affecting the lid's fit.
- **Dish Condition:** Inspect the rim of the casserole dish and the edge of the lid for any chips, cracks, or warping that might prevent a proper seal.
- **Lid Compatibility:** Verify that the lid being used is the original or a compatible replacement specifically designed for the P-1-3/4-B model.

Specifications

Feature	Detail
Model Number	P-1 3/4-B
Brand	CorningWare
Material	Ceramic (Dish), Glass (Lid)
Color	Blue (Cornflower pattern)
Capacity	1.75 Quarts
Product Dimensions	8.1"D x 9.6"W x 8.5"H
Item Weight	3.3 Pounds
Oven Safe	Yes
Dishwasher Safe	Yes
Product Care Instructions	Hand Wash Only

Warranty and Support

As this is a vintage item, original manufacturer warranties may no longer be applicable. For any issues or concerns regarding the condition of the product upon receipt, please contact the seller directly through your purchase platform. Preserve your item by following the care instructions provided in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00F62ET22

More documents and user manuals: **https://manuals.plus/**