



[Manuals.plus](#) /

› [Bowers & Wilkins](#) /

› Bowers & Wilkins P7 Wired Headphones User Manual

Bowers & Wilkins P7

Bowers & Wilkins P7 Wired Headphones User Manual

Model: P7 | Brand: Bowers & Wilkins

1. INTRODUCTION AND OVERVIEW

The Bowers & Wilkins P7 headphones are engineered to deliver an immersive audio experience, allowing you to fully appreciate your music. They feature a unique driver unit designed to mimic hi-fi speakers, ensuring precise and controlled sound reproduction across the entire frequency range. The over-ear design, combined with snugly-fitting ear pads, provides excellent sound isolation and comfort for extended listening sessions.

Key features include a diaphragm focused on generating sound with precise, controlled movement, and a dual cavity cushion design in the ear pads that conforms to the head's contours. This design maintains a consistent air volume between the drive unit and the ear, enhancing stereo imaging and optimizing sound for every listener.



Figure 1: Bowers & Wilkins P7 Wired Headphones

2. WHAT'S IN THE BOX

Upon unboxing your Bowers & Wilkins P7 headphones, please ensure all components are present:

- Bowers & Wilkins P7 Wired Headphones
- Protective Case
- Audio Cable (detachable)

3. SETUP

Setting up your P7 headphones is straightforward:

1. **Connect the Audio Cable:** Locate the audio input port on one of the earcups (typically the left earcup). Insert the smaller end of the provided audio cable firmly into this port.
2. **Connect to Audio Source:** Insert the other end of the audio cable (3.5 mm jack) into the headphone output of your desired audio source, such as a smartphone, tablet, or audio player.
3. **Adjust for Comfort:** Gently extend or retract the headband to ensure the earcups sit comfortably over your ears, fully enclosing them. The ear pads are designed to mold to your head's contours for optimal sound and comfort.

4. OPERATING INSTRUCTIONS

Once connected, your P7 headphones are ready for use. The sound is optimized for every listener, providing a rich and detailed audio experience.

- **Volume Control:** Adjust the volume directly from your connected audio source. The P7 headphones do not feature integrated volume controls.
- **Playback Control:** If your audio cable includes an in-line remote (not specified in product data, but common for wired headphones), you can use it to control playback (play/pause, skip tracks) and answer/end calls. Refer to your audio source's manual for specific compatibility.
- **Optimal Listening:** Ensure the ear pads fully cover your ears to benefit from the sound isolation and the dual cavity cushion design, which maintains consistent air volume for enhanced stereo imaging.

Product Overview Video

Video: Official product video showcasing the design and features of the Bowers & Wilkins P7 headphones.

5. MAINTENANCE

Proper care will ensure the longevity and performance of your P7 headphones:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the headphones. For the ear pads, a slightly damp cloth can be used, but avoid excessive moisture. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store your P7 headphones in the provided protective case to prevent dust accumulation and physical damage.
- **Cable Care:** Handle the detachable audio cable with care. Avoid sharp bends or excessive pulling, which can damage the internal wiring.

6. TROUBLESHOOTING

If you encounter issues with your P7 headphones, try the following steps:

Problem	Possible Cause	Solution
No sound	Cable not fully connected; Audio source volume too low; Incorrect audio output selected on device.	Ensure audio cable is securely plugged into both headphones and audio source. Increase volume on audio source. Verify correct audio output is selected on your device.
Poor sound quality (distortion, low bass)	Loose cable connection; Damaged cable; Ear pads not properly sealed around ears; Low-quality audio file.	Check and re-seat cable connections. Try a different audio cable if available. Adjust headphones for a proper seal. Try a different audio file or source.
Headphones uncomfortable	Headband not adjusted correctly.	Adjust the headband length to fit your head comfortably. Ensure ear pads are positioned correctly over your ears.

If the issue persists after trying these steps, please refer to the support section.

7. SPECIFICATIONS

Feature	Detail
Brand	Bowers & Wilkins
Model Name	P7
Connectivity Technology	Wired
Ear Placement	Over Ear
Form Factor	Over Ear
Color	Black
Material	foam
Headphones Jack	3.5 mm Jack
Sensitivity	111 dB
Impedance	22 Ohm
Frequency Range	20 Hz - 20,000 Hz
Noise Control	Sound Isolation
Item Weight	10.2 ounces (0.29 Kilograms)
Product Dimensions	9.2 x 7.6 x 5.2 inches
Cable Feature	Detachable
Included Components	Protective Case

8. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Bowers & Wilkins website or the full user manual PDF.

You can also access the comprehensive user manual in PDF format here: [Bowers & Wilkins P7 User Manual \(PDF\)](#)

For further assistance, please contact Bowers & Wilkins customer service through their official channels.