

[Manuals.plus](#) /

› [Ranch Hand](#) /

› RANCH HAND Running Step Instruction Manual

Ranch Hand RSD101M6B4W

Ranch Hand Running Step Instruction Manual

Model: RSD101M6B4W

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Ranch Hand Running Step. Please read this manual thoroughly before beginning any procedures to ensure safe and correct usage. The Ranch Hand Running Step is designed for trucks and sport utility vehicles, offering a durable and functional step solution.



Image: A dark-colored pickup truck equipped with a Ranch Hand Running Step, parked on a gravel road with trees and grass in the background. The running step is visible along the side of the truck, providing a sturdy access point.

SETUP AND INSTALLATION

Proper installation is crucial for the safety and performance of your running step. It is recommended that installation be performed by a qualified professional. Ensure all components are present before beginning.

Package Contents:

- Ranch Hand Running Step (Alloy Steel, Black Powder Coat)
- Mounting Hardware (not explicitly listed but implied for installation)
- Auto Parts, Automotive Accessories, Replacement, Performance Parts

Pre-Installation Checklist:

1. Verify all parts are included and undamaged.
2. Ensure the vehicle is parked on a level surface and the parking brake is engaged.
3. Gather necessary tools (e.g., wrenches, sockets, measuring tape).
4. Review vehicle-specific instructions if provided by the vehicle manufacturer for accessory installation points.

Installation Steps (General):

While specific steps may vary by vehicle model, the general process involves:

1. Identify mounting points on the vehicle's frame or rocker panel.
2. Attach mounting brackets securely to the vehicle.
3. Position the running step onto the brackets.
4. Secure the running step to the brackets using the provided hardware.
5. Tighten all fasteners to the manufacturer's specified torque settings.
6. Perform a final check to ensure the running step is stable and properly aligned.

OPERATING INSTRUCTIONS

The Ranch Hand Running Step provides a stable platform for easier entry and exit from your truck or SUV. It is designed to support a weight limit of 54.82 pounds for stepping purposes.

Usage Guidelines:

- Always step onto the running board with caution, ensuring stable footing.
- Avoid placing excessive weight on the step beyond its specified limit.
- Do not use the running step as a jacking point or for vehicle recovery.
- Keep the step surface clean and free of debris, ice, or mud to prevent slips.

MAINTENANCE

Regular maintenance will ensure the longevity and continued performance of your Ranch Hand Running Step.

Cleaning:

- Clean the running step regularly with mild soap and water.
- Rinse thoroughly to remove all soap residue.

- Avoid abrasive cleaners or harsh chemicals that could damage the black powder coat finish.

Inspection:

- Periodically inspect all mounting hardware for tightness. Re-tighten if necessary.
- Check the running step for any signs of damage, corrosion, or wear.
- Address any issues promptly to prevent further damage or safety hazards.

TROUBLESHOOTING

This section addresses common issues you might encounter with your running step.

Issue: Running Step Feels Loose or Wobbly

- **Possible Cause:** Loose mounting hardware.
- **Solution:** Inspect all bolts and nuts securing the running step to the vehicle and the brackets. Tighten them to the recommended torque specifications. If the issue persists, check for damaged brackets or mounting points.

Issue: Noise (Squeaking/Rattling) from Running Step

- **Possible Cause:** Loose fasteners, contact with other vehicle components, or debris.
- **Solution:** Check all mounting hardware for tightness. Ensure no part of the running step is rubbing against the vehicle's body or frame. Clean any debris from around the mounting areas.

Issue: Damage to Powder Coat Finish

- **Possible Cause:** Abrasive cleaning, impact, or prolonged exposure to harsh elements.
- **Solution:** For minor scratches, touch-up paint designed for powder coat finishes can be used. For significant damage, professional re-coating may be necessary to prevent rust.

SPECIFICATIONS

Attribute	Detail
Model Number	RSD101M6B4W
Brand	Ranch Hand
Color	Black
Material	Alloy Steel
Product Dimensions (L x W x H)	132 x 14 x 11 inches
Item Weight	102 Pounds
Weight Limit (for stepping)	54.82 Pounds
Vehicle Service Type	Truck, Sport Utility Vehicle
UPC	848917004250
Manufacturer	RANCH HAND

Attribute	Detail
Country of Origin	United States

WARRANTY INFORMATION

Specific warranty details for the Ranch Hand Running Step are typically provided at the point of purchase or on the manufacturer's official website. Please retain your proof of purchase for any warranty claims. For detailed warranty terms and conditions, please refer to the official Ranch Hand documentation or contact their customer service.

CUSTOMER SUPPORT

For technical assistance, installation queries, or parts inquiries, please contact Ranch Hand customer support. Contact information can usually be found on the manufacturer's website or on the product packaging.
Note: As per the provided product data, direct contact information is not available in this manual. Please refer to the manufacturer's official resources.

© 2023 Ranch Hand. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

