

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Oase](#) /

› **EDEN 901 Automatic Food Dispenser User Manual**

Oase 901 (Model 57434)

EDEN 901 Automatic Food Dispenser

Model: 901 (57434) | Brand: Oase

INTRODUCTION

The EDEN 901 Automatic Food Dispenser is designed to provide reliable and consistent feeding for your aquarium fish, especially when you are away. Its innovative mechanism protects food from moisture, ensuring freshness. The device allows for flexible programming of feeding times and dosages to meet the specific needs of your aquatic inhabitants.



Figure 1: Front view of the EDEN 901 Automatic Food Dispenser, showing the display and control buttons.

PRODUCT FEATURES

- **Automatic Feeding:** Ensures consistent daily feeding for a large number of fish, even in the owner's absence.
- **Innovative Moisture Protection:** A sophisticated mechanism keeps food hermetically sealed and protected from humidity within the reservoir. The reservoir ejects to disperse food.
- **Programmable:** Features an LCD screen and intuitive buttons for easy programming. Up to 4 meals per day can be scheduled, with each meal allowing up to 3 dosages.
- **Adjustable Dosage:** Food quantity is individually programmable to suit specific requirements.
- **Battery Operated:** Operates safely with batteries (not included).

SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the main unit in water.
- Ensure hands are dry when handling the device, especially during battery installation.
- Use only the specified battery type (AA batteries, not included).

- Keep the device out of reach of children and pets.
- If using an optional power adapter, ensure it is compatible with the device's specifications.

PACKAGE CONTENTS

The EDEN 901 Automatic Food Dispenser package typically includes:

- Main automatic feeder unit

Please note that batteries, a transformer, and a mounting support are available as separate accessories and are not included with the main unit.

SETUP

1. **Install Batteries:** Open the battery compartment (usually located on the underside or back) and insert the required AA batteries, observing correct polarity. Close the compartment securely.
2. **Fill Food Container:** Open the food reservoir. Fill it with your desired dry fish food (flakes or pellets). Ensure the food is dry and not clumped. Close the reservoir securely to maintain moisture protection.
3. **Mounting:** The feeder can be placed directly on the aquarium lid. For aquariums without a lid, an optional adjustable support (10 to 50 mm) can be purchased separately to attach the feeder to the aquarium rim. Ensure the feeder is stable and positioned so that food dispenses directly into the water.
4. **Initial Power-On:** Once batteries are installed, the LCD display should activate.



Figure 2: Side view of the EDEN 901 Automatic Food Dispenser, illustrating its compact design and potential mounting points.

OPERATING INSTRUCTIONS

The EDEN 901 features an intuitive control panel for programming feeding schedules.



Figure 3: Detailed view of the control panel, showing the LCD display, plus/minus buttons, and the 'SET' button.

- 1. Set Current Time:** Press and hold the 'SET' button for 3 seconds until the time display flashes. Use the '+' and '-' buttons to adjust the hour, then press 'SET' to confirm and move to minutes. Adjust minutes and press 'SET' again to confirm.
- 2. Program Feeding Times:**
 - Briefly press the 'SET' button to enter feeding program mode. The first feeding time (F1) will flash.
 - Use '+' and '-' to set the desired hour for F1, then press 'SET'.
 - Adjust minutes for F1 and press 'SET'.
 - The display will then show the number of dosages (revolutions of the feeder). Use '+' and '-' to select 1, 2, or 3 dosages for this feeding. Press 'SET' to confirm.
 - Repeat this process for F2, F3, and F4 if additional feeding times are desired. To skip a feeding time, set its hour to '---:--' using the '-' button.
- 3. Manual Feeding:** To dispense food immediately, briefly press the '+' button. The feeder will perform one dosage.
- 4. Adjusting Food Quantity:** The amount of food dispensed per dosage can be adjusted by a slider or mechanism on the food drum itself (refer to Figure 4). This allows fine-tuning the portion size.



Figure 4: Detail of the food drum, showing the moisture protection mechanism and a slider for adjusting the dispensed food quantity.

MAINTENANCE

- Cleaning the Unit:** The exterior of the feeder can be easily cleaned with a damp cloth. Do not use abrasive

cleaners or immerse the unit in water.

- **Cleaning the Food Reservoir:** Periodically remove the food reservoir and clean it to prevent food residue buildup. Ensure it is completely dry before refilling with food and reattaching to the main unit.
- **Battery Replacement:** When the battery indicator on the LCD display shows low power, replace all batteries with new ones. Ensure the device is turned off or unplugged (if using an adapter) before replacing batteries.
- **Food Type:** Use only dry flake or pellet food. Avoid sticky or moist foods that can clog the dispensing mechanism.

TROUBLESHOOTING

- **Feeder not dispensing food:**

- Check if batteries are installed correctly and have sufficient power. Replace if necessary.
- Ensure the food reservoir is not empty.
- Verify that the dispensing mechanism is not clogged by clumped food. Clean the reservoir and mechanism if needed.
- Check programmed feeding times.

- **LCD display not working or dim:**

- Replace batteries.
- Ensure battery contacts are clean.

- **Food getting wet or clumping:**

- Ensure the food reservoir lid is securely closed.
- Check the environment for excessive humidity.
- Use only dry food types.

SPECIFICATIONS

Attribute	Value
Brand	Oase
Model Number	57434
Product Dimensions (L x W x H)	9.5 x 14 x 10 cm
Weight	280 grams
Color	Grey
Material	Plastic, aluminum or stainless steel
Power Source	Battery Powered
Requires Batteries	Yes


Batteries Included	No
Special Features	Automatic, Adjustable
Recommended Uses	Aquarium
Target Species	Fish
Care Instructions	Easy to clean with a damp cloth

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Oase customer service directly. Keep your proof of purchase for warranty claims.

Related Documents - 901 (Model 57434)

	<p>AIRJUGAR Smart Pet Feeder with Two-way Splitter: User Manual and Setup Guide</p> <p>Detailed user manual for the AIRJUGAR Smart Pet Feeder with Two-way Splitter. Learn about product assembly, specifications, daily feeding schedules, app connectivity via WiFi, troubleshooting, and cleaning instructions.</p>
	<p>Pit Pet Automatic Pet Feeder User Manual</p> <p>Comprehensive user manual for the Pit Pet Automatic Pet Feeder, detailing setup, operation, features, and maintenance for optimal pet feeding.</p>
	<p>Automatic Pet Feeder - User Guide</p> <p>Learn how to set up and use your automatic pet feeder for convenient pet meal times. This guide covers operation and features.</p>
	<p>Mellerware Petto! Eat Small Automatic Pet Feeder Manual</p> <p>User manual for the Mellerware Petto! Eat Small automatic pet feeder, providing instructions for setup, use, cleaning, and troubleshooting. Includes safety warnings and product specifications.</p>



[DÖRR Automatic Feeder Compact \(Model 204371\) - Instruction Manual](#)

Instruction manual for the DÖRR Automatic Feeder Compact (Model 204371), detailing setup, operation, safety guidelines, technical specifications, and disposal information.



[Tetra Bubbling LED Kit 1 Gallon Hexagon: Quick Setup Guide](#)

Follow this comprehensive quick setup guide from Tetra for the Bubbling LED Kit 1 Gallon Hexagon aquarium. Learn part identification, filter and airstone setup, air pump installation, and aquarium preparation for a healthy aquatic environment.