

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Weber](#) /

› [Weber Q2200 Liquid Propane Grill, Gray Weber Q 2200 Gas Grill, Titanium User Manual](#)

Weber 54060001

Weber Q 2200 Gas Grill User Manual

Model: 54060001

1. INTRODUCTION

The Weber Q 2200 Gas Grill is a versatile and compact liquid propane grill designed for both home use and portability. This manual provides essential information for the safe and efficient operation, maintenance, and care of your grill.



Figure 1: The Weber Q 2200 Gas Grill, showcasing its compact design and sturdy build.

Restyled for enhanced functionality and aesthetics, the Weber Q 2200 features a larger grip handle, ergonomic side handles, sturdy front and rear cradles, and larger fold-out side tables. Its design accommodates a variety of cooking needs, from small roasts to everyday meals.

2. SAFETY INFORMATION

Important Safety Warning:

- Handling the brass material on this product exposes you to lead, a chemical known to the State of California to cause cancer, birth defects or other reproductive harm. **(Wash hands after handling this product.)**
- Combustion byproducts produced when using this product contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Always read and understand all safety warnings and instructions before operating the grill. Keep this manual for future reference.

3. PRODUCT FEATURES

The Weber Q 2200 Gas Grill is equipped with several features designed for convenience and optimal grilling performance:

- **Total Cooking Area:** 280 square inches, providing ample space for various foods.
- **Stainless Steel Burner:** Ensures durability and long-lasting performance with a 12,000 BTU-per-hour input.
- **Porcelain-Enameled, Cast-Iron Cooking Grates:** Designed for even heat distribution and excellent searing. These split grates allow for a grate/griddle cooking combination (griddle sold separately).
- **Electronic Ignition:** For effortless and reliable startup.
- **Lid Thermometer:** Built into the tall lid, allowing you to monitor internal grill temperatures without lifting the lid.
- **Fold-Down Side Tables:** Two sturdy work tables provide extra space for preparation and serving, and fold down for compact storage.
- **Removable Catch Pan:** Located beneath the grill for easy cleanup of grease and drippings.
- **Cast-Aluminum Lid and Body:** Lightweight yet rugged construction.
- **Fuel Type:** Operates on disposable 14.1 or 16.4 oz. LP cylinders (sold separately). An optional LP adapter hose for 20-lb. tanks is available.

4. SETUP

Your Weber Q 2200 Gas Grill requires minimal assembly. Follow these general steps for initial setup:

1. **Unpack Components:** Carefully remove all parts from the packaging and ensure all components are present.
2. **Assemble Grill:** Attach the handle and thermometer to the lid. Place the cooking grates inside the grill body.
3. **Install LP Cylinder:** Connect a 14.1 or 16.4 oz. disposable LP cylinder to the grill's regulator. Ensure a secure, leak-free connection. If using a 20-lb. tank, connect the optional adapter hose.
4. **Position Grill:** Place the grill on a stable, level, non-combustible surface away from flammable materials. Ensure adequate ventilation.

Refer to the detailed assembly instructions provided in the full user manual for specific steps and diagrams.

5. OPERATING INSTRUCTIONS

Follow these steps to operate your Weber Q 2200 Gas Grill:

1. **Prepare for Ignition:** Ensure the lid is open. Turn the burner control knob to the "START/HIGH" position.
2. **Ignite Grill:** Press the electronic ignition button. You should hear a clicking sound and see the burner ignite. If the burner does not ignite within 5 seconds, turn the control knob to "OFF", wait 5 minutes for gas to clear, and repeat the process.
3. **Preheat:** Close the lid and allow the grill to preheat for 10-15 minutes, or until the lid thermometer reaches your desired cooking temperature.
4. **Cooking:** Place food on the cooking grates. Adjust the control knob to regulate the heat as needed. The tall lid allows for grilling larger items like small roasts and birds.
5. **Monitoring Temperature:** Use the built-in lid thermometer to monitor the internal temperature of the grill.
6. **After Cooking:** Turn the burner control knob to "OFF" and disconnect the LP cylinder if storing the grill.



Figure 2: Pineapple and chicken grilling on the Weber Q 2200, demonstrating the ample cooking surface.

Operational Features Video

Your browser does not support the video tag.

Video 1: An overview of the Weber Q 2200 Gas Grill's key features, including its lid and body design, lid thermometer, LP cylinder connection, cooking capacity, porcelain-enameled cast-iron grates, electronic ignition, and fold-down side tables.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your grill:

- **Clean Cooking Grates:** After each use, brush the grates clean while they are still warm.
- **Empty Catch Pan:** The removable catch pan should be emptied and cleaned regularly to prevent grease buildup and potential flare-ups.
- **Clean Exterior:** Wipe down the exterior surfaces with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Inspect Components:** Periodically check the burner, gas hose, and connections for any signs of wear, damage, or

leaks.

7. TROUBLESHOOTING

If you encounter issues with your Weber Q 2200 Gas Grill, consider the following common troubleshooting tips:

- **Grill Not Lighting:**
 - Check if the LP cylinder is properly connected and has gas.
 - Ensure the electronic ignition button is being pressed firmly.
 - Verify that the burner control knob is in the "START/HIGH" position.
- **Low Heat Output:**
 - Confirm the LP cylinder is not low on gas.
 - Check for any obstructions in the burner tubes.
 - Ensure the regulator is not in bypass mode (reset by turning off grill, disconnecting LP, waiting, then reconnecting and slowly opening gas).
- **Flare-ups:**
 - Clean the cooking grates and catch pan to remove excess grease.
 - Trim excess fat from meats before grilling.

For persistent issues, consult the comprehensive troubleshooting section in the full user manual or contact Weber customer support.

8. SPECIFICATIONS

Attribute	Detail
Brand	Weber
Model Name	Q 2200
Product Dimensions	25.1"D x 51.4"W x 26"H (Lid closed and tables out: 15.5" H x 51.4" W x 19.5" D)
Item Weight	42.5 Pounds
Color	Gray
Fuel Type	Gas (Liquid Propane)
Heating Power	12000 British Thermal Units
Cooking Surface Area	280 Square Inches
Material	Aluminum (Lid and Body), Stainless Steel (Burner, Handle, Frame)
Special Features	Compact, Electronic Ignition, Folding Side Table, Lid Thermometer, Porcelain-Enameled, Cast-Iron Cooking Grates, Removable Catch Pan
Assembly Required	No (Minimal assembly required)

9. WARRANTY & SUPPORT





For detailed warranty information, product registration, or customer support, please refer to the official Weber resources:



- **Official User Manual:** For comprehensive instructions and safety guidelines, please download the official user manual PDF: [Weber Q 2200 User Manual \(PDF\)](#)
- **Official User Guide:** An additional user guide is available here: [Weber Q 2200 User Guide \(PDF\)](#)
- **Weber Brand Store:** Explore other Weber products and accessories, and find additional support at the official Weber store: [Visit the Weber Store](#)

Always use genuine Weber replacement parts and accessories to ensure the safety and performance of your grill.

© 2023 Weber. All rights reserved. Information subject to change without notice.

Related Documents - 54060001

	<p>Weber Genesis S-335 LP Gas Grill Assembly Guide</p> <p>Comprehensive assembly instructions for the Weber Genesis S-335 LP Liquid Propane Gas Grill. This guide provides detailed steps, parts lists, tool requirements, and important safety information, with all content presented in English for clarity and accessibility.</p>
	<p>Weber Spirit E-210/E-310 LP Gas Grill Assembly Guide</p> <p>Comprehensive assembly instructions for the Weber Spirit E-210 and E-310 Liquid Propane (LP) gas grills. This guide details required tools, lists all parts and hardware, and provides step-by-step instructions for building your grill.</p>
	<p>Weber Spirit EX-315 SX-315 LP Gas Grill Owner's Manual</p> <p>Comprehensive owner's manual for the Weber Spirit EX-315 and SX-315 LP gas grills, covering safety, installation, operation, maintenance, troubleshooting, and grilling tips. Includes WEBER CONNECT technology details.</p>
	<p>Weber SB38 S Built-In Gas Grill Installation Guide</p> <p>Comprehensive installation guide for the Weber SB38 S Built-In Gas Grill, covering safety, planning, construction, gas supply, and assembly requirements for natural gas installations.</p>

 <p>SPIRIT E-325</p> <p>LP ASSEMBLY GUIDE GUIDE DE MONTAGE ENSEMBLE GUIDE</p> <p>Scan for easy QR instructions</p> <p>Top Down, Bottom Up, or Offtop Assembly Instructions for Spirit E-325</p> <p>BUILT</p> <p>9153114 E-325 ©2017 Weber-Steel, Inc.</p> <p>weber</p>	<p>Weber Spirit E-325 LP Gas Grill Assembly Guide</p> <p>Step-by-step instructions for assembling your Weber Spirit E-325 LP gas grill, including parts lists, hardware identification, and assembly procedures.</p>
 <p>GENESIS E-315/E-415</p> <p>LP ASSEMBLY GUIDE GUIDE DE MONTAGE ENSEMBLE GUIDE</p> <p>Enhance your assembly experience. Download the new QR™ app for 3D step-by-step instructions.</p> <p>BUILT</p> <p>9500123 E-315 ©2017 Weber-Steel, Inc.</p> <p>weber</p>	<p>Weber Genesis E-315/E-415 LP Assembly Guide</p> <p>Comprehensive step-by-step assembly instructions for the Weber Genesis E-315 and E-415 LP gas grills, including parts identification, assembly procedures, and important pre-assembly and post-assembly information.</p>