

## Severin FS 3602

# Severin Folio Bag Sealer FS 3602 Instruction Manual

## 1. INTRODUCTION

This instruction manual provides essential information for the safe and efficient operation of your Severin Folio Bag Sealer FS 3602. Please read these instructions carefully before first use and keep them for future reference. The Severin Folio Bag Sealer is designed to vacuum and seal food in special folio bags, helping to preserve freshness and prevent spills.

## 2. SAFETY INSTRUCTIONS

- Always ensure the appliance is unplugged before cleaning or if it is not in use.
- Do not immerse the appliance in water or other liquids.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the power cord is damaged.
- Use only original Severin accessories and bags designed for this appliance.
- This appliance is intended for household use only.
- Avoid touching the sealing wire immediately after use, as it may be hot.

## 3. PACKAGE CONTENTS

Upon unpacking, please verify that all items are present and in good condition:

- Severin Folio Bag Sealer FS 3602 unit
- 1 roll of foil (width 29 cm)
- Instruction Manual (this document)

## 4. PRODUCT FEATURES

The Severin Folio Bag Sealer FS 3602 is equipped with features designed for convenient and effective food preservation:

- **Automatic Vacuum Control:** Automatically removes air from the bag before sealing.
- **Sealing Function:** Creates a secure, airtight seal.
- **Integrated Cutting Wire:** Allows for precise cutting of the bag after sealing.
- **Pilot Lights:** Two indicator lights for vacuum control (green) and sealing function (red).

- **Cable Storage:** Integrated storage for the power cable for compact storage.



*Image 1: Severin Folio Bag Sealer FS 3602. This image shows the white bag sealer with its control lights visible on the top right.*

## 5. SETUP

---

1. Unpack the appliance and remove all packaging materials.
2. Place the bag sealer on a stable, flat, and dry surface.
3. Ensure the power cord is easily accessible and plug the appliance into a suitable power outlet.
4. Open the lid of the appliance.

## 6. OPERATING INSTRUCTIONS

---

### 6.1. Preparing the Bag

- Use only special vacuum sealer bags or rolls. The included foil roll is 29 cm wide.
- Cut the bag to the desired length, ensuring enough space (at least 5-7 cm) between the food and the seal.
- Ensure the open end of the bag is clean and dry.

### 6.2. Vacuuming and Sealing

1. Place the open end of the bag into the vacuum channel of the appliance. Ensure the bag lies flat and is not wrinkled.
2. Close the lid firmly until it clicks into place.
3. The appliance will automatically begin the vacuuming process. The green pilot light will illuminate.
4. Once the air is removed, the appliance will automatically switch to the sealing function. The red pilot light will illuminate.
5. When the sealing process is complete, both pilot lights will turn off.
6. Open the lid and remove the sealed bag.

### 6.3. Sealing Only (without vacuuming)

1. Place the open end of the bag over the sealing wire, ensuring it is positioned correctly.
2. Close the lid firmly until it clicks into place.
3. The red pilot light will illuminate, indicating the sealing process.
4. Once the sealing is complete, the red pilot light will turn off.
5. Open the lid and remove the sealed bag.

*Note: For liquids or moist foods, it is recommended to pre-freeze them or use a container with the vacuum sealer if available, to prevent liquids from being drawn into the vacuum pump.*

## 7. MAINTENANCE AND CLEANING

- Always unplug the appliance before cleaning.
- Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the vacuum channel and sealing area with a damp cloth to remove any food residues. Ensure these areas are completely dry before next use.
- Do not immerse the appliance in water.
- Store the appliance in a dry place with the lid slightly ajar to prevent compression of the sealing gaskets.

## 8. TROUBLESHOOTING

| Problem                           | Possible Cause                                                               | Solution                                                                                         |
|-----------------------------------|------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| Appliance does not turn on.       | Not plugged in; power outlet faulty.                                         | Check power cord connection; test outlet with another appliance.                                 |
| Vacuumping is not effective.      | Bag not correctly placed; bag is damaged; sealing gaskets are dirty or worn. | Ensure bag opening is flat in the vacuum channel; check bag for holes; clean or replace gaskets. |
| Bag does not seal properly.       | Sealing wire or strip is dirty; bag is wet; too much food in the bag.        | Clean sealing area; ensure bag opening is dry; leave sufficient space at the top of the bag.     |
| Appliance stops during operation. | Overheating protection activated.                                            | Allow the appliance to cool down for at least 20 minutes before resuming use.                    |

## 9. SPECIFICATIONS

- **Model:** FS 3602
- **Brand:** Severin
- **Item Weight:** 1 kg 480 g
- **Item Dimensions (LxWxH):** 37 x 12 x 16.6 Centimeters

## 10. WARRANTY AND CUSTOMER SUPPORT

This Severin product comes with a **1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, spare parts, or warranty inquiries, please contact Severin customer support. Contact details can typically be found on the official Severin website or on your product packaging.



| ART - NE 36 340 |                         |                                 |    |
|-----------------|-------------------------|---------------------------------|----|
| DE              | Gebühren nach Maßgabe   | Valuierungsergebnis             | 4  |
| DE              | Instructions for use    | Valuierungsgesetz               | 9  |
| FR              | Made d'empile           | Conditionnement sous vide       | 10 |
| NL              | Gebühren aanmelding     | Valuierungswesen                | 18 |
| ES              | Instrucciones de uso    | Sellado de bolsas de vacío      | 20 |
| IT              | Manuale d'uso           | Macchine per sottovuoto         | 28 |
| DE              | Brugningsanvisning      | Valuierungspakt                 | 31 |
| SK              | Instrukcia používania   | Páčiť sa k                      | 37 |
| FR              | Carte d'identité        | Prestations automatisées        | 41 |
| PL              | Instrukcja obsługi      | Procedura zgłaszania do firmy   | 46 |
| DE              | Öffenes Spielrecht      | Zuerst entscheiden, wer spielt  | 50 |
| RU              | Примечания к инструкции | Беспроводной телефонной станции |    |

Official user manual for the SEVERIN FS 3610 vacuum sealer. Learn how to operate, clean, and maintain your appliance for optimal food preservation. Includes safety instructions, accessory information, and multilingual support.



| DET - HQ1 304 3771 / 304 3772 |                           |                            |    |
|-------------------------------|---------------------------|----------------------------|----|
| DE                            | Detektiva utredning       | Stämmande                  | 4  |
| DE                            | Instructions for use      | Handboken                  | 13 |
| FR                            | Mode d'emploi             | Barbure électrique         | 21 |
| NO                            | Detektiva utredning       | Stämmande                  | 30 |
| IT                            | Istruzioni tecniche d'uso | Barbure da braccio         | 38 |
| PT                            | Manual de Utilização      | Praticidade e conveniência | 47 |
| DE                            | Angewandte Ausbildung     | Stämmande                  | 56 |
| SE                            | Instruktioner             | Stämmande                  | 62 |
| PT                            | Key-locks                 | Securidade                 | 71 |
| FI                            | Manuaaliset ohjeet        | Välikäsi -magneetti        | 75 |
| PL                            | Instrukcja obsługi        | Branding -system           | 87 |
| DE                            | Styger, styrtapp          | Stämmande av spår          | 90 |

Umfassende Bedienungsanleitung für den SEVERIN Stabmixer SM 3771 und SM 3772. Enthält Sicherheitshinweise, Bedienung, Reinigung und technische Daten.



| ART-NO WK 5472                  |                                   |    |
|---------------------------------|-----------------------------------|----|
| DE Gebrauchsanweisung           | Wasserhaushalt                    | 4  |
| EN Instructions for use         | Ceiling bottle                    | 10 |
| FR Mode d'emploi                | Bouteille d'entretien             | 10 |
| NL Gebruiksaanwijzing           | Plafondfles voor onderhoud        | 25 |
| ES Instrucciones de uso         | Botella de agua de techo          | 27 |
| PT Manual d'uso                 | Bottle of water ceiling           | 30 |
| DE Ergänzungsanleitung          | Elektronik verbindet              | 39 |
| EN Extension manual             | Electronics interconnection       | 46 |
| FR Ajout manuel                 | Verbinden elektronica             | 46 |
| PT Manual de extensões          | Arreio eletrônico                 | 56 |
| NL Installatiehandleiding       | Ceplak installatiegids            | 59 |
| ES Instrucciones de instalación | Manual de instalación de plafones | 60 |

Finden Sie detaillierte Anleitungen und wichtige Sicherheitshinweise für den SEVERIN Wasserkocher WK 3472. Erfahren Sie mehr über Anschluss, Bedienung, Reinigung und Wartung.



| ART.-NO. | U2368                       |                          |    |
|----------|-----------------------------|--------------------------|----|
| DE       | Getriebebau einseitig       | Universalantriebsmotor   | 4  |
| EN       | Instructions for use        | Food chopper             | 9  |
| FR       | Mode d'emploi               | Hachoir                  | 9  |
| NO       | Getriebebau einseitig       | Hakkeapparat             | 17 |
| ES       | Instrucciones de uso        | Plataforma               | 26 |
| IT       | Manuale d'uso               | Tritatutto               | 29 |
| DK       | Brugsanvisning              | Universal eldrivemaskine | 36 |
| SE       | Brugsanvisning              | Matberedare              | 38 |
| FI       | Käyttöohje                  | Winkelmixuri             | 42 |
| PL       | Instrukcja obsługi          | Przebijarka kuchenna     | 46 |
| GR       | Οδηγός χρήσης               | Πολυδριμνιστής           | 51 |
| RU       | Руководство по эксплуатации | Универсальный            | 55 |

Die Bedienungsanleitung für den SEVERIN UZ 3861 Universalzerkleinerer bietet detaillierte Informationen zur sicheren Handhabung, Pflege und Anwendung des Küchengeräts.



| ART.-NO. FKS 8841 |                         |                                    |    |
|-------------------|-------------------------|------------------------------------|----|
| DE                | Geräuschabschlebung     | Fätscheküchlschrank                | 3  |
| FR                | Instructions de montage | Refrigerateur sur batteries        | 10 |
| FR                | Mode d'emploi           | Refrigerateur pour bouteilles      | 10 |
| NL                | Gebruiksaanwijzing      | Koelkast voor flessen              | 23 |
| ES                | Instrucciones de uso    | Frigorifico para botellas          | 23 |
| IT                | Manuale d'uso           | Refrigeratore per bottiglie        | 37 |
| DK                | Brukervejledning        | Køleskab til flasker               | 44 |
| SE                | Bråksanvisning          | Kylskåp för flaskor                | 51 |
| PT                | Cartão de instruções    | Refrigerador para garrafas         | 67 |
| PL                | Instrukcja obsługi      | Chłodziarka do napojów w butelkach | 79 |
| GR                | Εγχειρίδιο χρήσης       | Ψυγείο για ποτά                    | 79 |

Entdecken Sie die detaillierte Bedienungsanleitung und das Produktdatenblatt für den SEVERIN FKS 8841 Flaschenkühlschrank. Erfahren Sie mehr über Installation, Bedienung, Sicherheitshinweise und technische Spezifikationen dieses hochwertigen Geräts von SEVERIN.



| ART.-NO. JO 3521 |                      |                                |    |
|------------------|----------------------|--------------------------------|----|
| DE               | Einbauschraube       | Digitaler Joghurtbaker         | 12 |
| DE               | Instruktion für use  | Digitaler Joghurtbaker         | 4  |
| FR               | Mala d'emploi        | Yaourtière numérique           | 12 |
| NL               | Gebruiksaanwijzing   | Digitalis yoghurt maker        | 12 |
| ES               | Instrucciones de uso | Yogurtera digital              | 36 |
| PT               | Manual d'uso         | Yogurteira digital             | 36 |
| DE               | Einbauschraube       | Digitalis Joghurtmaschine      | 52 |
| DE               | Einbauschraube       | Digitalis Joghurtmaschine      | 52 |
| PT               | Cartão de            | Digitalização Joghurtificadora | 76 |
| PT               | Manual de instruções | Yogurteira digital             | 76 |
| PL               | Instrukcja obsługi   | Ocywca jogurtowniczy           | 82 |
| FR               | Manuel d'emploi      | Yaourtière numérique           | 12 |

Entdecken Sie den SEVERIN JG 3521 Digitalen Joghurtbereiter. Diese Anleitung bietet detaillierte Informationen zur Verwendung, Sicherheit und Rezepten für die Zubereitung von hausgemachtem Joghurt.