

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bosch](#) /
- › [Bosch TZ60001/310575 Coffee Machine Cleaning Tablets User Manual](#)

Bosch TZ60001/310575

Bosch TZ60001/310575 Coffee Machine Cleaning Tablets User Manual

Model: TZ60001 / Part Number: 310575

1. INTRODUCTION

These Bosch cleaning tablets are designed for the maintenance of automatic coffee machines and thermos flasks. Regular use helps remove coffee grease and residue, ensuring optimal machine performance and consistent coffee quality.



Image: Bosch Cleaning Tablets packaging, showing a blue box with text 'Reinigungstabletten' and 'Cleaning tablets' and a coffee cup icon.

2. SAFETY INFORMATION

- **Danger:** Causes severe skin irritation and serious eye damage.
- Keep out of reach of children.
- Wear protective gloves and eye protection when handling.
- **IF ON SKIN:** Wash with plenty of water.
- **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.
- Contains phosphonates and oxygen-based bleaching agents.
- Refer to your appliance's instruction manual for specific cleaning procedures.

3. PACKAGE CONTENTS

- 1 box of Bosch Cleaning Tablets (Part Number: 310575)
- Contains 10 tablets, each 2.2g.

4. COMPATIBILITY

These cleaning tablets are suitable for various Bosch, Siemens, and Neff automatic coffee machines and thermos flasks. For a comprehensive list of compatible models, please refer to your appliance's user manual or the product packaging. Examples of compatible models include:

- **Neff:** C7660N0 series, C77V60N01 series, C77V60N2 series
- **Bosch:** TCA6301 series, TCC78K750 series, TES50 series, TES70 series, TKN68E750 series, TK52 series, TK54 series, TK58 series, TK60 series, TK64 series, TK68E570 series, TK73 series, TK76 series
- **Siemens:** TC55001 series, TE50 series, TE70 series
- **Balay:** 3CF458X series

Note: This is not an exhaustive list. Always consult your appliance's manual for specific cleaning requirements.

5. USAGE INSTRUCTIONS

The cleaning process varies depending on your specific coffee machine model. Always refer to your appliance's instruction manual for detailed steps. General guidelines are provided below:

1. **Preparation:** Ensure your coffee machine is turned on and ready for a cleaning cycle. Empty the drip tray and coffee grounds container.
2. **Tablet Placement:** Place one Bosch cleaning tablet into the designated cleaning compartment or directly into the coffee grounds chute, as instructed by your machine's manual. Do not place the tablet in the water tank.
3. **Start Cleaning Cycle:** Initiate the cleaning program on your coffee machine. Follow the on-screen prompts or indicator lights.
4. **Rinsing:** After the cleaning cycle is complete, perform several rinsing cycles with fresh water to ensure all cleaning solution is removed from the system.
5. **Final Check:** Visually inspect the machine for any remaining residue. Your machine is now ready for use.

These tablets are effective for removing coffee oils and residues from dispensing units, filters, and thermos flasks. For descaling (calcium buildup), a separate descaling product is typically required.

6. MAINTENANCE SCHEDULE

For optimal performance and longevity of your coffee machine, it is recommended to use one cleaning tablet:

- Every couple of weeks, or
- After approximately 250 cups of coffee.

Your coffee machine may have an indicator light or message prompting you when cleaning is due.

7. TROUBLESHOOTING

If you encounter issues during or after the cleaning process, consider the following:

- **Cleaning Cycle Not Starting:** Ensure the tablet is correctly placed and all machine components (e.g., water tank, drip tray) are properly inserted.
- **Residue Remaining:** If coffee residue persists, repeat the cleaning cycle or perform additional rinsing cycles. For stubborn buildup, manual cleaning of removable parts may be necessary.
- **Error Messages:** Refer to your coffee machine's specific error code guide in its user manual.

For persistent problems, contact Bosch customer support or a qualified service technician.

8. SPECIFICATIONS

Brand	Bosch
Model Number	310575 (also known as TZ60001)
Item Form	Tablet
Scent	Coffee (neutralizes coffee odors)
Specific Uses	Coffee Maker Cleaning
Material Feature	Biobased
Quantity	10 tablets per pack

9. INGREDIENTS

The cleaning tablets contain:

- Phosphonates (5-15%)
- Oxygen-based bleaching agents (5-15%)

For a complete list of ingredients and safety data, please refer to the product packaging or the manufacturer's website.