

## Nyko 86103

# Nyko Xbox One Power Kit Plus Rechargeable Battery Kit User Manual

## INTRODUCTION

---

The Nyko Xbox One Power Kit Plus provides a convenient and reliable rechargeable power solution for your Xbox One wireless controllers. This kit includes two rechargeable battery packs, four replacement battery covers (two black and two white), and an 8-foot Micro-USB charge cable with an LED indicator. It is designed to eliminate the need for disposable batteries, offering extended gameplay sessions.

## COMPATIBILITY

---

This Power Kit Plus is specifically designed for **original Xbox One wireless controllers ONLY**. It is **not compatible** with Xbox Series S/X controllers or any Xbox controllers that feature a dedicated Home button on the battery cover itself.

## WHAT'S INCLUDED

---

Please verify that all the following components are present in your package:

- 2 x Nyko Rechargeable Battery Packs (1200 mAh NiMH)
- 2 x Black Replacement Battery Covers
- 2 x White Replacement Battery Covers
- 1 x 8-foot Micro-USB Charge Cable with LED Indicator

NYKO®

# Power Kit Plus

for Xbox One

## Battery Pack x 2

1,200 mAh NiMH • Rechargeable



## Micro-USB Charge Cable

LED Charge Indicators • 8 Feet Long



## XB1 Battery Door x 4

2 White • 2 Black



Image: Overview of the Nyko Xbox One Power Kit Plus components, including two rechargeable battery packs, an 8-foot Micro-USB charge cable, and four battery covers (two black, two white).

## SETUP INSTRUCTIONS

Follow these steps to install the rechargeable battery pack and cover into your Xbox One wireless controller:

- 1. Insert Battery Pack:** Open the battery compartment on the back of your Xbox One controller. Carefully insert one of the Nyko rechargeable battery packs, ensuring the contacts align correctly. The battery pack is labeled "THIS SIDE UP" for proper orientation.
- 2. Attach Cover:** Select a matching or preferred color battery cover (black or white) and snap it securely into place over the installed battery pack. Ensure it clicks firmly to prevent dislodging during use.



Image: Step-by-step visual guide for installing the battery pack and cover into an Xbox One controller, followed by plugging in the Micro-USB cable.

## CHARGING INSTRUCTIONS

The Nyko Power Kit Plus offers two methods for charging your rechargeable battery packs:

- 1. Direct Charging with Micro-USB Cable:** Connect the included 8-foot Micro-USB charge cable directly to the port on the rechargeable battery pack while it is installed in the controller. Plug the other end of the cable into a powered USB port (e.g., on your Xbox One console, a wall adapter, or a PC). The LED indicator on the cable will illuminate to show charging status.
- 2. Charging with Nyko Charge Base (Sold Separately):** If you own a Nyko Charge Base, you can place

the controller with the installed battery pack onto the base. Ensure the battery charge contacts on the controller align with the contacts on the charge base. The base will indicate when charging is active.

The LED indicator on the Micro-USB cable will typically show a red light during charging and turn green when the battery is fully charged. Each battery pack provides up to 25 hours of gameplay per charge.

**NYKO®**

**NYKO SEAL OF QUALITY**

**PLAY AND CHARGE • RECHARGEZ ET JOUEZ**  
Play and recharge the battery pack at the same time, no need to wait  
Jouez et rechargez le pack batterie en même temps, pas besoin d'attendre

**CE APPROVED • CE APPROUVÉ**  
CE approved for safety and quality assurance  
Conforme aux normes de sécurité et de qualité CE

**8 FT**  
8 foot cable length  
2.43 foot cable length

**Two 1,200 mAh NiMH rechargeable batteries included**  
Includes: Deux batteries 1,200 mAh rechargeables NiMH

**4 battery covers**  
4 couvercles de piles

**INCLUDED • INCLUSES:**

**2 RECHARGEABLE BATTERIES**  
2 PILES RECHARGEABLES

**1 CHARGE CABLE**  
1 CORDON DE RECHARGE

**2 WHITE AND 2 BLACK BATTERY COVERS**  
2 NOIR ET 2 BLANC COUVERCLES DE PILES

**f** [www.facebook.com/NykoTech](http://www.facebook.com/NykoTech)

**t** Follow us on twitter @NykoTech

**i** [www.instagram.com/NykoTech](http://www.instagram.com/NykoTech)

Image: Illustration demonstrating the two charging methods for the Nyko Power Kit Plus: direct connection via Micro-USB cable to the battery pack, and charging via a separate Nyko Charge Base.

## OPERATION

Once the battery pack is installed and charged, your Xbox One wireless controller will function as usual. The rechargeable battery provides power for gameplay, and the 8-foot Micro-USB cable allows for continued play

while charging, effectively turning your wireless controller into a wired one if needed.

## MAINTENANCE

---

- Keep the battery packs and charging cable dry. Avoid exposure to moisture or extreme temperatures.
- Clean the battery contacts periodically with a dry cloth to ensure optimal connection.
- Store unused battery packs in a cool, dry place.

## TROUBLESHOOTING

---

- **Battery Not Charging:**
  - Ensure the Micro-USB cable is securely connected to both the battery pack and the power source.
  - Try a different USB port or power adapter.
  - Verify the LED indicator on the cable is illuminated (red for charging).
- **Controller Not Turning On:**
  - Check that the battery pack is fully inserted and the battery cover is securely attached.
  - Ensure the battery pack is charged. If not, connect the charging cable.
  - Try using a different, fully charged battery pack.
- **Charging While Playing:** If the battery is completely depleted, plugging in the charge cable might not immediately allow for continuous play without interruption. It is recommended to plug in the controller when a low battery alert appears, rather than waiting for the battery to fully die.

## SPECIFICATIONS

---

Feature	Detail
Brand	Nyko
Model Number	86103
UPC	743840861034
Battery Type	NiMH (Nickel-Metal Hydride)
Battery Capacity	1200 mAh (per pack)
Output Voltage	3.7 Volts (DC)
Output Current	1 Amps
Input Voltage	5 Volts (DC)
Amperage	0.5 Amps
Wattage	10 watts
Cable Length	8 feet (approx. 2.43 meters)
Connector Type	Micro USB

Material	Plastic
Weight	0.18 Kilograms
Certification	CE Approved

## WARRANTY AND SUPPORT

---

This product comes with a manufacturer's warranty. For detailed warranty information, support, or service inquiries, please refer to the official Nyko website or contact Nyko customer support directly. Keep your proof of purchase for warranty claims.