

T'nB Hpbmicbk

T'nB Hpbmicbk Bluetooth Speaker with Microphone User Manual

Model: Hpbmicbk

INTRODUCTION

Thank you for choosing the T'nB Hpbmicbk Bluetooth Speaker with Microphone. This compact and portable device allows you to enjoy wireless audio and conduct hands-free calls. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your speaker.

PACKAGE CONTENTS

- T'nB Hpbmicbk Bluetooth Speaker with Microphone
- Mini USB Charging Cable (80 cm)
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your T'nB Hpbmicbk speaker.



Image 1: The T'nB Hpbmicbk Bluetooth Speaker, showcasing its compact, spherical design with a black finish and a silver band. The speaker grille is visible on top, and the power/hang-up button is located on the front silver band, next to the microphone icon.

- **Speaker Grille:** Located on the top surface for audio output.
- **Power/Hang-up Button:** Multi-function button for turning the device on/off and managing calls.
- **Microphone:** Integrated for hands-free communication.
- **Charging Port:** Mini USB port for connecting the charging cable.
- **LED Indicator:** (Assumed, common for Bluetooth devices) Indicates power status, charging, and Bluetooth pairing status.

SETUP

1. Charging the Speaker

1. Connect the supplied mini USB charging cable to the charging port on the speaker.
2. Connect the other end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator will typically show a charging status (e.g., red light).
4. Once fully charged (approximately 4 hours for full autonomy), the LED indicator may change color or turn off.

Note: Ensure the speaker is fully charged before first use for optimal battery life.

2. Bluetooth Pairing

1. **Power On:** Press and hold the Power/Hang-up button until the LED indicator lights up and/or you hear an audible prompt. The speaker will enter pairing mode, indicated by a flashing LED (e.g., blue/red alternating).
2. **Activate Bluetooth on Your Device:** On your smartphone, tablet, PC, or other compatible device, go to the Bluetooth

settings and ensure Bluetooth is enabled.

3. **Search for Devices:** Your device will scan for available Bluetooth devices.
4. **Select "Hpbmicbk":** From the list of found devices, select "Hpbmicbk" (or a similar name like "T'nB Speaker").
5. **Confirm Pairing:** Once paired, the LED indicator on the speaker will typically show a solid blue light, and you may hear a confirmation tone.

The speaker has a wireless range of up to 10 meters (33 feet) from the paired device.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the Power/Hang-up button for approximately 3 seconds.
- **To Power Off:** Press and hold the Power/Hang-up button for approximately 3 seconds.

Music Playback

Once paired with your device, audio will automatically stream to the T'nB Hpbmicbk speaker. Control playback (play, pause, skip tracks, volume) directly from your connected device.

Hands-Free Calling (Conference Call Mode)

The integrated microphone allows you to answer calls directly through the speaker.

- **Answering a Call:** When a call comes in, press the Power/Hang-up button once to answer.
- **Ending a Call:** During a call, press the Power/Hang-up button once to end the call.
- **Rejecting a Call:** Press and hold the Power/Hang-up button for approximately 2 seconds to reject an incoming call.

Energy Saving Mode

To conserve battery life, the speaker will automatically power off after 5 minutes of inactivity (no audio playback or Bluetooth connection).

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable.

Problem	Possible Solution
Cannot pair with a Bluetooth device.	• Ensure the speaker is in pairing mode (flashing LED). • Make sure Bluetooth is enabled on your device. • Move the speaker closer to your device (within 10 meters). • Turn off and on both the speaker and your device's Bluetooth. • Forget the device from your Bluetooth list and try pairing again.
No sound or low volume.	• Increase the volume on both the speaker and your connected device. • Ensure the speaker is properly paired and connected. • Check if the audio output on your device is set to the Bluetooth speaker.
Call quality is poor.	• Ensure you are within the 10-meter Bluetooth range. • Minimize interference from other wireless devices. • Speak clearly towards the microphone.

SPECIFICATIONS

- **Model:** Hpbmicbk
- **Connectivity:** Bluetooth 3.0 A2DP
- **Wireless Range:** Up to 10 meters (33 feet)
- **Power Output:** 2 Watts
- **Battery:** Rechargeable Lithium-Ion, 420 mAh
- **Battery Autonomy:** Approximately 4 hours (listening time)
- **Charging Time:** Approximately 4 hours for full charge.
- **Microphone:** Integrated for hands-free calls
- **Energy Saving:** Automatic power-off after 5 minutes of inactivity
- **Dimensions:** 7 x 7 x 4.8 cm (2.76 x 2.76 x 1.89 inches)
- **Weight:** 110 g (0.24 lbs)
- **Compatibility:** Smartphones, iPod, MP3 players, PC/Mac, tablets

WARRANTY AND SUPPORT

The T'nB Hpbmicbk Bluetooth Speaker comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or further assistance, please refer to the contact information provided on the official T'nB website or your retailer's support channels.

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00FLXSMOC>

More documents and user manuals: <https://manuals.plus/>