

[Manuals.plus](#) /

› [Dickie Toys](#) /

› DICKIE TOYS Fire Hero Try Me 43 cm Fire Truck Instruction Manual

Dickie Toys Fire Hero Try Me

DICKIE TOYS Fire Hero Try Me 43 cm Fire Truck Instruction Manual

Model: Fire Hero Try Me

1. INTRODUCTION

Thank you for choosing the DICKIE TOYS Fire Hero Try Me 43 cm Fire Truck. This toy is designed to provide an engaging play experience with realistic fire truck features, including lights, sounds, an extendable ladder, and a water spray function. This manual provides essential information for safe and proper use, setup, operation, and maintenance of your new toy.

2. SAFETY INFORMATION

- **Age Recommendation:** This toy is suitable for children aged 3 years and older.
- **Small Parts:** This product may contain small parts that could pose a choking hazard for children under 3 years. Adult supervision is recommended.
- **Battery Safety:** If the remote control or any electronic components require batteries (not included for remote), always use the correct type and insert them with the correct polarity (+/-). Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly. Do not recharge non-rechargeable batteries. Keep batteries out of reach of small children.
- **Water Use:** The water spray function uses water. Ensure play is conducted in an appropriate area to avoid water damage to surfaces or electronics. Do not spray water towards electrical outlets or other electronic devices.
- **Supervision:** Always supervise children during play, especially when using the water spray function or operating the vehicle near obstacles.

3. SETUP

3.1 Unboxing

Carefully remove all components from the packaging. Ensure all parts are present: the Fire Hero fire truck, the remote control/microphone unit, and any included accessories. Dispose of packaging materials responsibly.



Image Description: The DICKIE TOYS Fire Hero fire truck is shown inside its retail packaging, highlighting the product's presentation before unboxing.

3.2 Battery Installation (Remote Control)

The main fire truck features a 'Try Me' function, which typically includes demonstration batteries. For full functionality of the remote control/microphone unit, user-installed batteries are required.

1. Locate the battery compartment on the underside of the remote control/microphone unit.
2. Using a screwdriver (not included), open the battery compartment cover.
3. Insert the required number and type of batteries (e.g., 2 x AA, not included) according to the polarity markings (+/-).
4. Replace the battery compartment cover and secure it with the screw.



Image Description: The main product view shows the red fire truck with its extendable ladder, alongside the red remote control unit with blue buttons and an attached microphone.

4. OPERATING INSTRUCTIONS

4.1 Basic Movement

Use the controls on the remote control unit to move the fire truck. Typically, there are buttons or joysticks for:

- **Forward/Backward:** Moves the truck in the desired direction.
- **Left/Right:** Steers the truck.

4.2 Lights and Sounds

Press the designated buttons on the remote control or the truck itself to activate realistic lights and siren sounds. The 'Try Me' function allows for a demonstration of these features directly from the packaging.

4.3 Ladder Operation

The fire truck features an extendable and rotatable ladder. Use the controls on the remote or manually adjust the ladder to:

- **Extend/Retract:** Lengthen or shorten the ladder.
- **Rotate:** Turn the ladder left or right.
- **Raise/Lower:** Adjust the angle of the ladder.

4.4 Water Spray Function

To activate the water spray:

1. Locate the water tank on the fire truck and fill it with clean tap water.
2. Ensure the ladder is extended and positioned correctly.
3. Press the dedicated water spray button on the remote control. Water will be sprayed from the nozzle at the end of the ladder.



Image Description: The red fire truck is depicted in action, with its blue emergency lights flashing and a stream of water spraying

from the nozzle at the end of its extended ladder.

4.5 Microphone Function

The remote control unit includes a microphone. Speak into the microphone to amplify your voice through the truck's speaker, simulating a real fire truck's public address system.



Image Description: A child is shown happily playing with the Fire Hero fire truck, holding the microphone from the remote control unit, demonstrating interactive play.

5. MAINTENANCE

- **Cleaning:** Wipe the toy with a damp cloth to remove dust and dirt. Do not immerse the toy or remote control in water. Avoid using harsh chemicals or abrasive cleaners.
- **Water Tank:** After using the water spray function, empty any remaining water from the tank to prevent mold or mildew buildup.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use. Remove batteries from the remote control if the toy will not be used for an extended period.

6. TROUBLESHOOTING

- **Toy Not Responding:**
 - Check if the remote control batteries are correctly installed and not depleted. Replace if necessary.
 - Ensure the toy's power switch (if any) is in the 'ON' position.
- **Lights/Sounds Not Working:**
 - Verify battery status in the remote control.
 - Ensure no obstructions are blocking the speaker or light components.
- **Water Spray Not Working:**
 - Check if the water tank is filled.
 - Ensure the nozzle is not clogged.

7. SPECIFICATIONS

Brand	Dickie Toys
Model Name	Fire Hero Try Me
Toy Vehicle Form	Car (Fire Truck)
Material	Plastic
Colour	Red
Age Range (Description)	Kid (3+ years)
Special Features	Portable, Lights, Sounds, Extendable Ladder, Water Spray, Microphone

Item Weight	1.4 Kilograms
Dimensions	Approximately 43 cm (length)

8. WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct customer support contacts for the DICKIE TOYS Fire Hero Try Me 43 cm Fire Truck is not available in the provided product details. Please refer to the product packaging or the manufacturer's official website for further assistance.

© 2023 Dickie Toys. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00FMA9RZW>

More documents and user manuals: <https://manuals.plus/>