

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sauder](#) /

› [Sauder Palladia Credenza \(Model 415025\) User Manual](#)

Sauder 415025

Sauder Palladia Credenza (Model 415025) User Manual

For TVs up to 70 inches, Select Cherry Finish

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sauder Palladia Credenza, Model 415025. This credenza is designed to accommodate televisions up to 70 inches and offers versatile storage solutions for media components and decorative items.

Key features include four framed doors with interchangeable glass or wood panels, adjustable shelving, a concealed power strip, and an integrated cord management system to maintain an organized appearance.



Image 1.1: Front view of the Sauder Palladia Credenza.

2. SAFETY INFORMATION

Caution: This product may weigh over 179 lbs (81 kg). Additional assistance is required during assembly and installation to prevent injury. Always lift with proper technique and ensure the credenza

is placed on a stable, level surface.

Do not overload shelves. Ensure all fasteners are securely tightened before use. Keep small parts away from children during assembly.

3. SETUP AND ASSEMBLY

Assembly of the Sauder Palladia Credenza requires patience and attention to detail. It is recommended that two adults perform the assembly. All necessary materials, hardware, and detailed instructions are included with your purchase.

- **Unpacking:** Carefully unpack all components and verify against the parts list in your instruction manual. Inspect all pieces for any damage before beginning assembly.
- **Tools Required:** Standard household tools such as a screwdriver and hammer may be required.
- **Assembly Steps:** Follow the step-by-step instructions provided in the included manual. Pay close attention to diagrams and part numbers.
- **Door Panels:** The credenza features versatile door options with easy-to-insert panels in either safety-tempered glass or wood. Choose your preferred style during assembly.
- **Placement:** Ensure the credenza is assembled in or near its final location due to its weight.




Image 3.1: Dimensional diagram of the credenza, showing overall and internal compartment measurements.



Image 3.2: Credenza with glass panels, allowing visibility of contents.



Image 3.3: Credenza with solid wood panels, providing concealed storage.

4. OPERATING INSTRUCTIONS

The Sauder Palladia Credenza is designed for versatile use in your living space.

- **Television Placement:** The top surface can accommodate a TV up to 70 inches, weighing 95 lbs (43 kg) or less. Ensure the TV base fits securely within the credenza's top dimensions.
- **Storage and Display:** Utilize the four large adjustable shelves behind the doors for flexible storage of media components, books, or decorative items. The center door conceals a power strip for convenient organization of gaming components and other electronics.
- **Cord Management:** An integrated cord management system helps keep wires and cables neat and out of sight, contributing to a tidy entertainment area.



Image 4.1: Credenza in use with a television and media devices.



Image 4.2: Interior view demonstrating adjustable shelving for various items.



Image 4.3: Another interior view highlighting storage capacity.

5. MAINTENANCE

To maintain the appearance and longevity of your Sauder Palladia Credenza, follow these simple care instructions:

- **Cleaning:** Wipe the surface with a dry cloth. Avoid using abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Promptly clean any spills with a soft, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.
- **Heat:** Do not place hot items directly on the surface without protective padding.

6. TROUBLESHOOTING

If you encounter issues during assembly or use, consider the following:

- **Missing or Damaged Parts:** Before assembly, carefully inspect all components. If any parts are missing or damaged, contact Sauder customer service for replacements. Do not attempt to assemble with

damaged parts.

- **Assembly Difficulties:** Review the instruction manual carefully. Ensure all parts are oriented correctly and fasteners are tightened as specified. Sometimes, having a second person assist can resolve alignment issues, especially with doors.
- **Stability Issues:** Ensure the credenza is placed on a flat, level surface. Verify all cam locks and screws are fully tightened.

7. SPECIFICATIONS

Feature	Detail
Brand	Sauder
Model Number	415025
Color	Select Cherry
Product Dimensions (D x W x H)	19.45"D x 70.16"W x 33.11"H (49.4cm D x 178.2cm W x 84.1cm H)
TV Accommodation	Up to 70" TV, weighing 95 lbs (43 kg) or less
Item Weight	152 Pounds (68.9 kg)
Material	Engineered Wood
Number of Shelves	4 (adjustable)
Special Features	Adjustable Shelves, Concealed Power Strip, Cord Management System
Door Style	Glass Front (interchangeable with wood panels)
Assembly Required	Yes

8. WARRANTY AND SUPPORT

Warranty Information:

This Sauder product is covered by a **5-year parts warranty**. Please retain your proof of purchase for warranty claims.

Customer Support:

For assistance with assembly, replacement parts, or any other inquiries, please contact Sauder customer service:

- **Website:** sauder.com/service
- **Phone:** 800-523-3987

Sauder's domestic call center is ready to assist you with any questions or concerns.



BOOKCASES

Image 8.1: Sauder customer service information.

© 2025 Sauder Woodworking. All rights reserved.

Related Documents - 415025

	<p>Sauder Entertainment Credenza Model 421192 Assembly Instructions</p> <p>Detailed assembly instructions, part identification, and safety information for the Sauder Entertainment Credenza, Model 421192. Includes guidance for a successful setup.</p>
	<p>Sauder Avdija TV Stand (THVE3430) Assembly Instructions</p> <p>Official assembly guide for the Sauder Avdija TV Stand (Model THVE3430). Includes detailed steps, part identification, hardware usage, safety warnings, and warranty information.</p>
	<p>Sauder TV Stand Model 411660 Assembly Instructions and Safety Guide</p> <p>A comprehensive guide for assembling the Sauder TV Stand, Model 411660. Includes detailed step-by-step instructions, parts and hardware identification, important safety warnings regarding TV stability and weight limits, and warranty information.</p>

	<p><u>Sauder Panel TV Stand - Model 413037 Assembly Instructions</u></p> <p>Detailed assembly instructions for the Sauder Panel TV Stand, Model 413037. Includes product information, safety warnings, assembly tools, part identification, hardware list, step-by-step assembly guide, and warranty details.</p>
	<p><u>Sauder L-Desk (Model 420606) Assembly Instructions</u></p> <p>Comprehensive assembly guide for the Sauder L-Desk, Palladia Collection (Model 420606), including part identification, hardware details, and step-by-step instructions.</p>
	<p><u>Sauder Palladia Collection Computer Desk with Hutch (Model 420513) - Assembly Instructions</u></p> <p>Detailed assembly instructions and parts identification for the Sauder Palladia Collection Computer Desk with Hutch, Model 420513. Includes safety information and warranty details.</p>