

[Manuals.plus](#) /

› [VIBE SOUND](#) /

› VIBE SOUND VS 599 BLK Oval Stereo Speaker (Black) User Manual

VIBE SOUND VS-599-BLK

VIBE SOUND VS 599 BLK Oval Stereo Speaker User Manual

Model: VS-599-BLK

INTRODUCTION

The VIBE SOUND VS 599 BLK Oval Stereo Speaker is a portable and lightweight audio device designed for convenient music playback. Its unique design allows for easy integration with compatible devices, providing a straightforward audio experience.

Key Features:

- Lid opens to conveniently cradle your iPhone5.
- Features ON/OFF button for simple control.
- Includes AUX cable and convenient 3.5mm jack cable slot for universal compatibility.
- Comes with an extra AUX cable.

PRODUCT OVERVIEW



This image shows the VIBE SOUND VS 599 BLK Oval Stereo Speaker in black. An iPhone 5 is securely docked in the speaker's cradle, demonstrating its compatibility and design feature. The speaker has an oval shape with a textured front grille. The iPhone screen displays a music player interface with the text 'high quality stereo sound' and 'Vibe Sound Mix-Soundtrack 01'.

SETUP

1. **Power Connection:** The speaker can be powered by 3 AAA batteries (not included) or via a corded electric connection. Insert batteries into the designated compartment or connect the power adapter (if included) to a power outlet.
2. **Device Placement:** Open the lid of the speaker to reveal the cradle. Carefully place your iPhone 5 or similarly sized device into the cradle for convenient access to its screen.
3. **Audio Connection:** Connect your audio source (e.g., smartphone, MP3 player) to the speaker using the provided 3.5mm AUX cable. Insert one end into the audio output jack of your device and the other end into the 3.5mm jack cable slot on the speaker.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Locate the ON/OFF button on the speaker. Press it to turn the speaker on. Press it again to turn the speaker off.
2. **Audio Playback:** Once your audio source is connected and the speaker is powered on, begin playing audio from your device. The sound will be routed through the VIBE SOUND speaker.
3. **Volume Control:** Adjust the volume directly from your connected audio device. The speaker does not feature

independent volume controls.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If using batteries, replace all 3 AAA batteries simultaneously when the sound quality degrades or the speaker fails to power on. Ensure correct polarity.
- **Cable Care:** Handle the AUX cables gently. Avoid sharp bends or excessive pulling to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speaker	Speaker is off Low battery Audio cable not connected properly Device volume is too low	Press the ON/OFF button to turn on Replace AAA batteries or connect to power Ensure AUX cable is fully inserted into both speaker and audio device Increase volume on your connected audio device
Distorted or muffled sound	Damaged AUX cable Audio source issue Speaker placed on an uneven surface	Try using the extra AUX cable or a different 3.5mm cable Test with a different audio source or song Place the speaker on a flat, stable surface
Device not fitting in cradle	Device is not an iPhone 5 or similar size	The cradle is specifically designed for iPhone 5. Other devices may not fit perfectly.

SPECIFICATIONS

Feature	Detail
Model Name	VS 599
Item Model Number	VS-599-BLK
Brand	VIBE SOUND
Color	Black
Audio Output Mode	Stereo
Connectivity Technology	Auxiliary
Connectivity Protocol	Auxiliary
Power Source	Corded Electric
Batteries Required	3 AAA batteries (not included)
Impedance	4 Ohm

Feature	Detail
Product Dimensions	5.6 x 4.9 x 8.2 inches
Item Weight	2.4 ounces
Manufacturer	DGL Group, LLC
UPC	822248572305

© 2024 VIBE SOUND. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question