

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Philips](#) /

› [Philips Daily Collection HR2738 Citrus Juicer User Manual](#)

Philips HR2738

Philips Daily Collection HR2738 Citrus Juicer User Manual

Model: HR2738

INTRODUCTION

Thank you for choosing the Philips Daily Collection HR2738 Citrus Juicer. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before first use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Philips HR2738 Citrus Juicer.

1. **Juicing Cone:** Designed to extract juice from citrus fruits.
2. **Pulp Filter:** Separates pulp and seeds from the juice.
3. **Juice Jug (0.5L):** Collects the extracted juice. Features measurement markings.
4. **Motor Base:** Contains the motor and power cord.
5. **Spout:** For pouring juice without drips.
6. **Power Cord Storage:** Integrated storage for the power cord.



Image: The Philips HR2738 citrus juicer showing the 500 ml juice jug with measurement markings.



Image: Close-up of the Philips HR2738 juicer's spout, highlighting its no-drip design.

SETUP

Follow these steps to assemble your juicer before use:

1. Place the motor base on a clean, stable, and dry surface.
2. Place the juice jug onto the motor base, ensuring it is seated correctly.
3. Position the pulp filter on top of the juice jug.
4. Place the juicing cone onto the pulp filter.
5. Unwind the power cord from the integrated storage at the base and plug the appliance into a suitable power outlet.



Image: The underside of the Philips HR2738 juicer, illustrating the integrated power cord storage.

OPERATING INSTRUCTIONS

To extract juice from citrus fruits:

1. Wash the citrus fruit (e.g., oranges, lemons, grapefruits) thoroughly.
2. Cut the fruit in half.
3. Place one half of the fruit onto the juicing cone.

4. Press down gently on the fruit. The juicer will automatically start rotating. Apply steady, gentle pressure to extract the juice. The juicing cone rotates in both directions for optimal juice extraction.
5. Release the pressure to stop the juicer.
6. Once juicing is complete, lift the juicing cone and pulp filter to access the juice in the jug.
7. Use the spout to pour the fresh juice into a glass.



Image: A hand pouring freshly extracted juice from the Philips HR2738 juicer's jug into a glass.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your juicer.

1. Always unplug the appliance from the power outlet before cleaning.
2. Disassemble the juicing cone, pulp filter, and juice jug from the motor base.
3. All removable parts (juicing cone, pulp filter, juice jug) are dishwasher safe. Alternatively, wash them by hand with warm water and a mild dishwashing liquid. Rinse thoroughly.

4. Wipe the motor base with a damp cloth. Do not immerse the motor base in water or rinse it under running water.
5. Ensure all parts are completely dry before reassembling or storing the appliance.



Image: Illustration indicating that all removable parts of the Philips HR2738 juicer are dishwasher safe for easy cleaning.

TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

- **Juicer does not turn on:**
Ensure the power plug is securely inserted into a working electrical outlet. Check if there is a power outage or if the circuit breaker has tripped.
- **Poor juice extraction or excessive pulp:**
Ensure you are applying gentle, consistent pressure on the fruit. Make sure the fruit is cut in half properly. The juicer is designed to rotate both ways for maximum extraction.
- **Juicer is leaking:**
Verify that all parts (juice jug, pulp filter, juicing cone) are correctly assembled and securely seated on the motor base.

If the problem persists, please contact Philips customer support.

SPECIFICATIONS

Brand	Philips
Model Number	HR2738/01
Power Consumption	25 W
Material	Plastic
Capacity	0.5 Litre
Color	White
Product Dimensions	19 x 17 x 14 cm

Item Weight	550 g
Special Features	Cord storage, Dishwasher safe parts
Recommended Uses	Citrus fruits

WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Philips website. For technical support or service, please contact Philips customer service in your region. You can find more information and support on the official Philips website: www.philips.com