Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Lasko /
- Lasko 2002W 6-Inch Personal Table Fan Instruction Manual

Lasko 2002W

Lasko 2002W 6-Inch Personal Table Fan Instruction Manual

Model: 2002W | Brand: Lasko

1. Introduction

This manual provides essential information for the safe and efficient operation of your Lasko 2002W 6-inch Personal Table Fan. Please read all instructions carefully before use and retain this manual for future reference.

The Lasko 2002W is a compact personal fan designed to provide cooling comfort in various indoor settings. It features a quiet operation, two-speed settings, and a tilt-back fan head for directional airflow.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electrical shock, or personal injury, always follow these basic safety precautions:

- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- Always unplug the fan before moving, servicing, or cleaning.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not use this fan with any solid-state speed control device.
- This fan is intended for indoor use only. Do not use outdoors.

• The fan is equipped with an ETL listed, patented, fused safety plug for enhanced protection.

3. ASSEMBLY

Your Lasko 2002W Personal Table Fan requires minimal assembly and no tools are needed.

- 1. Carefully remove the fan from its packaging.
- 2. Ensure the fan head is securely attached to the base.
- 3. Place the fan on a stable, flat surface.



Figure 1: The Lasko 2002W fan highlighting its simple no-tools assembly and integrated storage compartment.

4. OPERATING INSTRUCTIONS

4.1 Power and Speed Control

The Lasko 2002W fan features an easy-grip rotary control located on the back of the fan unit. This control allows you to turn the fan On/Off and select between two quiet speeds.

1. Plug the fan into a 120V AC wall outlet.

- 2. Rotate the control knob to '1' for Low speed or '2' for High speed.
- 3. To turn the fan Off, rotate the control knob to '0'.

4.2 Adjusting Airflow Direction (Tilt-Back Head)

The fan head can be tilted up or down to direct airflow precisely where needed.

- 1. Gently grasp the fan head.
- 2. Tilt the fan head to your desired angle (upwards towards the ceiling or downwards towards the floor). The fan will hold its position.



Figure 2: The Lasko 2002W fan positioned on a bedside table, illustrating its adjustable tilt-back head for personalized airflow.

5. FEATURES

- 2 Quiet Speeds: Provides customizable airflow with minimal noise.
- Tilt-Back Fan Head: Allows for precise direction of air, from floor to ceiling.
- Integrated Storage Tray: Conveniently located in the base for small items like coins or paper clips.
- Compact Design: Ideal for personal use in home offices, bedrooms, kitchens, and other small

spaces.

- Easy-Grip Rotary Control: Simple and intuitive operation.
- No-Tools Assembly: Quick and easy setup.



Figure 3: The Lasko 2002W fan's base features a practical storage tray, useful for keeping small desk items organized.

6. MAINTENANCE

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- Always unplug the fan from the power outlet before cleaning.
- Use a soft cloth to gently wipe the exterior surfaces of the fan.
- To clean the fan blades, the front grille can be carefully removed. Refer to the assembly section for guidance on reattaching the grille.
- Do not immerse the fan in water or allow water to drip into the motor housing.
- Do not use abrasive cleaners or harsh chemicals, as these may damage the fan's finish.

7. TROUBLESHOOTING

If your fan is not operating as expected, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power to the fan.	Ensure the fan is plugged into a working 120V AC outlet. Check if the outlet is active by plugging in another appliance.
	Rotary switch is in the '0' (Off) position.	Rotate the control knob to '1' or '2'.

Problem	Possible Cause	Solution
	Blown fuse in the polarized plug.	Replace the fuse according to the instructions provided with the fan or contact Lasko customer service.
Reduced airflow.	Dust accumulation on blades or grille.	Unplug the fan and clean the blades and grille as described in the Maintenance section.
Fan is noisy.	Loose parts or debris.	Unplug the fan and inspect for any loose components or foreign objects. Ensure the fan is on a stable surface.

8. SPECIFICATIONS

Feature	Detail
Model Name	2002W
Brand	Lasko
Electric Fan Design	Table Fan
Power Source	Corded Electric
Product Dimensions	6.44"D x 7.88"W x 9.25"H
Item Weight	2 Pounds
Color	White
Wattage	12 watts
Voltage	120V
Number of Power Levels	2
Blade Length	6 Inches
Air Flow Capacity	190 Cubic Feet Per Minute
Switch Type	Rotary
Indoor/Outdoor Usage	Indoor
Main Power Connector Type	NEMA 5-15 plug
UPC	046013458216

9. WARRANTY AND SUPPORT

This Lasko fan is covered by a **1-year manufacturer limited warranty** from the date of purchase. This warranty covers defects in material or workmanship under normal use.

For warranty claims, technical support, or replacement parts, please contact Lasko customer service directly. Keep your proof of purchase for warranty validation.

For more information, visit the official Lasko website or refer to the contact details provided in your product packaging.

© 2023 Lasko Products, LLC. All rights reserved.

Related Documents - 2002W



Manual de Operación Lasko Modelo 2002W: Ventilador Personal de 6 Pulgadas y 2 Velocidades

Este manual de operación para el ventilador personal Lasko Modelo 2002W de 6 pulgadas y 2 velocidades proporciona instrucciones de seguridad importantes, montaje, uso y mantenimiento. Diseñado para uso residencial.



Lasko MYHEAT® MAX Digital Personal Ceramic Heater - Instruction Manual

Instruction manual for the Lasko MYHEAT® MAX Digital Personal Ceramic Heater (Models CD09100, CD09101), covering safety, operation, maintenance, troubleshooting, and warranty information.



Lasko MYHEAT®-GO Space Heater CD12100 User Manual and Safety Instructions

Comprehensive user manual and safety guide for the Lasko MYHEAT®-GO Space Heater, Model CD12100. Includes operating instructions, maintenance, troubleshooting, warranty, and safety information.



Lasko CT22539 Ceramic Tower Heater with Remote Control - User Manual and Safety Instructions

Comprehensive user manual and safety instructions for the Lasko CT22539 Ceramic Tower Heater with Remote Control. Includes details on operation, safety warnings, maintenance, troubleshooting, and warranty information.



Lasko Cyclonic Ceramic Heater Instruction Manual

Instruction manual for the Lasko Cyclonic Ceramic Heater (Model CC24925), providing safety warnings, operating instructions, maintenance, troubleshooting, warranty information, and parts details.



Lasko U35105 Oscillating High Velocity Fan - Operating Manual and Safety Instructions

Comprehensive operating manual and safety instructions for the Lasko U35105 Oscillating High Velocity Fan. Includes maintenance, troubleshooting, warranty information, and usage guidelines for residential use.