

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [McCULLOCH](#) /

> [McCulloch Canister Steam Cleaner MC1375, 90 Minute Runtime, 20 Accessories: Jet Nozzle, Brushes, & More - Built for Home, Tile, Grout, Carpet, Furniture, Car Detailing, & Commercial Deep Cleaning](#)

## McCULLOCH MC1375

# McCulloch MC1375 Canister Steam Cleaner Instruction Manual

Model: MC1375

Brand: McCULLOCH

## INTRODUCTION

---

The McCulloch MC1375 Canister Steam System is a versatile multi-purpose steam cleaner designed for effective and natural cleaning across a wide variety of surfaces. It utilizes ordinary water heated to over 200°F to eliminate grease, grime, and stains without harsh chemicals. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your MC1375 steam cleaner.



20-PIECE

# PROFESSIONAL ACCESSORY KIT



Figure 2: Detailed view of the 20-piece professional accessory kit.

- **Main Unit:** The canister base housing the water tank, heating element, and controls.
- **Steam Hose:** 7-foot insulated hose connecting the main unit to the steam gun.
- **Steam Gun:** Handheld trigger-operated steam release.
- **Extension Wands (2):** For extended reach, especially with the floor mop.
- **Floor Mop Head:** Attaches to extension wands for floor cleaning.
- **Mop Pads (Scrubby & Traditional):** Reusable pads for the floor mop head.
- **Jet Nozzle:** Concentrates steam for targeted cleaning.
- **Angled Nozzle:** For reaching difficult angles.
- **Nylon Brushes (various sizes):** For general scrubbing on various surfaces.
- **Brass Brush:** For heavy-duty scrubbing on durable surfaces like grout or grills.
- **Scraper:** For removing stubborn, baked-on grime.
- **Squeegee:** For cleaning windows and mirrors.
- **Triangle Brush:** A versatile brush for corners and detailed areas.
- **Large Brush:** Designed for cleaning floors and tiles.
- **Measuring Cup & Funnel:** For accurate and easy water filling.

- **Swanky Storage Bag:** For convenient storage of accessories.

**MC1375**

# POWER STEAM SERIES

**7 FT. INSULATED HOSE**  
for easy reach

**ON-BOARD STORAGE**  
convenient storage

**PRESSURE GAUGE**  
displays steam pressure

**48 OZ. WATER TANK**  
for fewer refills

**2 YEAR WARRANTY**

**ON-DEMAND VARIABLE STEAM**  
allows you to dial in steam flow

**18 FT. POWER CORD**  
for easy reach

**1500W HEATING POWER**  
90 min. of continuous steam

Figure 3: Key features of the MC1375 Power Steam Series.

## SETUP

1. **Unpack:** Remove all components from the packaging.
2. **Fill Water Tank:** Unscrew the water tank cap. Using the provided measuring cup and funnel, carefully pour up to 48 ounces of distilled water into the tank. Do not overfill. Securely replace the cap.
3. **Connect Hose:** Attach the steam hose securely to the main unit.
4. **Plug In:** Plug the 18-foot power cord into a standard 120V electrical outlet.
5. **Heat Up:** Turn the unit on. The MC1375 heats up in under 12 minutes. The pressure gauge will indicate when optimal steam pressure is reached (green zone).

## READY IN MINUTES



**ON-DEMAND VARIABLE STEAM ALLOWS YOU TO DETAIL IN STEAM FLOW**



**10 MINUTE HEAT TIME**



**90 MINUTE CONTINUOUS STEAM**



Figure 4: The MC1375 is ready for use in minutes.

## OPERATING INSTRUCTIONS

Once the unit is heated and pressurized, you can begin cleaning. Select the appropriate accessory for your task.

- **Attaching Accessories:** Securely attach the desired nozzle or brush to the steam gun or extension wand.
- **Variable Steam Control:** Use the variable steam control knob on the main unit to adjust the steam intensity for different cleaning needs.
- **Steam Lock:** For continuous steam, engage the optional steam lock on the steam gun handle.
- **Cleaning Surfaces:**
  - **Floors:** Use the floor mop head with mop pads for sealed hardwood, tile, and laminate.
  - **Grout & Tile:** Use the jet nozzle or brass brush for deep cleaning grout lines.
  - **Appliances & Grills:** Use the brass brush or scraper for tough grease and grime.
  - **Furniture & Upholstery:** Use softer nylon brushes or the mop pads (with caution) for delicate fabrics. Always test on an inconspicuous area first.
  - **Car Detailing:** Ideal for interior surfaces, dashboards, and hard-to-reach areas.

- **Wiping:** Always wipe the steamed surface with a clean cloth immediately after steaming to remove loosened dirt and moisture.




Figure 5: The MC1375 is safe and effective on a wide range of surfaces.

Your browser does not support the video tag.

Video 1: A quick overview of the McCulloch MC1375 Canister Steamer, demonstrating its features and ease of use.

## MAINTENANCE

- **Empty Water Tank:** After each use, ensure the unit is cool and depressurized, then carefully empty any remaining water from the tank.
- **Clean Accessories:** Wash all brushes, nozzles, and mop pads with soap and water. Allow them to air dry completely before storing.
- **Descaling:** Over time, mineral deposits may build up, especially if non-distilled water is used. Refer to the full user guide (PDF link provided in product details) for detailed descaling instructions.
- **Storage:** Store the steam cleaner and all accessories in a cool, dry place, preferably in the provided storage bag.

## TROUBLESHOOTING

| Problem                         | Possible Cause   | Solution   |
|---------------------------------|--|--|
| No steam or low steam pressure. | Water tank empty; unit not heated sufficiently; mineral buildup. | Refill water tank with distilled water; allow 12 minutes for heating; descale unit if necessary.       |
| Water leaking from nozzle.      | Accessory not securely attached; condensation.                   | Ensure accessory is firmly attached; allow a few seconds for steam to build up and clear condensation. |
| Unit not turning on.            | Not plugged in; power outlet issue.                              | Check power cord connection; try a different outlet.   |

## SPECIFICATIONS

- **Model Name:** MC1375
- **Power Source:** Corded Electric
- **Voltage:** 120V
- **Wattage:** 1500 watts
- **Tank Volume:** 48 Fluid Ounces (approx. 1.4 liters)
- **Heat Time:** Under 12 minutes
- **Continuous Steam Runtime:** Up to 90 minutes
- **Steam Pressure:** Up to 58 PSI
- **Power Cord Length:** 18 feet
- **Steam Hose Length:** 7 feet
- **Item Weight:** 10.78 Pounds
- **Product Dimensions:** 8"D x 5.2"W x 10.7"H
- **Included Components:** Steam cleaner, 20 accessories

## WARRANTY AND SUPPORT

The McCulloch MC1375 Steam Cleaner comes with a **1-year limited warranty**. Additionally, McCulloch offers superior support, promising to replace the product for up to 2 years if it does not meet your expectations. Support is provided from Andover, KS.

For further assistance or to access the full user guide, please refer to the official McCulloch website or contact their customer support directly.

*Note: The full User Manual (PDF) can often be found on the product's Amazon page or the manufacturer's website.*