

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Titan](#) /
- › [Titan Purple Analog Gold Dial Women's Watch \(Model NQ9955WM01/NP9955WM01\) - Instruction Manual](#)

Titan NQ9955WM01/NP9955WM01

Titan Purple Analog Gold Dial Women's Watch

Model: NQ9955WM01/NP9955WM01

[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

PRODUCT OVERVIEW

The Titan Purple Analog Gold Dial Women's Watch is a sophisticated timepiece designed for everyday elegance. It features a round, rose gold dial with three plain hands, Roman numeral markings at the quarter intervals, and slanted markings for minute indication. The dial is encased in a studded rose gold case, complemented by a stainless steel rose gold strap secured with a push-button clasp.





Front view of the Titan Purple Analog Gold Dial Women's Watch, showcasing the rose gold dial, studded bezel, and stainless steel strap.

SETUP INSTRUCTIONS

1. Initial Activation

Your watch comes with a pre-installed Lithium Metal battery. In some cases, a small plastic stopper may be present under the crown to preserve battery life during shipping. Gently pull out and remove this stopper if present.

2. Setting the Time

1. Pull the crown (the small knob on the side of the watch case) outwards to the time-setting position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.





Close-up view of the watch dial and crown, illustrating the component used for time adjustment.

3. Adjusting the Strap

The stainless steel strap is designed for comfort. If the strap is too loose or too tight, it may require adjustment by adding or removing links. This procedure typically requires specialized tools and is best performed by a qualified watch technician or an authorized Titan service center to prevent damage to the strap or clasp.



The Titan watch displayed on a wrist, demonstrating how the strap fits.

OPERATING YOUR WATCH

Timekeeping

Your Titan watch is an analog timepiece powered by a Quartz movement, providing accurate time display with hour, minute, and second hands.

Water Resistance

This watch has a water resistance rating of 5 ATM (50 meters). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water, such as washing hands. It is **not** suitable for swimming, diving, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

CARE AND MAINTENANCE

Cleaning Your Watch

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt.
- For stainless steel parts, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish and seals.

Battery Replacement

The watch is powered by a Lithium Metal battery. When the watch stops or its movement becomes erratic, it indicates that the battery needs replacement. Battery replacement should be performed by an authorized Titan service center or a qualified watch technician to ensure proper sealing and maintain water resistance.

General Care

- Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes.
- Keep the watch away from strong magnetic fields, as these can affect the accuracy of the Quartz movement.

- Protect the watch from impacts and drops.

TROUBLESHOOTING

Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in against the watch case. If it is pulled out, the watch will not run.
- **Battery:** The battery may be depleted. Contact an authorized service center for battery replacement.

Inaccurate Time


- **Magnetic Fields:** Exposure to strong magnetic fields can affect accuracy. If suspected, keep the watch away from such sources.
- **Battery:** A low battery can sometimes cause irregular timekeeping.
- **Service:** If accuracy issues persist, the watch may require inspection by an authorized service center.

Water Inside the Watch

If you notice condensation or water droplets inside the watch, immediately take it to an authorized Titan service center. Do not attempt to open the watch yourself, as this can cause further damage and void the warranty.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Titan
Model Name/Number	NQ9955WM01/NP9955WM01
Display Type	Analog
Movement Type	Quartz
Case Diameter	45.6 Millimetres
Case Thickness	7.45 Millimetres
Band Material	Stainless Steel
Band Colour	Gold
Dial Colour	Gold
Water Resistance Depth	50 Metres (5 ATM)
Power Source Type	Battery Powered (1 Lithium Metal battery included)
Item Weight	45 Grams
Crystal Material	Mineral
Clasp Type	Deployment Clasp / Push-Button
Manufacturer	Titan



Visual representation of the watch's size, compared to common objects like a 10 Rupee coin and a credit card, indicating a case diameter of 39mm.

WARRANTY INFORMATION

This Titan watch comes with a **24-month manufacturer warranty** covering manufacturing defects from the date of purchase.

How to Avail Warranty:

To avail warranty services, you only need to present your original purchase invoice at any authorized Titan Service Center. A separate warranty card is not required.

CUSTOMER SUPPORT

For further details, service-related queries, or assistance, please contact Titan customer support:

- **Toll-Free Number:** 1800-266-0123 (Available 10 AM to 7 PM, all days of the week)
- **Email:** customercare@titan.co.in



The watch is typically packaged in a branded Titan box, as shown.

© 2023 Titan. All rights reserved.