

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Avital](#) /
- › [Avital EZSDEI474S 4-Button Keyless Entry Remote Alarm System User Manual](#)

### Avital EZSDEI474S

# Avital EZSDEI474S 4-Button Keyless Entry Remote User Manual

Model: EZSDEI474S

## 1. INTRODUCTION

This manual provides instructions for the Avital EZSDEI474S 4-button keyless entry remote. This device is designed to control your vehicle's alarm and keyless entry system, offering convenience and security.

### 1.1 Product Overview



The image above displays the Avital EZSDEI474S key fob. It features a black casing with four distinct green buttons. These buttons are typically used for locking, unlocking, remote start or trunk release, and an auxiliary or panic function.

### 1.2 Compatibility

This remote is compatible with specific Avital alarm systems and vehicles. To ensure proper function, verify compatibility using the OEM part number EZSDEI474S or manufacturer part number AVITAL EZSDEI474S 474L 4BTN. Consult your vehicle's documentation or the alarm system's manual for specific compatibility details.

## 2. PROGRAMMING INSTRUCTIONS

Programming this key fob to your vehicle's system is required for operation. The process typically involves placing your vehicle's alarm system into a programming mode. Due to variations in vehicle models and alarm systems, specific steps may differ.

### 2.1 General Programming Steps

1. Locate your vehicle's alarm system programming button or switch. This is often found near the fuse box, under the dashboard, or directly on the alarm control module.
2. Turn the vehicle's ignition to the **ON** position (do not start the engine).
3. Press and release the programming button a specific number of times, or hold it down, as indicated by your vehicle's or alarm system's specific instructions. The system may respond with a chirp or light flash to confirm entry into programming mode.
4. Press a button on the new Avital EZSDEI474S key fob. The system should respond with a confirmation chirp or light flash, indicating successful programming.
5. Turn the ignition **OFF** to exit programming mode.

**Important:** These are general guidelines. Specific programming steps vary significantly by vehicle make, model, and the installed alarm system. For precise instructions, consult your vehicle's owner's manual, the Avital alarm system manual, or search for vehicle-specific programming guides online (e.g., on YouTube). Professional installation or programming by a qualified technician is recommended if you encounter difficulties.

### 3. KEY FOB OPERATION

The Avital EZSDEI474S key fob features four distinct buttons for controlling your vehicle's functions:

- **Lock Button (Closed Padlock Symbol):** Press this button to lock your vehicle's doors and arm the alarm system.
- **Unlock Button (Open Padlock Symbol):** Press this button to unlock your vehicle's doors and disarm the alarm system.
- **Remote Start / Trunk Release Button (Car with Open Trunk Symbol):** This button typically activates the remote engine start function or opens the vehicle's trunk/hatch. The exact functionality may vary based on your installed alarm system's configuration.
- **Auxiliary / Panic Button (Star/Asterisk Symbol):** This button often serves as a panic alarm (press and hold for several seconds) or an auxiliary function, depending on how your system is configured.

**Note:** For some functions, you may need to press and hold the button for approximately 1-2 seconds to activate.

### 4. MAINTENANCE

#### 4.1 Battery Replacement

The Avital EZSDEI474S key fob is powered by one CR2 battery. If the remote's operational range decreases significantly or it stops responding, the battery may need replacement.

##### Steps for Battery Replacement:

1. Carefully separate the two halves of the key fob casing. A small, flat-head screwdriver can be used to gently pry them apart at the seam.
2. Locate the CR2 battery inside the casing.
3. Remove the old battery, carefully noting its orientation (+/- terminals).
4. Insert a new CR2 battery, ensuring it is correctly oriented according to the markings inside the casing.
5. Snap the two halves of the key fob casing back together until securely closed.

**Caution:** Ensure proper battery polarity during installation. Dispose of old batteries responsibly according to local regulations.

## 5. TROUBLESHOOTING

If your Avital EZSDEI474S key fob is not functioning as expected, consider the following common issues and solutions:

- **Remote Not Responding:**
  - Check the battery. Replace it if necessary (refer to Section 4.1 Battery Replacement).
  - Ensure you are within the operational range of the system (approximately 30-50 feet).
  - Verify the remote is correctly programmed to your vehicle's system. Reprogramming may be required (refer to Section 2. Programming Instructions).
- **Reduced Range:**
  - This often indicates a low battery. Replace the CR2 battery.
  - Environmental interference (e.g., strong radio signals, large metal structures) can also affect range.
- **Difficulty Programming:**
  - Review the programming instructions carefully, ensuring all steps are followed precisely.
  - Confirm the key fob is compatible with your specific alarm system and vehicle.
  - Seek assistance from a professional automotive technician or consult online resources (e.g., YouTube tutorials for your specific vehicle/alarm model).

If problems persist after attempting these steps, contact Avital customer support or a certified installer for further assistance.

## 6. PRODUCT SPECIFICATIONS

Feature	Detail
Model	EZSDEI474S
Brand	Avital
Buttons	4
Battery Type	1 x CR2 (included)
Approximate Range	30-50 feet
Item Weight	0.634 ounces
Package Dimensions	4.5 x 3.9 x 0.3 inches
OEM Part Number	EZSDEI474S, 4BTN
Manufacturer Part Number	AVITAL EZSDEI474S 474L 4BTN
Compatible Devices	Cars, Trucks






## 7. WARRANTY AND SUPPORT

For warranty information regarding your Avital EZSDEI474S key fob, please refer to the documentation

provided with your original purchase or contact Avital customer service directly.


For technical support or further assistance, visit the official Avital website or consult with an authorized Avital dealer. Many users also find helpful programming videos and guides on platforms like YouTube by searching for "Avital EZSDEI474S programming" or "[Your Vehicle Make/Model] key fob programming."

## Related Documents - EZSDEI474S

	<p><a href="#">Avital 5105L Remote Start and Security System Owner's Guide</a></p> <p>Comprehensive owner's guide for the Avital 5105L Remote Start and Security System with 1-Way Remote, detailing features, operation, and important safety information.</p>
	<p><a href="#">Avital 7353L Remote Control User Guide</a></p> <p>This document provides information on the Avital 7353L remote control, including its features, functions, and government regulations.</p>
	<p><a href="#">AVITAL D9858L Owner's Guide - Remote Start System</a></p> <p>Comprehensive owner's guide for the AVITAL D9858L remote start system, detailing features, commands, configuration, and safety information.</p>
	<p><a href="#">Avital 3300L Keyless Entry System Owner's Guide</a></p> <p>This owner's guide provides comprehensive details for the Avital 3300L Keyless Entry System, a product of Directed Electronics, covering its features, operation, and maintenance for enhanced vehicle security.</p>
	<p><a href="#">AVITAL Model D9147L Owner's Guide: Remote Start and Security System</a></p> <p>Comprehensive owner's guide for the AVITAL Model D9147L remote start and security system, covering installation, operation, features, commands, safety, and warranty information.</p>



Comprehensive owner's guide for the Avital 2101L vehicle security system by Directed. Learn about installation, features, operation, programming, and warranty.




[\[pdf\]](#) User Manual Owner's Manual Instructions

Product Access 1 Alarm Audio 7143L PAIR Programming instructions are included in the package and will require accessing your valet programming switch Video be available on our product 1114 access1alarm component eshop id |||

Access 1 Alarm and Audio - 10418 Lorain Ave Cleveland, OH 44111 7143L PAIR  
Phone: 216 252-3000 - Email: sales.access1alarm.com Brand: Avital Product Code: 7143L-PAIR Availability: In Stock UPC: 093207094880 FCC ID: **EZSDEI474S** MPN: Avital 7143L Location: Cleveland, Ohio Price: 59.99 Short Desc...

lang:en score:34 filesize: 175.01 K page\_count: 3 document date: 2025-07-18




[\[pdf\]](#) Instructions

Product Access 1 Alarm Audio Price \$39 99 AudioMPN Avital 7143L Location Cleveland Ohio Short  
Brand NEW Way 4 Button Remote Control Replacement Transmitterproduct 374access1alarm  
component eshop product id 374 |||

Access 1 Alarm and Audio - 10418 Lorain Ave Cleveland, OH 44111 7143L Phone: 216 252-3000 - Email: sales.access1alarm.com Brand: Avital Product Code: 7143L Availability: In Stock UPC: 093207094880 FCC ID: **EZSDEI474S** MPN: Avital 7143L Location: Cleveland, Ohio Price: 39.99 Short Description Av...

lang:en score:27 filesize: 156.83 K page\_count: 3 document date: 2025-09-10



[\[pdf\]](#) Instructions

Product Access 1 Alarm Audio 474T Brand NEW Directed Way 4 Button Remote Control Replacement Transmitter Looking for a replacement remote control your system or just need product 1415  
access1alarm component eshop id |||

Access 1 Alarm and Audio - 10418 Lorain Ave Cleveland, OH 44111 474T Phone:  
216 252-3000 - Email: sales.access1alarm.com Brand: Directed Product Code: 474T  
Availability: In Stock UPC: 93207004742 FCC ID: EZSDEI474 MPN: 474T Location:  
Cleveland, Ohio Price: 49.99 Short Description 1-Way 4-Butt...

lang:en score:20 filesize: 194.3 K page\_count: 3 document date: 2025-07-28