

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Everbilt](#) /
- › [Everbilt Movealls Reuse Furniture Movers \(8-Pack\) Instruction Manual](#)

## Everbilt 83036N12

# Everbilt Movealls Reuse Furniture Movers (8-Pack) Instruction Manual

### INTRODUCTION

The Everbilt Movealls Reuse Furniture Movers are designed to simplify the process of moving heavy furniture and appliances across carpeted surfaces. This 8-pack provides a convenient solution for rearranging rooms, cleaning, or relocating items without straining your back or damaging your floors. Each mover is engineered to allow smooth gliding, making heavy lifting unnecessary.

### SAFETY INFORMATION

- **Surface Compatibility:** These furniture movers are specifically designed for use on *carpeted surfaces only*. Using them on hard floors (wood, tile, laminate) may cause damage to the floor or the movers.
- **Load Limit:** Do not exceed the maximum load limit of 1,000 lbs (453.5 kg) for the entire set. Distribute weight evenly among all movers.
- **Placement:** Always ensure that the furniture legs or base are centered securely on the foam pad of each mover to prevent slipping.
- **Personal Safety:** Exercise caution when lifting furniture to place movers. For very heavy or awkward items, seek assistance from another person to prevent injury.
- **Obstacles:** Clear the path of any obstacles, cords, or rugs before moving furniture to ensure a smooth and safe transition.

### PACKAGE CONTENTS

- 8 x Everbilt Movealls Reuse Furniture Movers

### SETUP

1. **Prepare the Furniture:** Ensure the furniture item is stable and clear of any loose items on top or inside.
2. **Lift and Place:** Carefully lift one corner or leg of the furniture item. If the item is too heavy to lift alone, enlist the help of another person or use a lifting tool.
3. **Position the Mover:** Place an Everbilt Movealls furniture mover, with the *black foam side facing upwards*, directly under the lifted furniture leg or corner. Ensure the leg is centered on the foam pad for maximum stability.

4. **Repeat:** Repeat steps 2 and 3 for all remaining legs or corners of the furniture item. For items with a solid base, distribute the movers evenly underneath.






Image: Everbilt Movealls in packaging, highlighting their intended use for carpet only. The black foam side should face up towards the furniture.

## OPERATING INSTRUCTIONS

1. **Verify Placement:** Before moving, double-check that all movers are securely in place under the furniture legs/base and that the furniture is stable.
2. **Clear the Path:** Ensure the area where you intend to move the furniture is clear of any obstructions, including other furniture, rugs, or electrical cords.
3. **Gentle Movement:** Once ready, gently push the furniture in the desired direction. The movers are designed to glide smoothly across carpet.
4. **Controlled Motion:** Move the furniture slowly and steadily. Avoid sudden jerks or rapid movements, which could cause the furniture to shift or fall off the movers.
5. **Guidance for Large Items:** For larger or heavier items, it is recommended to have two people: one to push and another to guide the furniture, ensuring it moves in a straight line and avoids collisions.
6. **Removal:** Once the furniture is in its new position, carefully lift each corner or leg and remove the movers.



Image: The Everbilt Movealls Reuse Furniture Movers, showing the complete 8-pack. These movers facilitate easy relocation of furniture on carpet.

## MAINTENANCE

- **Cleaning:** If the movers become dirty, wipe them clean with a damp cloth. Avoid harsh chemicals that could damage the materials.
- **Storage:** Store the movers in a dry place when not in use to prolong their lifespan.

- **Inspection:** Before each use, inspect the foam pads and plastic bases for any signs of wear, tears, or damage. Replace any movers that are significantly worn or damaged to ensure optimal performance and safety.

## TROUBLESHOOTING

Issue	Solution
Furniture not sliding smoothly.	Ensure the movers are placed with the black foam side facing up towards the furniture. Check for any debris (e.g., carpet fibers, small objects) under the movers that might impede gliding. Verify the surface is indeed carpet.
Furniture slipping off the movers.	Confirm that the furniture legs or base are centered securely on the foam pads. If the load is too heavy or unevenly distributed, it may cause instability. Reduce the load if it exceeds the specified weight limit.
Mover appears damaged after use.	Inspect the mover for cracks in the plastic or significant wear on the foam. If damaged, discontinue use and replace the mover to ensure safety and prevent potential floor damage.

## SPECIFICATIONS

Feature	Detail
Brand	Everbilt
Model Number	83036N12
UPC	848228030368
Material	Plastic, Rubber, Felt
Shape	Round
Surface Recommendation	Carpet
Load Limit	Up to 1,000 lbs (453.5 kg)
Item Package Quantity	8
Item Weight	12.8 ounces (0.8 Pounds)
Color	White (base), Black (foam)

## WARRANTY AND SUPPORT

For product support, warranty information, or to inquire about replacement parts, please contact Everbilt customer service directly. Refer to your purchase receipt for specific warranty terms and conditions, as these may vary.

