#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Behringer /
- > Behringer X32 Rack Digital Mixer Audio Mixing Console User Manual

# **Behringer X32RACK**

# Behringer X32 Rack Digital Mixer Audio Mixing Console User Manual

Model: X32RACK | Brand: Behringer

#### **INTRODUCTION**

The Behringer X32 Rack Digital Mixer is a 40-input channel, 25-bus, 3U rack-mountable digital mixer designed for live and installed sound applications. This manual provides essential information for setting up, operating, and maintaining your X32 Rack to ensure optimal performance and longevity.

Key features include:

- 25-bus Digital Rack Mixer with 16 Gain-programmable Preamps
- iPad/iPhone Remote Control
- USB Audio Interface
- 40-input Channel
- Virtual FX Rack

# **PRODUCT OVERVIEW**



**Figure 1: Front Panel View.** This image displays the front panel of the Behringer X32 Rack, highlighting the main display, control knobs, USB port, and various input/output indicators.



Figure 2: Rear Panel View. This image shows the rear panel of the Behringer X32 Rack, detailing the XLR inputs and outputs, auxiliary inputs/outputs, expansion slot for USB audio interface, and network connections.

# **SETUP**

# 1. Unpacking and Inspection

Carefully unpack your Behringer X32 Rack and inspect it for any signs of damage during transit. Ensure all components listed in the packing list are present. Keep the original packaging for future transport or storage.

# 2. Rack Mounting

The X32 Rack is designed for 3U rack-mounting. Securely fasten the unit into a standard 19-inch equipment rack using appropriate rack screws. Ensure adequate ventilation around the unit to prevent overheating.

#### 3. Power Connection

Connect the supplied power cable to the AC input on the rear panel of the X32 Rack and then to a suitable power outlet. Ensure the power switch is in the OFF position before connecting.

#### 4. Audio Connections

The X32 Rack features 16 gain-programmable Midas-designed preamps for inputs and 8 XLR outputs, plus 6 additional line in/outputs. Connect your microphones, instruments, and other audio sources to the appropriate XLR or 1/4-inch inputs. Connect your main speakers or monitoring systems to the XLR outputs.

#### 5. USB Audio Interface Setup

The unit includes a 32-channel USB 2.0 audio interface. Connect a USB cable from the X32 Rack's USB port to your computer for multi-track recording and playback. Install the necessary drivers from the Behringer website if required by your operating system.

#### 6. Network and Remote Control Setup

For remote control via iPad or iPhone, connect the X32 Rack to a wireless router via its Ethernet port. Download the Behringer X32-Mix app from your device's app store. Ensure your iPad/iPhone is connected to the same Wi-Fi network as the X32 Rack. The app allows for comprehensive control over all mixer functions.

Your browser does not support the video tag.

**Video 1: Product Summary.** This video provides a concise overview of the Behringer X32 Rack, demonstrating its physical features, connectivity options, and remote control capabilities, which are essential for initial setup and understanding the product's core functionalities.

## **OPERATING INSTRUCTIONS**

## 1. Powering On

Once all connections are secure, switch the power button on the front panel to the ON position. The unit will boot up, and the 5-inch color TFT display will become active.

# 2. Navigating the Interface

The X32 Rack features a high-contrast 5-inch color TFT display for intuitive operation. Use the dedicated buttons (HOME, METERS, ROUTING, LIBRARY, EFFECTS, SETUP, MONITOR, SCENES, MUTE GRP, UTILITY) and the rotary encoders with push functionality to navigate through menus and adjust parameters. The display provides visual feedback for all settings, including channel levels, EQ curves, and effects parameters.

#### 3. Channel Control

Adjust individual channel levels using the dedicated CHANNEL LEVEL rotary encoder. Use the SOLO and MUTE buttons for quick control over specific channels. The LED meters provide visual indication of input and output levels, helping to prevent clipping.

#### 4. Virtual FX Rack

The Virtual FX Rack offers a wide array of digital effects, with over 50 onboard FX plugins. Access the FX Rack via the EFFECTS button and navigate the display to select, configure, and apply various effects such as reverb, delay, chorus, and dynamics processing to your audio channels or buses.

## 5. Saving and Recalling Scenes

The X32 Rack allows you to save and recall complete mixer configurations as "scenes." This feature is invaluable for quickly switching between different setups for various performances or events. Use the SCENES button to manage your saved configurations.

#### MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Behringer X32 Rack.

- Cleaning: Use a soft, dry cloth to clean the exterior of the unit. For the display, use a microfiber cloth specifically designed for electronics. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure that the ventilation slots are clear of dust and debris. Proper airflow is crucial to prevent overheating.
- **Connections:** Periodically check all cable connections for secure fit and signs of wear. Loose connections can lead to signal loss or noise.
- **Software Updates:** Check the Behringer website regularly for firmware updates. Keeping your mixer's firmware up-to-date can provide new features, performance improvements, and bug fixes.

## **T**ROUBLESHOOTING

If you encounter issues with your Behringer X32 Rack, try the following basic troubleshooting steps:

- No Power: Check the power cable connection and the power outlet. Ensure the power switch is fully engaged.
- No Audio Output: Verify all audio cables are correctly connected. Check channel levels, mute statuses, and main output levels. Ensure the correct input routing is selected.
- No Remote Control Connection: Confirm the X32 Rack and your control device (iPad/iPhone) are on the

same Wi-Fi network. Restart both the mixer and the control app. Check network settings on the mixer.

• **Distorted Audio:** Check input gain levels to ensure they are not clipping (indicated by red CLIP LEDs). Verify output levels are not overdriving connected amplifiers or speakers.

For more detailed troubleshooting or complex issues, refer to the comprehensive user manual available for download from the Behringer website or contact Behringer customer support.

## **SPECIFICATIONS**

Feature	Specification
Item Weight	10 pounds
Product Dimensions	14.25 x 21.55 x 7.7 inches
ASIN	B00GA41EXC
Item model number	X32RACK
Color Name	Black
Hardware Interface	USB
Power Source	Corded Electric
Standing screen display size	5 inches
Wattage	120 watts
Brand	Behringer
Number of Channels	40
Connectivity Technology	USB

## WARRANTY AND SUPPORT

The Behringer X32 Rack Digital Mixer comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support, service, or to download the full user manual, visit the official Behringer website or contact their customer service department.

You can also find the User Manual (PDF)here.

#### **Related Documents - X32RACK**



#### Behringer X32 Digital Mixing Console Quick Start Guide

Get started quickly with the Behringer X32 digital mixing console. This guide provides an overview of basic operations, features, and setup for the X32, including its 40 inputs, 32 Midas preamps, and extensive connectivity for professional audio applications.



#### Behringer WING Digital Mixing Console Quick Start Guide

A quick start guide for the Behringer WING 48-Channel, 28-Bus Full Stereo Digital Mixing Console with 24-Fader Control Surface and 10" Touch Screen, covering setup, features, and specifications.



#### Behringer X32 Digital Mixer: Quick Start Guide for Professional Audio Production

Discover the Behringer X32 digital mixing console with this quick start guide. Learn about its 40 inputs, 25 buses, 32 MIDAS preamps, motorized faders, channel LCDs, 32-channel audio interface, and remote control capabilities for live sound and studio environments.



#### Behringer WING Quick Start Guide: 48-Channel Digital Mixing Console

A concise guide to the Behringer WING digital mixing console, covering its features, hardware, main screens, patching, setup, safety instructions, and firmware updates. Learn about its 48 channels, 10-inch touchscreen, flexible routing, and professional audio capabilities.



#### Behringer X32 Digital Mixer User Manual

Explore the capabilities of the Behringer X32 Digital Mixing Console with this comprehensive user manual. Learn about its 40 inputs, 32 MIDAS preamps, motorized faders, USB audio interface, digital effects, and remote control options for live sound and studio environments.



## Behringer X32 COMPACT DIGITAL MIXER Quick Start Guide

This guide provides an overview of the basic operations of the Behringer X32 COMPACT digital mixing console, enabling users to get started quickly. It covers interface operation, channel strip details, input channel banks, the main display area, group/bus channel banks, and various assignments.