

[Manuals.plus](#) /

› [TECKNET](#) /

› TECKNET Wireless Mouse Instruction Manual

TECKNET EWM01002

TECKNET Wireless Mouse Instruction Manual

Model: EWM01002

INTRODUCTION

Thank you for choosing the TECKNET Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your new mouse. Designed for comfort and efficiency, this mouse offers advanced features to enhance your computing experience. Please read this manual thoroughly before use to ensure proper functionality and longevity of your device.

KEY FEATURES

- **6-Level Adjustable DPI:** Customize sensitivity with 800/1200/1600/2400/3200/4800 DPI settings for precise tracking.
- **Extended Battery Life:** Enjoy up to 30 months of use with just two AA batteries (not included), thanks to upgraded independent power switches and sleep modes.
- **Plug & Play Connectivity:** Simple setup with a 2.4G USB receiver, offering a 50ft/15m wireless range without the need for driver installation.
- **Ergonomic Design:** Streamlined curved design with non-slip rubber sides and a sculpted palm rest for comfortable, long-term use.
- **Wide Compatibility:** Compatible with Windows XP, Vista, 11/10/8/7, Chromebook, Mac OS, and Linux systems.
- **6-Button Functionality:** Includes standard left/right click, scroll wheel, DPI switch, and convenient forward/back buttons.

SETUP GUIDE

1. Battery Installation

The TECKNET Wireless Mouse requires two AA batteries (not included). To install:

1. Locate the battery compartment cover on the underside of the mouse.
2. Gently slide the cover off to reveal the battery slots.
3. Insert two AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.




Image: Underside of the mouse showing battery compartment and USB receiver storage.

2. Connecting the USB Receiver

The mouse uses a tiny USB receiver for wireless connectivity.

1. The USB receiver is stored inside the battery compartment for convenience. Remove it from its slot.
2. Plug the USB receiver into an available USB port on your computer (PC, Chromebook, Mac, or Linux device).
3. Turn on the mouse using the ON/OFF switch located on the underside of the mouse.
4. Your computer should automatically detect and install the necessary drivers. The mouse is ready for use once detected.

2.4GHz Stable and Powerful Wireless Connection



2.4G



15M



Image: Wireless mouse connected via USB receiver to a laptop, demonstrating its 2.4GHz stable connection.

OPERATING YOUR MOUSE

The TECKNET Wireless Mouse features 6 buttons for versatile control:

- **Left Button:** Standard click function.
- **Right Button:** Standard right-click function.
- **Anti-slip Scroller (Scroll Wheel):** Scroll up or down through documents and web pages. Can also be clicked for middle-click functionality.
- **DPI Switch:** Located below the scroll wheel. Press to cycle through 6 adjustable DPI levels (800/1200/1600/2400/3200/4800) to change cursor sensitivity. A light indicator will flash to show the current DPI setting.
- **Forward Button:** Located on the left side, typically used for navigating forward in web browsers or file explorers.
- **Back Button:** Located on the left side, typically used for navigating backward in web browsers or file explorers.



Image: Detailed view of the mouse with labels for each button.

Adjusting DPI Sensitivity

Press the DPI switch button to instantly change the cursor speed and precision. Each press cycles to the next DPI level, allowing you to adapt to different tasks, from precise graphic design to fast-paced gaming.

6-Level Adjustable DPI

High-precision sensor & Higher productivity




Image: Visual representation of DPI settings and their impact on cursor movement.

MAINTENANCE

Battery Replacement

The mouse is designed for long battery life (up to 30 months). When the mouse's performance degrades or the light indicator (if present) signals low battery, replace the two AA batteries following the installation steps in the Setup Guide.

30 Months Extra-Long Battery Life



Auto sleep



2 AA batteries



Image: Illustration of the mouse's internal battery placement and extended battery life.

Cleaning

To maintain optimal performance, regularly clean your mouse:

- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Wipe down the exterior of the mouse.
- For the optical sensor on the bottom, use a dry cotton swab to gently remove any dust or debris.
- Ensure the mouse is turned off before cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Mouse not responding	Low battery; USB receiver disconnected; Mouse turned off.	Replace batteries; Re-insert USB receiver; Turn on mouse.
Cursor erratic or not moving smoothly	Dirty optical sensor; Unsuitable surface; Low battery.	Clean optical sensor; Use on a mouse pad or smooth, non-reflective surface; Replace batteries.
Wireless connection issues	Interference; Receiver too far from mouse.	Move mouse closer to receiver; Avoid placing near other wireless devices; Re-pair if necessary (though typically plug-and-play).
DPI setting not changing	DPI button malfunction.	Ensure button is pressed firmly; If issue persists, contact support.

SPECIFICATIONS

- Brand:** TECKNET
- Model Number:** EWM01002
- Product Dimensions:** 2.56 x 1.63 x 4.13 inches
- Item Weight:** 2.93 ounces
- Connectivity Technology:** USB (2.4G Wireless)
- Movement Detection Technology:** Optical
- DPI Levels:** 800/1200/1600/2400/3200/4800
- Buttons:** 6
- Battery Type:** 2 AA batteries (not included)
- Estimated Battery Life:** Up to 30 months
- Wireless Range:** Up to 50ft / 15m
- First Available Date:** January 24, 2014

WARRANTY AND SUPPORT

TECKNET products are designed for reliability and performance. For detailed warranty information and customer support, please refer to the official TECKNET website or the user manual PDF provided with your purchase. You can also find additional support and a downloadable PDF version of the user manual[here](#).