

Salter 1053WH

Salter Ultra-Thin Oval Scale 1053WH - Instruction Manual

Your guide to setting up, operating, and maintaining your Salter kitchen scale.

1. INTRODUCTION

Thank you for choosing the Salter Ultra-Thin Oval Scale 1053WH. This precision kitchen scale is designed for accurate measurement of ingredients up to 5 kilograms. Its ultra-thin glass design makes it a sleek and practical addition to any kitchen.

Please read this instruction manual carefully before using your scale to ensure proper operation and longevity.

2. SETUP

2.1 Battery Installation

Your scale requires 1 Lithium Ion battery, which is included. To install or replace the battery:

1. Turn the scale over to access the battery compartment on the underside.
2. Open the battery compartment cover.
3. Insert the Lithium Ion battery, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

2.2 Initial Placement

Place the scale on a firm, flat, and level surface. Avoid placing it on soft or uneven surfaces, as this may affect accuracy. Keep the scale away from strong electromagnetic fields or extreme temperature changes.



Image: The Salter Ultra-Thin Oval Scale 1053WH, a white oval-shaped kitchen scale with a digital display and an "on/off tare" button. This image shows the top view of the scale, highlighting its sleek design and compact form factor.

3. OPERATING INSTRUCTIONS

3.1 Turning On/Off

- To turn on the scale, press the "on/off tare" button. The display will show "0" or "0.0" when ready for use.
- To turn off the scale, press and hold the "on/off tare" button for a few seconds until the display turns off. The scale will also automatically turn off after a period of inactivity to conserve battery life.

3.2 Weighing Items

1. Ensure the scale is on a flat, stable surface and turned on.
2. Place the item to be weighed directly onto the center of the scale platform.
3. Read the weight displayed on the digital screen.

3.3 Tare Function (Add & Weigh)

The tare function allows you to weigh multiple ingredients in the same bowl or to subtract the weight of a container.

1. Place your empty container (e.g., bowl) onto the scale. The display will show its weight.
2. Press the "on/off tare" button. The display will reset to "0" or "0.0".
3. Add your first ingredient to the container. The display will show the weight of only that ingredient.
4. To add another ingredient, press the "on/off tare" button again to reset the display to "0" before adding the next item. Repeat as needed.

3.4 Unit Conversion

The scale may offer different units of measurement (e.g., grams, pounds, ounces). Look for a "UNIT" or "g/oz" button, usually on the underside or near the display, to cycle through available units. (Note: Specific button location may vary slightly; refer to the scale itself.)

4. MAINTENANCE

4.1 Cleaning

To clean your scale, wipe the surface with a damp cloth and mild detergent. Do not immerse the scale in water or use abrasive cleaning agents, as this can damage the electronic components.

4.2 Storage

Store the scale in a dry place at room temperature. Avoid storing heavy objects on top of the scale, as this can damage the weighing mechanism.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display shows "Lo" or "Err"	Low battery or overload.	Replace the battery. If "Err" persists, remove item to ensure it's within the 5kg limit.
Inaccurate readings	Scale not on a flat surface, movement during weighing, or extreme temperature changes.	Ensure scale is on a stable, level surface. Avoid movement. Allow scale to acclimatize to room temperature.
Scale does not turn on	Battery incorrectly installed or completely drained.	Check battery polarity. Replace battery if necessary.

6. SPECIFICATIONS

- Model: 1053WH
- Brand: Salter
- Type: Ultra-Thin Glass Kitchen Scale
- Weight Limit: 5 Kilograms (11 lbs)
- Material: Glass
- Power Source: 1 x Lithium Ion battery (included)
- Product Dimensions: 2.79 x 24.89 x 19.81 cm (1.1 x 9.8 x 7.8 inches)
- Item Weight: Approximately 453.59 g (1 Pound)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question