Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM A2-0059

HOMCOM Faux Leather Heated Massage Recliner Chair (Model A2-0059) User Manual

Your comprehensive guide to assembly, operation, and maintenance.

1. Introduction

Thank you for choosing the HOMCOM Faux Leather Heated Massage Recliner Chair. This manual provides essential information for the safe and effective use of your new chair. Please read all instructions carefully before assembly and operation, and retain this manual for future reference.



Image 1.1: The HOMCOM Faux Leather Heated Massage Recliner Chair.

2. Safety Instructions

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Keep children and pets away from the chair during assembly and operation, especially when reclining or adjusting.
- Place the chair on a level, stable surface.
- Do not expose the chair to direct sunlight or extreme temperatures.
- Avoid spilling liquids on the chair, especially near electrical components.
- Only use the provided power adapter. Disconnect power before cleaning or if the chair will not be used for an extended period.
- Do not stand on the chair or use it as a step stool.
- Maximum weight capacity: 330 lbs (150 kg). Do not exceed this limit.

- Consult a physician before using the massage or heating functions if you have any medical conditions.

3. Package Contents

Verify that all the following components are included in your package:

- Recliner Base
- Backrest
- Remote Control
- Power Adapter
- Instruction Manual (this document)

4. Setup and Assembly

Assembly of your HOMCOM recliner chair is straightforward and typically requires two main steps:

1. **Attach the Backrest:** Carefully align the backrest with the mounting brackets on the recliner base. Slide the backrest down firmly until it locks securely into place. You should hear a click or feel it settle firmly.
2. **Connect Electrical Wires:** Locate the electrical wires extending from the backrest and the base. Connect the corresponding wires. There are typically four wires: two color-coded (e.g., red and white) for the massage/heat functions, one large plug for the remote control, and one for the main power supply. Ensure all connections are snug.



Image 4.1: Chair dimensions in upright and reclined states. Ensure adequate space for reclining.



Image 4.2: Side pocket and cup holder detail. The remote can be stored in the side pocket.

5. Operating Instructions

Your HOMCOM recliner chair offers multiple comfort features controlled by the attached remote.

5.1 Reclining Function

To recline the chair, locate the lever on the side of the chair (typically on the right side). Pull the lever to release the footrest and lean back to your desired angle. To return to the upright position, push the footrest down with your legs and lean forward until the backrest locks into place.



Image 5.1: Reclining the chair. Pull the side lever to extend the footrest and recline.

5.2 Massage and Heating Functions

The chair features eight vibration massage motors targeting four zones (upper back, lower back, thighs, and calves) and a heating function in the lumbar area. These functions are controlled via the remote control.




Image 5.2: Overview of chair features including massage points and heating area.



Image 5.3: Remote Control Layout.

Remote Control Functions:

- **POWER Button:** Press to turn the massage function ON or OFF.
- **HEAT Button:** Press to activate or deactivate the lumbar heating function.
- **INTENSITY (HIGH/LOW):** Adjusts the vibration intensity between high and low settings.
- **MODE Button:** Cycles through five preset massage modes (PULSE, PRESS, WAVE, AUTO, NORMAL).
- **Massage Zone Buttons (BACK, LUMBAR, THIGH, LEG):** Select specific areas for massage. You can activate multiple zones simultaneously.
- **TIMER (15Min, 30Min, 60Min):** Sets the duration of the massage session.

5.3 Swivel and Rocking Functions

The chair is designed to swivel 360 degrees on its base, allowing for easy rotation. It also features a gentle rocking motion for added relaxation.

6. Maintenance

Proper care will extend the life and appearance of your recliner chair.

- **Cleaning:** For faux leather, wipe with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Inspection:** Periodically check all connections and moving parts for tightness and wear. Tighten any loose screws.
- **Power Cord:** Inspect the power cord for any damage. If damaged, discontinue use and contact customer support.

7. Troubleshooting

Problem	Possible Cause	Solution
Chair does not power on / Massage or heat not working.	Power cord not properly connected. Remote control not connected. Power outlet not functioning.	Ensure power cord is securely plugged into the chair and a working wall outlet. Check the remote control's connection to the chair. Test the outlet with another device.
Reclining mechanism is stiff or not engaging.	Obstruction in the mechanism. Lever not fully engaged.	Check for any objects obstructing the mechanism. Ensure the recline lever is pulled completely. Apply firm, even pressure to recline.
Vibration is weak or inconsistent.	Intensity setting is low. Specific massage zones not selected.	Increase the intensity setting on the remote. Ensure desired massage zones are activated on the remote.

8. Specifications

- **Brand:** HOMCOM
- **Model Name:** Charles
- **Model Number:** A2-0059
- **Color:** Black
- **Material:** Faux Leather, Plastic, Metal, Foam Sponge
- **Overall Dimensions (Upright):** 35"D x 34"W x 31"H
- **Weight Capacity:** 330 lbs
- **Item Weight:** 110 lbs
- **Special Features:** Arm Rest, Cushion Availability, Heated Massage, Recline, Swivel, Rocker, Cup Holders, Side Pockets

9. Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact HOMCOM customer service directly. Keep your proof of purchase for any warranty claims.

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00GHZFYNU

More documents and user manuals: **https://manuals.plus/**