



Manuals.plus /

› [Intex](#) /

› [Intex Comfort Plush Mid Rise Dura-Beam Airbed Instruction Manual - Model 67766](#)

## Intex 67766

# Intex Comfort Plush Mid Rise Dura-Beam Airbed

## INSTRUCTION MANUAL

Model: 67766 | Brand: Intex

		<a href="#">Introduction</a>	<a href="#">Safety Information</a>	<a href="#">Package Contents</a>	<a href="#">Product</a>		
<a href="#">Features</a>	<a href="#">Setup</a>	<a href="#">Operation</a>	<a href="#">Maintenance</a>	<a href="#">Troubleshooting</a>	<a href="#">Specifications</a>	<a href="#">Warranty &amp; Support</a>	

### 1. Introduction

Thank you for choosing the Intex Comfort Plush Mid Rise Dura-Beam Airbed. This airbed is designed to provide enhanced comfort, stability, and support through its Fiber-Tech beam construction. The built-in electric pump ensures quick and easy inflation and deflation. This manual provides essential information for the safe and effective use, setup, and maintenance of your airbed.



Figure 1: Intex Comfort Plush Mid Rise Dura-Beam Airbed, Full size, showing the built-in pump on the side.

## 2. Important Safety Information

---

Please read and understand all safety warnings before using this product. Failure to follow these instructions may result in injury or product damage.

- **Do not over-inflate or under-inflate the air mattress.** Re-inflate as needed to maintain desired firmness.
- Follow the manufacturer's guidelines for proper inflation and deflation to avoid damage or injury.
- Keep the air mattress clean and dry to prevent mold or mildew growth.
- Do not use the air mattress if it is damaged or punctured.
- Always follow the manufacturer's instructions for safe use and storage.
- This product is intended for occasional use and should not be used as a permanent bed.
- Always follow the manufacturer's guidelines to maintain the warranty.

## 3. Package Contents

Verify that all items are present in the package:

- Intex Comfort Plush Mid Rise Dura-Beam Airbed (Full size)
- Built-in Electric Pump
- AC Power Cord
- Duffel Bag for storage and transport

#### 4. Product Features

The Intex Comfort Plush Mid Rise Dura-Beam Airbed offers the following key features:

- **Fiber-Tech Construction:** Engineered with thousands of high-strength polyester fibers for enhanced comfort, stability, and support.
- **Built-in Electric Pump:** High-powered pump for hassle-free inflation and deflation, inflating the mattress in approximately 3 minutes to the desired firmness.
- **Waterproof Flocked Top:** Provides a soft, comfortable sleeping surface.
- **Dura-Beam Technology:** Ensures durability and consistent support.
- **Raised Height:** 13 inches from the floor, making it taller than many inflatable mattresses for easier access.
- **Indented Sides:** Designed to keep fitted sheets from slipping.
- **Duffel Bag:** Included for convenient storage and transport.




Figure 2: Illustration of the unique edge construction, designed to maximize sleeping space and enhance mattress stability.



Figure 3: A cutaway view of the airbed, revealing the internal Fiber-Tech construction with thousands of high-strength polyester fibers for superior support.



Figure 4: Visual comparison demonstrating the superior strength and support of Fiber-Tech construction compared to traditional airbed designs, illustrated with weights.

# Incredible Strength Luxurious Comfort





Figure 5: A kettlebell placed on a Dura-Beam Airbed showing minimal indentation, contrasting with a traditional airbed that shows significant sagging, highlighting enhanced stability.

# Unmatched Support System




Figure 6: A diagram illustrating the difference in support systems, showing how a Dura-Beam Airbed maintains a flat, supportive surface compared to the sagging of a traditional airbed.

## 5. Setup Instructions

### 5.1 Unpacking and Preparation

1. Remove the airbed from its duffel bag and unroll it on a clean, flat surface. Ensure the area is free of sharp objects.
2. Locate the built-in electric pump on the side of the airbed.

### 5.2 Inflation

1. Plug the AC power cord into a standard electrical outlet.
2. Turn the pump switch to the "Inflate" position (usually indicated by an arrow pointing upwards or an "I" symbol).

3. Allow the airbed to inflate until it reaches your desired firmness. This typically takes about 3 minutes. Do not over-inflate.
4. Once inflated, turn the pump switch to the "Off" position and unplug the power cord.

Your browser does not support the video tag.

Video 1: Demonstration of inflating the Intex Comfort Plush Mid Rise Dura-Beam Airbed with its built-in electric pump.

Your browser does not support the video tag.

Video 2: General Intex Airbed Instructional Video, showing the inflation and deflation process.

### 5.3 Initial Stretching and Re-inflation

When an airbed is new, the material will naturally stretch. This may cause the airbed to feel softer or appear to lose air during the first few uses. This is normal and not an indication of a leak.

- Simply re-inflate the bed as needed to achieve your desired firmness.
- Repeat this process for the first 2-3 nights until the material has fully settled and stretched.

Your browser does not support the video tag.

Video 3: Short video explaining that initial pressure loss is due to material stretching, not a leak, and how to re-inflate.

## 6. Operating Instructions

---

Once inflated, your Intex Comfort Plush Mid Rise Dura-Beam Airbed is ready for use. For optimal comfort and longevity:

- Avoid placing the airbed near heat sources or direct sunlight.
- Do not jump on the airbed.
- Distribute weight evenly across the surface.
- Use standard fitted sheets for a more comfortable sleeping experience; the indented sides will help keep them in place.

## 7. Care and Maintenance

---

### 7.1 Cleaning

- Clean the flocked top with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- Ensure the airbed is completely dry before storing to prevent mildew.

### 7.2 Storage

1. To deflate, plug in the power cord and turn the pump switch to the "Deflate" position (usually indicated by an arrow pointing downwards or an "O" symbol).
2. Once fully deflated, fold or roll the airbed neatly.
3. Store the airbed in its provided duffel bag in a cool, dry place, away from extreme temperatures and direct sunlight.

## 8. Troubleshooting

---

### 8.1 Airbed Appears to Lose Air

- **Material Stretching:** New PVC material tends to stretch during the first few uses. This is normal and not a leak. Re-inflate the airbed to desired firmness. This may be necessary for the first 2-3 nights.
- **Temperature Changes:** Air expands and contracts with temperature changes. If the room temperature drops, the airbed may feel softer. Add more air if needed.

## 8.2 Airbed Not Inflating/Deflating

- **Power Connection:** Ensure the power cord is securely plugged into a working electrical outlet.
- **Pump Switch Position:** Verify the pump switch is correctly set to either "Inflate" or "Deflate".
- **Obstructions:** Check the pump's air intake/exhaust for any obstructions.

## 9. Product Specifications

Feature	Detail
Model Number	67766
Size	Full
Product Dimensions (L x W x Th)	75" x 54" x 13"
Material	Polyester, Vinyl
Construction Type	Fiber-Tech
Weight Capacity	600 Pounds
Item Weight	14 Pounds
Special Feature	Flocked Top, Inflatable, Built-in Electric Pump
Water Resistance Level	Waterproof
Included Components	Power Cord, Duffel Bag

## 10. Warranty and Support

This Intex product is manufactured with high-quality materials and workmanship. For specific warranty details and to register your product, please refer to the documentation included in your package or visit the official Intex website. For technical support or assistance with your airbed, please contact Intex customer service.

You can find more information and support at the official Intex store **Intex Store on Amazon**.

