

HOMCOM A2-0054

HOMCOM A2-0054 High Back Vibration Massage Office Chair User Manual

Model: A2-0054

1. INTRODUCTION

Thank you for choosing the HOMCOM A2-0054 High Back Vibration Massage Office Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new office chair. Please read these instructions thoroughly before use and retain them for future reference.



Image 1.1: HOMCOM A2-0054 High Back Vibration Massage Office Chair in Red.

2. SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Follow assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- Do not stand on the chair. Use it only for sitting.
- Do not exceed the maximum weight capacity of 265 lbs (120 kg).
- Keep children and pets away from the chair during assembly and operation.
- Avoid placing the chair near heat sources or in direct sunlight for prolonged periods to prevent material degradation.
- Disconnect the power adapter for the massage and heating functions when not in use or before cleaning.
- Do not attempt to repair or modify the electrical components of the massage function. Contact qualified service personnel if issues arise.

3. PACKAGE CONTENTS

Verify that all parts are included in the package before beginning assembly. Refer to the separate assembly instructions provided with your chair for a detailed list of components and hardware.



Image 3.1: The chair is delivered in one package.

4. ASSEMBLY INSTRUCTIONS

Detailed assembly instructions, including a list of all parts and step-by-step diagrams, are provided in a separate document within your product packaging. Please follow these instructions carefully to ensure proper and safe assembly of your HOMCOM office chair. Assembly typically requires basic tools and can be completed by one person.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

To adjust the chair's height, locate the lever on the right side, beneath the seat. While seated, pull the lever upwards to lower the chair. To raise the chair, stand up slightly to relieve weight from the seat, then pull the lever upwards. Release the lever at the desired height to lock it in place.

HEIGHT ADJUSTABLE



Lift up and down to
adjust height



Image 5.1: Height adjustment lever operation.

5.2. Reclining Function

The chair features a 120-degree reclining function. To recline, push your back against the backrest. The chair will recline smoothly. To return to an upright position, lean forward. The chair does not have a locking recline mechanism; it relies on body weight for position.



Image 5.2: Chair reclining function.

5.3. Vibration Massage and Heating

The chair is equipped with a six-point vibration massage system and a lumbar heating function, controlled by a remote. Connect the chair's power adapter to a suitable electrical outlet. The remote control allows you to:

- **Power On/Off:** Use the power button on the remote.
- **Massage Modes:** Select from various vibration patterns (M1, M2, M3, M4, M5) or an automatic cycle (AUTO).
- **Intensity:** Adjust vibration intensity (Hi/Lo).
- **Target Areas:** Select specific massage zones (BACK, LUMBAR, THIGH).
- **Heat Function:** Activate or deactivate the lumbar heating.
- **Timer:** Set the operating duration (15, 30, or 60 minutes).

Store the remote control in the convenient side pocket when not in use.

VIBRATION MASSAGE

- Six-point
- Heating



Image 5.3: Vibration massage and heating points with remote control.



Image 5.4: Remote control in side pocket.

6. MAINTENANCE

To ensure the longevity and appearance of your HOMCOM office chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the faux leather.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Retighten if necessary.
- **Casters:** Keep casters free of debris to ensure smooth rolling.
- **Storage:** Store the chair in a cool, dry place away from direct sunlight when not in regular use.

7. TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common troubleshooting tips:

- **Chair does not adjust height:** Ensure the height adjustment lever is fully engaged. Check if the gas lift cylinder is damaged.

- **Chair is unstable/wobbly:** Verify that all assembly bolts are securely tightened. Ensure the chair is on a flat, even surface.
- **Massage/Heat function not working:** Check if the power adapter is securely plugged into both the chair and the electrical outlet. Ensure the outlet is functional. Check the remote control batteries.
- **Casters not rolling smoothly:** Inspect casters for hair, dust, or other debris and clean them if necessary.

For persistent issues not resolved by these steps, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	A2-0054
Brand	HOMCOM
Color	Red
Material	Faux Leather, Foam
Overall Dimensions	25.5" W x 28" D x 43.25" - 47.25" H
Seat Dimensions	20.5" W x 19.75" D
Seat Height	17.75" - 21.75" H
Back Style	Cushion Back
Special Features	Adjustable Height, Heated, High Back, Reclining, Rolling, Vibration Massage
Maximum Weight Capacity	265 lbs
Item Weight	39 lbs
UPC	700729271087



Image 8.1: Detailed dimensions of the office chair.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOMCOM customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.