

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Delta Children](#) /

› [Delta Children Deluxe Sweet Beginnings Bedside Bassinet \(Model 25021-138\) Instruction Manual](#)

Delta Children 25021-138

Delta Children Deluxe Sweet Beginnings Bedside Bassinet (Model 25021-138) Instruction Manual

[Introduction](#) [Safety Information](#) [Parts List](#) [Setup & Assembly](#) [Operating Instructions](#) [Maintenance & Care](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Delta Children Deluxe Sweet Beginnings Bedside Bassinet. Please read all instructions carefully before use and retain this manual for future reference. This bassinet is designed to provide a safe and comfortable sleeping environment for newborns.

The Delta Children Deluxe Sweet Beginnings Bassinet features a modern, gender-neutral design with a calming nightlight and soothing music module. It includes a large dual storage basket, a machine washable fitted sheet, a water-resistant mattress pad, and a removable canopy. Equipped with locking wheels, it offers easy room-to-room mobility.



Figure 1: Fully assembled Delta Children Deluxe Sweet Beginnings Bedside Bassinet.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings and the instructions could result in serious injury or death.

- This bassinet is intended for infants from birth up to 5 months of age, or until the infant begins to push up on their hands and knees, whichever comes first. Discontinue use immediately if your infant reaches either of these milestones.
- Always place your baby on their back to sleep.
- To prevent suffocation, never use soft bedding such as quilts, pillows, or comforters in the bassinet. Use only the mattress pad and fitted sheet provided by the manufacturer.
- Ensure all assembly fasteners are tightened securely. Periodically check for loose fasteners, damaged parts, or missing components. Do not use the bassinet if any parts are missing or broken.
- Keep the bassinet away from windows, cords, and any objects that could pose a strangulation hazard.
- Never leave an infant unattended in the bassinet.
- The bassinet requires 4 AA batteries (not included) for the music module and nightlight. Ensure batteries are installed correctly and replaced as needed.

This product is JPMA certified to meet or exceed all safety standards set by the CPSC and ASTM.

3. PARTS LIST

Before assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer service.

- Bassinet Frame (with wheels)
- Bassinet Basket Fabric (with skirt)
- Mattress Pad
- Fitted Sheet
- Adjustable/Removable Canopy
- Music Module with Nightlight
- Storage Basket Fabric
- Assembly Hardware (screws, etc.)

4. SETUP AND ASSEMBLY

Assembly typically requires a Phillips head screwdriver (not included). Follow the step-by-step instructions provided in the separate assembly guide included in your product packaging. Ensure all connections are secure before placing an infant in the bassinet.

1. Unpack all components and verify against the parts list.
2. Assemble the bassinet frame according to the detailed diagrams in your assembly guide. Ensure all locking mechanisms are engaged.
3. Attach the bassinet basket fabric to the frame, ensuring it is taut and securely fastened.
4. Insert the mattress pad into the bassinet basket and cover with the fitted sheet.
5. Install the music module into its designated slot on the bassinet rim. Insert 4 AA batteries (not included) into the module.
6. Attach the adjustable canopy to the bassinet frame.
7. Secure the lower storage basket fabric to the frame.



Figure 2: Assembled bassinet with canopy folded back, showing the interior and storage area.

5. OPERATING INSTRUCTIONS

5.1 Music Module and Nightlight

The music module provides soothing sounds and a gentle nightlight. It is located on the rim of the bassinet.



Figure 3: Close-up view of the music module controls.

- **Power Button:** Press to turn the module on/off.
- **Music Selection:** Press the music note buttons to cycle through different lullabies.
- **Nightlight:** Press the light bulb button to activate or deactivate the gentle nightlight.
- **Volume Control:** Use the '+' and '-' buttons to adjust the sound volume.

Ensure 4 AA batteries are installed correctly for the module to function.

5.2 Canopy Adjustment

The canopy can be adjusted to block light or removed entirely. Simply push or pull the canopy to the desired position. For removal, follow the instructions in your assembly guide.

WE'RE AWARD WINNING!



Figure 4: Bassinet with canopy extended to provide shade.

5.3 Mobility and Storage

The bassinet is equipped with locking wheels for easy movement. To move the bassinet, unlock the wheels. To secure it in place, engage the wheel locks. The large storage basket underneath provides convenient space for baby essentials.



Figure 5: The spacious storage basket for baby supplies.

6. MAINTENANCE AND CARE

6.1 Cleaning Instructions

- **Fitted Sheet:** The fitted sheet is machine washable. Wash in cold water on a gentle cycle and tumble dry low.
- **Mattress Pad:** The mattress pad is water-resistant. Wipe clean with a damp cloth and mild soap. Air dry thoroughly.
- **Fabric Components (Bassinet Skirt, Canopy):** Spot clean with a damp cloth and mild soap. Do not machine wash unless specified in the product's care tag.
- **Frame:** Wipe the metal and plastic parts of the frame with a damp cloth. Do not use abrasive cleaners.

6.2 General Maintenance

- Regularly inspect the bassinet for any signs of wear, damage, or loose parts.
- Ensure all screws and fasteners remain tight. Tighten as necessary.
- Check the wheels for smooth operation and ensure locks engage properly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Music module/nightlight not working.	Batteries are dead or incorrectly installed.	Replace with fresh 4 AA batteries, ensuring correct polarity.
Bassinet feels unstable or wobbly.	Assembly fasteners are loose.	Check and tighten all screws and connections on the frame.
Wheels not rolling smoothly or locking.	Debris in wheels or lock mechanism.	Clean wheels and check lock for obstructions. Apply light lubricant if necessary.
Canopy does not stay in position.	Canopy attachment points are loose or damaged.	Re-secure canopy to frame. If damaged, contact customer service.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Delta Children customer support.

8. SPECIFICATIONS

- **Model Number:** 25021-138
- **Brand:** Delta Children
- **Color:** Falling Leaves
- **Product Dimensions (L x W x H):** 35.5" x 21" x 45.5"
- **Item Weight:** 10.6 pounds
- **Material:** Metal frame, Polyester fabric
- **Battery Requirement:** 4 AA batteries (not included) for music module
- **Recommended Age/Weight:** 0-5 months, or until infant pushes up on hands and knees.

- **Certifications:** JPMA certified, meets CPSC and ASTM safety standards.



Figure 6: Product dimensions for the bassinet.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the warranty card included with your purchase or visit the official Delta Children website. You may also contact their customer service department directly for assistance.

Contact Information: Please refer to your product packaging or the Delta Children official website for the most current customer service contact details.