

Ibiza QMS15A

Ibiza QMS15A Active Speaker Instruction Manual

Model: QMS15A

INTRODUCTION

Thank you for purchasing the Ibiza QMS15A Active Speaker. This powerful 2-way speaker system is designed for versatile audio applications, featuring 300W output, USB, SD card, Bluetooth, and AUX connectivity. To ensure optimal performance and longevity of your device, please read this instruction manual thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- **Power Supply:** Connect the unit only to a grounded mains socket with the correct voltage (220-240V AC, 50/60Hz).
- **Water and Moisture:** Do not expose the unit to rain or moisture to prevent fire or electric shock. Keep away from liquids.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings.
- **Heat Sources:** Do not place the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Clean only with a dry cloth. Do not use liquid cleaners or aerosols.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the speaker on a stable, flat surface. Avoid placing it in direct sunlight or in environments with extreme temperatures.
- **Cables:** Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

PACKAGE CONTENTS

Please check that all items listed below are present in the packaging:

- 1 x Ibiza QMS15A Active Speaker Unit
- 1 x Power Cable
- 1 x Instruction Manual (this document)

If any items are missing or damaged, please contact your retailer immediately.

PRODUCT OVERVIEW

The Ibiza QMS15A is a robust active speaker designed for various audio needs. It features a durable ABS cabinet, integrated handles for portability, and multiple input options for flexible connectivity.



Figure 1: Front view of the Ibiza QMS15A Active Speaker, showcasing its robust design and speaker grille.

Rear Panel and Controls

The rear panel houses all input/output connections and control knobs. Familiarize yourself with these components before operation.



Figure 2: Rear panel of the Ibiza QMS15A Active Speaker, showing various inputs, outputs, and control knobs.

Key Features:

- **Connectivity:** Bluetooth, USB, SD Card, AUX (RCA, XLR, 6.3mm Jack).
- **Power Output:** 300 Watts.
- **Audio Control:** Master Volume, Treble, Bass, and a 5-band graphic equalizer.
- **Microphone Inputs:** XLR and 6.3mm Jack inputs with independent volume control.
- **Line Input:** RCA and XLR line inputs.
- **Output:** XLR line output for connecting to another active speaker.
- **Media Player:** Integrated MP3 player with USB and SD card slots.
- **Construction:** Durable ABS cabinet with integrated handles.

SETUP

1. Placement

Place the Ibiza QMS15A speaker on a stable, flat surface or a compatible speaker stand. Ensure there is adequate space around the speaker for ventilation.

2. Power Connection

1. Ensure the speaker's power switch is in the "OFF" position.
2. Connect the supplied power cable to the AC IN socket on the rear panel of the speaker.
3. Plug the other end of the power cable into a suitable grounded mains outlet (220-240V AC, 50/60Hz).

3. Audio Source Connection

The QMS15A offers multiple ways to connect your audio sources:

- **Bluetooth:** For wireless connection from smartphones, tablets, or other Bluetooth-enabled devices.
- **USB/SD Card:** Insert a USB drive or SD card into the respective slots on the control panel for MP3 playback.
- **AUX Input (Line In):** Connect external audio devices (e.g., mixer, CD player, laptop) using RCA or XLR cables to the LINE IN sockets.
- **Microphone Input:** Connect microphones using XLR or 6.3mm Jack cables to the MIC IN sockets.

Note: Ensure all volume controls are set to minimum before powering on the speaker to prevent sudden loud noises.

OPERATING INSTRUCTIONS

1. Powering On/Off

Flip the power switch on the rear panel to the "ON" position. The power indicator light will illuminate. To power off, flip the switch to "OFF".

2. Selecting Input Mode

Use the "MODE" button on the media player section to cycle through input sources: USB, SD, Bluetooth, and Line In.

3. Bluetooth Operation

1. Select "Bluetooth" mode using the MODE button. The display will show "BLUE" or a similar indicator.
2. On your Bluetooth-enabled device, search for available devices. You should find "IBIZA SOUND" or "QMS15A".
3. Select the speaker to pair. Once paired, a confirmation sound may play, and the display will indicate a successful connection.
4. Start playing audio from your device. Adjust the master volume on the speaker and the volume on your source device.

4. USB/SD Card Playback

1. Insert a USB drive or SD card containing MP3 audio files into the corresponding slot.

2. The speaker should automatically switch to USB/SD mode and begin playback. If not, use the MODE button to select it.
3. Use the media player controls (Play/Pause, Next, Previous) to manage playback.

5. Adjusting Audio Levels

- **Master Volume:** Controls the overall output volume of the speaker.
- **Mic Volume:** Adjusts the volume of connected microphones independently.
- **Treble/Bass:** Use these knobs to fine-tune the high and low frequencies of the audio.
- **5-Band Graphic Equalizer:** Provides more precise control over specific frequency ranges. Adjust the sliders to boost or cut frequencies as desired for your audio preference.

MAINTENANCE

Cleaning

- Always disconnect the speaker from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces of the speaker.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- Keep the ventilation openings free of dust and debris.

Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to cover the speaker to protect it from dust.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet faulty; Speaker power switch off.	Check power cable connection; Try a different outlet; Ensure power switch is ON.
No sound output	Volume too low; Incorrect input mode selected; Audio source not playing; Cables faulty.	Increase master volume and source volume; Select correct input mode; Check audio source playback; Inspect and replace cables if necessary.
Bluetooth not connecting	Speaker not in Bluetooth mode; Device too far; Interference; Already paired with another device.	Ensure speaker is in Bluetooth mode; Move device closer; Reduce interference; Disconnect from other devices and try pairing again.
USB/SD playback issues	Unsupported file format; Corrupted files; USB/SD card faulty; Incorrect mode.	Ensure files are MP3 format; Try different files/card; Check card for errors; Select USB/SD mode.
Distorted sound	Volume too high (clipping); EQ settings incorrect; Faulty audio source.	Reduce master volume and source volume; Adjust EQ settings; Test with a different audio source.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Model	QMS15A
Brand	Ibiza
Type	Active 2-way Speaker
Max. Power Output	300 Watts
Connectivity Technology	Auxiliary, Bluetooth, USB, SD Card
Speaker Type	Full-range, Outdoor
Mounting Type	Floor Mount
Cabinet Material	ABS
Dimensions (L x W x H)	41 x 35 x 68 cm
Weight	12.5 kg
Power Source	Corded Electric
Color	Black

WARRANTY AND SUPPORT

The Ibiza QMS15A Active Speaker comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Ibiza Sound website. For technical support, troubleshooting assistance, or service inquiries, please contact your retailer or the Ibiza Sound customer service department. Contact information can typically be found on the manufacturer's website or in your purchase documentation.

Online Resources: You may find additional support and product information on the [Ibiza Sound Brand Store](#).