

IKEA 801.538.00

IKEA TROFAST Frame - 99x56 cm User Manual

Model: 801.538.00 | Brand: IKEA

1. INTRODUCTION

This user manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your IKEA TROFAST frame (Model: 801.538.00). Please read this manual carefully before assembly and use to ensure safe and correct handling of the product. Keep this manual for future reference.

The IKEA TROFAST storage system is designed to help organize toys and other items, offering a versatile and durable solution for children's rooms and other spaces. This frame is specifically designed to accommodate TROFAST storage boxes (sold separately), which slide into the integrated guide rails.

2. SAFETY INFORMATION

Important: Always follow these safety guidelines to prevent injury or damage to the product.

- **Assembly:** Assemble the product on a clean, flat, and soft surface to avoid scratches. Ensure all screws and fittings are tightened securely according to the instructions.
- **Wall Attachment:** For safety, it is crucial to secure this furniture to the wall using the included anti-tip device. Different wall materials require different types of fastening devices. Use fastening devices suitable for the walls in your home (not included). If you are uncertain about what type of fastening devices to use, please contact your local specialized retailer.
- **Weight Limit:** Do not overload the frame or individual compartments. Refer to the specifications for maximum weight capacity if available, or distribute weight evenly.
- **Children's Safety:** Do not allow children to climb on or hang from the furniture. Always supervise children around the unit.
- **Placement:** Place the furniture on a level surface to prevent tipping.

3. PARTS LIST

Before beginning assembly, verify that all components are present and undamaged. The package for the IKEA TROFAST frame (Model: 801.538.00) includes:

- Frame panels (top, bottom, sides, dividers)
- Integrated guide rails for TROFAST storage boxes
- All necessary screws, dowels, and fittings for assembly
- Anti-tip device (wall fastening devices not included)

If any parts are missing or damaged, please contact IKEA customer service before proceeding with assembly.

4. ASSEMBLY INSTRUCTIONS

Follow these general steps for assembling your IKEA TROFAST frame. For detailed, step-by-step visual instructions, refer to the assembly leaflet included in your product packaging.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a soft, clean surface. Identify each part using the assembly leaflet.
2. **Assemble Side Panels:** Attach the top and bottom panels to the side panels using the provided screws and dowels. Ensure all connections are secure.
3. **Insert Dividers:** Slide the internal divider panels into their designated slots. These panels also feature pre-installed guide rails for the storage boxes.
4. **Secure Back Panel (if applicable):** If a back panel is included, attach it to the frame using the small nails or screws provided. This adds stability.
5. **Attach Anti-Tip Device:** Secure the anti-tip device to the top or back of the frame as indicated in the assembly leaflet. This device must be attached to a wall for safety.
6. **Final Check:** Ensure all screws are tightened and the frame is stable.



An image showing the assembled IKEA TROFAST frame in white, featuring three compartments with pre-installed guide rails for storage

boxes. The frame measures 99x56 cm.

5. OPERATING INSTRUCTIONS

The IKEA TROFAST frame is designed for use with IKEA TROFAST storage boxes (sold separately). The integrated guide rails allow for easy insertion and removal of these boxes.

- **Inserting Boxes:** Align the grooves on the sides of the TROFAST storage box with the guide rails inside the frame compartment. Gently slide the box into place until it rests securely.
- **Removing Boxes:** Simply pull the TROFAST storage box outwards from the frame.
- **Arrangement:** You can mix and match different sizes and colors of TROFAST boxes to create a customized storage solution that fits your needs.

6. CARE AND MAINTENANCE

To keep your IKEA TROFAST frame in good condition, follow these simple care instructions:

- **Cleaning:** Wipe clean with a damp cloth and a mild cleaner.
- **Drying:** Wipe dry with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or strong chemical solvents, as these can damage the surface finish.
- **Regular Checks:** Periodically check all assembly fittings and re-tighten them if necessary to ensure the stability and safety of the frame.

7. TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Frame is wobbly or unstable.	Loose fittings; uneven floor.	Check and re-tighten all screws and fittings. Ensure the frame is placed on a level surface. Use shims if necessary.
Storage boxes do not slide smoothly.	Debris on guide rails; box misalignment.	Clean the guide rails. Ensure the box is correctly aligned before pushing it in.
Missing parts during assembly.	Packaging error.	Do not proceed with assembly. Contact IKEA customer service with your product details and proof of purchase.

8. SPECIFICATIONS

- **Brand:** IKEA
- **Model Number:** 801.538.00
- **Product Dimensions:** Approximately 99 cm (Length) x 56 cm (Height) x 0.1 cm (Depth - Note: This depth is for a panel, overall depth will be greater, refer to assembly instructions for full dimensions)
- **Weight:** Approximately 24.04 kg
- **Material:** Particleboard, Fibreboard, Acrylic paint, Plastic edging
- **First Available Date:** August 7, 2014

9. WARRANTY INFORMATION

For information regarding the warranty for your IKEA TROFAST frame, please refer to the warranty documentation provided at the time of purchase or visit the official IKEA website for your region. Warranty terms and conditions may vary by country and product.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact IKEA customer service. You can find contact information on the official IKEA website for your country or region. When contacting support, please have your product model number (801.538.00) and proof of purchase readily available.

© 2023 IKEA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question