Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tommy Bahama B00GOG1J90

Tommy Bahama Blue Olive Fire Pit

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Tommy Bahama Blue Olive Fire Pit. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new fire pit. Please read all instructions carefully before use and retain this manual for future reference.
The Blue Olive fire pit features a rectangular design, ideal for various outdoor settings. Its base showcases a channeled herringbone design crafted from all-weather wicker, complemented by a Weatherstone top that mimics natural slate.

Important Safety Information

WARNING: For outdoor use only. Do not use this fire pit indoors or in an enclosed area. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

- Always keep children and pets away from the fire pit.
- Do not use gasoline, kerosene, diesel fuel, lighter fluid, or alcohol to start or restart the fire.
- Never leave the fire pit unattended while in use.
- Ensure the fire pit is placed on a level, non-combustible surface.
- Maintain a safe distance from combustible materials.
- Allow the fire pit to cool completely before moving or storing.
- Use appropriate fire extinguishing materials nearby.

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not attempt to assemble the product. Contact customer support for assistance.

- Fire Pit Base (with all-weather wicker)

- Weatherstone Top
- Burner Assembly
- Ignition System Components (if applicable for gas models)
- Decorative Fire Glass/Lava Rocks (if included)
- Instruction Manual
- Optional accessories (e.g., Flame Guard 3100-92FPS, Burner Cover 3100-92FPC - sold separately)

Setup and Assembly

Follow these steps for proper setup and assembly of your fire pit. Two people are recommended for assembly due to the weight of the components.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Position the Base:** Place the fire pit base in its desired outdoor location. Ensure the surface is level and stable.
3. **Install Burner Assembly:** Carefully place the burner assembly into the designated opening in the fire pit base. Ensure all connections are secure.
4. **Attach Weatherstone Top:** Gently lower the Weatherstone top onto the fire pit base, aligning it with the burner assembly. Ensure it sits securely and evenly.
5. **Connect Fuel Source:** For wood-burning models, ensure proper ventilation and a safe distance from combustibles. For gas models (if applicable), connect the gas line according to local codes and manufacturer instructions.
6. **Add Decorative Media:** Distribute the decorative fire glass or lava rocks evenly around the burner, ensuring not to cover the igniter or burner ports.



Image 1: Front view of the Tommy Bahama Blue Olive Fire Pit, showcasing the rectangular design, all-weather wicker base, and Weatherstone top with the burner insert.

Operating Instructions

This fire pit is designed for wood fuel. Always use dry, seasoned wood to minimize smoke and maximize heat output.

1. **Preparation:** Ensure the fire pit area is clear of debris and combustible materials.

2. **Loading Wood:** Place a small amount of kindling and dry wood in the center of the burner area. Do not overfill.
3. **Ignition:** Use a long-stemmed lighter or match to ignite the kindling. Never use flammable liquids.
4. **Maintaining the Fire:** Gradually add more wood as needed, ensuring good airflow.
5. **Extinguishing the Fire:** Allow the fire to burn down naturally. Do not use water to extinguish the fire, as this can damage the fire pit and create steam hazards. Once the flames are out, ensure all embers are completely cool before leaving the area.



Image 2: The Blue Olive Fire Pit positioned in an outdoor patio environment, surrounded by matching furniture, demonstrating its use as a central gathering point.

Maintenance

Regular maintenance will ensure the longevity and safe operation of your fire pit.

- **Cleaning:** After the fire pit has completely cooled, remove ash and debris from the burner area. Use a soft cloth and mild soap for cleaning the exterior surfaces. Avoid abrasive cleaners.
- **Inspection:** Periodically inspect the fire pit for any signs of damage, wear, or corrosion. Ensure all connections are secure.
- **Storage:** When not in use for extended periods, especially during inclement weather, cover the fire pit with a weather-resistant cover or store it in a dry, protected area.
- **Wicker Care:** The all-weather wicker can be cleaned with a soft brush and soapy water. Rinse thoroughly and allow to air dry.



Image 3: A broader view of the Blue Olive Fire Pit within a luxurious outdoor patio setting, highlighting its integration with surrounding decor and landscaping.

Troubleshooting

Problem	Possible Cause	Solution
Fire does not ignite easily.	Wood is damp or not seasoned. Insufficient kindling.	Use dry, seasoned wood. Ensure adequate kindling and airflow.
Excessive smoke.	Wood is wet or green. Poor airflow.	Use only dry, seasoned wood. Arrange wood to allow for better airflow. Do not overfill.
Fire goes out quickly.	Insufficient fuel. Lack of oxygen.	Add more wood as needed. Ensure vents are not blocked.

Specifications

Brand: Tommy Bahama

Model: B00GOG1J90 (Blue Olive Fire Pit)

Material: High Density Polyethylene (Wicker Base), Weatherstone (Top)

Shape: Rectangular

Item Weight: 178 Pounds

Fuel Type: Wood

Color: Blue (refers to collection name; actual product features brown/grey wicker and dark top)

UPC: 662869350278

Manufacturer: Tommy Bahama Outdoor Living

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Tommy Bahama Outdoor Living customer service. Keep your purchase receipt for warranty claims.
For customer support inquiries, please visit the official Tommy Bahama website or contact their customer service department directly.

© 2026 Tommy Bahama Outdoor Living. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00GOG1J90

More documents and user manuals: **https://manuals.plus/**