

[Manuals.plus](#) /

› [Prym](#) /

› Prym 611916-1 Mini Steam Iron with UK Plug User Manual

Prym PRYM_611916-1

Prym 611916-1 Mini Steam Iron with UK Plug User Manual

Model: PRYM_611916-1

Your compact and versatile solution for wrinkle-free garments.

[Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Specifications](#)

[Troubleshooting](#)

[Warranty &](#)

[Support](#)

PRODUCT OVERVIEW

The Prym 611916-1 Mini Steam Iron is a compact and powerful ironing solution designed for convenience and versatility. Ideal for travel, crafting, and quick touch-ups, this iron features dual voltage capability, a non-stick soleplate, and a robust steam function to keep your fabrics smooth and pristine.



SETUP

Unboxing and Initial Inspection

Upon unboxing, ensure all components are present: the Prym 611916-1 Mini Steam Iron, a measuring cup, and a carrying bag. Inspect the iron for any visible damage.



Image: The Prym Mini Steam Iron in its original packaging, highlighting the compact size and included accessories.

Voltage Selection

The iron features dual voltage capability (100-127V / 220-240V), making it suitable for international travel. Locate the voltage selector switch on the back of the iron. Use a small tool (e.g., a coin) to slide the switch to the appropriate voltage for your region before plugging in the iron.



Image: Close-up of the Prym Mini Steam Iron's UK plug, illustrating the power connection.

Filling the Water Tank

1. Ensure the iron is unplugged and cool.
2. Open the water filler cap located on the top of the iron.
3. Using the provided measuring cup, carefully pour water into the tank up to the 'MAX' line. Do not overfill.
4. Close the water filler cap securely.

611 916

Preisgruppe · Price group · Catégorie de prix

XX



MINI
Dampfbügeleisen
Steam iron



Fer à repasser vapeur



Image: The Prym Mini Steam Iron shown with its measuring cup and carrying bag, demonstrating the complete set.

OPERATING INSTRUCTIONS

Powering On and Temperature Setting

1. Plug the iron into a suitable power outlet. The indicator light will illuminate.
2. Turn the temperature dial to select the desired heat setting for your fabric type. The indicator light will turn off once the iron reaches the set temperature (approximately 1 minute).

Steam Function

To activate steam, ensure the water tank is filled and the iron is at the correct temperature. Press the steam button located on the top of the iron. Steam will be released through the soleplate holes. To turn off steam, press the button again.



Image: The Prym Mini Steam Iron being used on fabric, illustrating its compact size and ease of handling.

Ironing Tips

- For best results, iron fabrics on a clean, heat-resistant surface.
- The compact size is ideal for intricate tasks like quilting, crafting, and pressing seams.
- The non-stick soleplate ensures smooth gliding over various materials.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and use of a similar mini steam iron by a seller. It highlights the iron's portability and effectiveness for various fabrics and crafts.

Your browser does not support the video tag.

Video: Product overview video from Amazon Product Imaging, a seller, showcasing the mini iron's design and basic functions. This video provides a quick visual guide to the product.

MAINTENANCE

After Each Use

- Always unplug the iron and allow it to cool completely before cleaning or storing.
- Empty any remaining water from the tank to prevent mineral buildup and leakage.
- Wipe the non-stick soleplate with a soft, damp cloth if necessary. Do not use abrasive cleaners or scouring pads.



Image: Underside view of the Prym Mini Steam Iron, showing its non-stick soleplate with steam holes.

TROUBLESHOOTING

- **Iron not heating:** Ensure the iron is properly plugged in and the voltage selector switch is set correctly for your region. Check the temperature dial setting.
- **No steam:** Verify the water tank is filled and the iron has reached the selected temperature. Ensure the steam button is pressed.
- **Water leakage:** Ensure the water tank is not overfilled and the filler cap is securely closed. Always empty the tank after use.

SPECIFICATIONS

Brand	Prym
Model Number	PRYM_611916-1
Wattage	700 watts
Voltage	100-127V / 220-240V (Dual Voltage)
Frequency	50 Hz
Product Dimensions	7.48"L x 6.69"W
Item Weight	280 Grams
Soleplate Material	Stainless Steel (Non-stick)
Special Feature	Steam Boost Function

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact Prym customer service directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

