Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Teamson Home B00GTZ3TEE

Teamson Home 17-inch Teal Glazed Pot Water Fountain with LED Light Instruction Manual

Model: B00GTZ3TEE

1. Introduction

Thank you for choosing the Teamson Home 17-inch Teal Glazed Pot Water Fountain. This manual provides essential information for the safe and efficient operation of your new water feature. Please read all instructions carefully before assembly and use.

This water fountain is designed to provide a calming water flow and ambient LED lighting for both indoor and outdoor environments, including patios, gardens, and decks.

2. Safety Information

- Always disconnect the power supply before performing any maintenance or cleaning.
- Ensure the fountain is placed on a level, stable surface to prevent tipping.
- Do not operate the pump without water. This can damage the pump.
- Keep the power cord away from high-traffic areas and ensure it is not pinched or damaged.
- Use only clean water in the fountain. Do not use chemicals or abrasive cleaners.
- For outdoor use, ensure the power outlet is a GFCI (Ground Fault Circuit Interrupter) protected outlet.
- During freezing temperatures, drain the fountain completely and store it indoors to prevent damage.

3. Package Contents

Verify that all components are present before beginning assembly:

- 1x Fountain Body (Teal Glazed Pot)
- 1x Submersible Water Pump with LED Light
- 1x Power Adapter with 74" Cord
- Assembly Instructions (this manual)




Image: Main fountain body and the included water pump with LED light.

4. Setup Instructions

1. **Unpack Components:** Carefully remove all items from the packaging and place them on a clean, flat surface. Inspect for any damage.
2. **Position the Fountain:** Choose a level and stable location for your fountain, ensuring it is near a suitable electrical outlet. For outdoor use, ensure the outlet is GFCI protected.
3. **Install the Pump:** Place the submersible pump inside the fountain's reservoir. Ensure the LED light cable is securely connected to the pump.
4. **Connect Tubing:** Attach the pump's outlet nozzle to the water tubing inside the fountain. Ensure a snug fit to prevent leaks.
5. **Fill with Water:** Fill the fountain reservoir with distilled or clean tap water until the pump is fully submerged. Do not overfill.
6. **Connect Power:** Plug the power adapter into the electrical outlet. The pump and LED light should activate, and water will begin to flow.



Image: The 17-inch teal glazed pot water fountain positioned outdoors, showcasing its design and water flow.

5. Operating Instructions

- **Power On/Off:** The fountain operates by plugging it into an electrical outlet. To turn it off, simply unplug the power adapter.
- **Water Level:** Regularly check the water level. Due to evaporation, especially outdoors, water levels will decrease. Refill with water as needed to keep the pump fully submerged.
- **LED Lights:** The built-in LED lights activate automatically when the fountain is powered on, illuminating the water flow.



Image: The water fountain at night, demonstrating the effect of its integrated LED lighting.

6. Maintenance

- **Cleaning:** Periodically clean the fountain and pump to prevent mineral buildup and algae growth. Disconnect power, drain the water, and wipe surfaces with a soft cloth and mild soap. Rinse thoroughly.
- **Pump Cleaning:** Remove the pump from the reservoir. Disassemble the pump cover and impeller to clean any debris. Reassemble carefully.
- **Water Quality:** Use distilled water to minimize mineral deposits. If using tap water, consider a water clarifier or algaecide suitable for fountains.
- **Winterization (Outdoor Use):** Before the first freeze, disconnect power, drain all water from the fountain and pump. Clean the unit and store it in a dry, frost-free location.



Image: A detailed view of the water cascading over the wave-textured surface, highlighting the importance of clean water for optimal flow.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fountain not working / No water flow	Not plugged in Low water level Kinked tubing Clogged pump/filter	Ensure power cord is securely plugged in. Add water until pump is fully submerged. Check and straighten tubing. Clean pump and filter as per maintenance section.
Water splashing excessively	Water level too high Fountain not level	Remove some water. Adjust fountain placement to a level surface.
Pump is noisy	Low water level Debris in pump	Add water until pump is fully submerged. Clean pump and impeller.
LED lights not working	Loose connection Light failure	Check LED light cable connection to the pump. Contact customer support if lights remain off.

8. Specifications

- **Model:** B00GTZ3TEE
- **Brand:** Teamson Home
- **Color:** Teal
- **Material:** Resin
- **Product Dimensions:** 15.35"L x 15.35"W x 16.93"H
- **Item Weight:** 7.7 Pounds
- **Power Source:** Corded Electric
- **Special Feature:** Weather Resistant, Built-in LED Light
- **Included Components:** Assembly Instruction, Water Pump




Image: Product dimensions for the water fountain.

9. Warranty and Support

This product comes with a**30-day warranty against manufacturer defects**. For warranty claims, technical support, or replacement parts, please contact Teamson Home customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please refer to the contact information provided on the Teamson Home official website or your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00GTZ3TEE

More documents and user manuals: **https://manuals.plus/**