

Hornady 9919

Hornady Team Range Bag 9919 User Manual

Model: 9919

INTRODUCTION

The Hornady Team Range Bag is designed for durability and functionality, providing ample storage for range shooters and uniformed officers. This manual provides essential information for the proper use, care, and maintenance of your range bag.

PRODUCT FEATURES

- Durable nylon construction for long-lasting use.
- Large main compartments for significant storage capacity.
- Multiple pockets and expandable compartments for organized storage of various accessories.
- Embroidered Team Hornady logos.
- Suitable for range shooters, uniformed officers, and general outdoor use.

SETUP

The Hornady Team Range Bag requires minimal setup. Upon unboxing, unfold the bag and allow it to air out if necessary. Ensure all zippers and compartments are functioning correctly.

1. **Unpack:** Remove the range bag from its packaging.
2. **Inspect:** Check for any shipping damage or manufacturing defects.
3. **Adjust Straps:** Adjust the shoulder strap to a comfortable length for carrying.



Image: The Hornady Team Range Bag in black, showcasing its durable nylon construction, large main compartment, and various external pockets. The "H Team" logo is visible on the top flap, and "Team Hornady" is on the front handle strap.

OPERATING INSTRUCTIONS

The Hornady Team Range Bag is designed for intuitive use. Utilize its various compartments to organize your gear efficiently.

Loading the Bag

- **Main Compartment:** Ideal for larger items such as ammunition boxes, ear protection, or larger tools.
- **Side Pockets:** Use for smaller accessories like magazines, cleaning kits, or personal items.
- **Front Pockets:** Convenient for quick-access items such as targets, pens, or small notebooks.
- **Weight Distribution:** Distribute weight evenly to maintain balance and comfort when carrying. Avoid overloading the bag to prevent strain on seams and zippers.

MAINTENANCE

Proper maintenance will extend the life of your Hornady Team Range Bag.

Cleaning

- **Spot Cleaning:** For minor dirt or stains, use a damp cloth with mild soap. Gently rub the affected area.
- **Deep Cleaning:** For more extensive cleaning, hand wash the bag with cold water and a mild detergent. Do not use bleach.
- **Drying:** Air dry the bag completely in a well-ventilated area, away from direct sunlight or heat sources. Do not machine dry.

Storage

Store the bag in a cool, dry place when not in use to prevent mildew and material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Zipper sticking	Dirt or debris in zipper teeth; zipper misalignment.	Clean zipper teeth with a small brush. Apply a zipper lubricant (e.g., silicone spray or wax). Gently work the zipper back and forth.
Bag feels too heavy/uncomfortable	Overloaded; uneven weight distribution.	Reduce contents or redistribute items to balance the weight. Utilize all available compartments.
Material appears worn or frayed	Normal wear and tear; abrasive contact.	This is typically cosmetic. For minor fraying, carefully trim loose threads. For significant damage, consider repair or replacement.

SPECIFICATIONS

Attribute	Detail
Model Name	Range Bag
Part Number	9919
Color	Black
Material	Nylon
Item Weight	4 Ounces (empty)
Package Weight	4.3 Pounds
Item Package Dimensions (L x W x H)	26 x 13 x 5 inches
Manufacturer	Hornady
First Available Date	November 24, 2013

WARRANTY INFORMATION

The Hornady Team Range Bag comes with a One-Year Warranty from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please refer to the official Hornady website or contact customer support.

CUSTOMER SUPPORT

For further assistance, questions, or to report issues, please contact Hornady customer support:

- **Website:** Visit the official [Hornady website](#) for FAQs and contact information.
- **Brand Store:** You can also visit the [Hornady Store on Amazon](#).

