

Beyution 8541713522

Beyution Replacement Remote Control for Seiki TVs User Manual

Model: 8541713522

1. INTRODUCTION

This manual provides instructions for the Beyution Replacement Remote Control, designed for use with various Seiki TV models. This remote control offers direct functionality without the need for programming, serving as a direct replacement for your original Seiki TV remote.

Compatible Seiki TV Models: SE32HY27, SE20HS02, SE48FY19, SE22FR01, SE70GY03, SE65JY25, SE60GY05, SE55GY04, SE55GY07, SE50FY10, SE50UY04, SE50FY04, SE46FY10, SE46FT03, SE42FY08, SE40FH03, SE40GT03, SE39FH03, SE39UY04, SE39FY09, SE32HY10, SE32HT05, SE32HY01, SE28HT07, SE28HY10, SE28HY01, SE26HY10, SE24FT07, SE24FY10, SE24FY01, SE22FR01, SE22FT07, SE22FY01, SE19HY10, SE19HY01.

2. SETUP

2.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Ensure correct polarity when inserting batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, matching the (+) and (-) terminals inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.



Image: Front view of the Beyution replacement remote control, showing all buttons and layout. This image helps identify the remote and its various functions.

2.2 Initial Use

This remote control is a direct replacement and typically requires no programming. Once batteries are installed, point the remote towards your Seiki TV and begin operation.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the button layout for optimal use.

- **Power Button (●):** Turns the TV on or off.
- **Mute Button (⏸):** Mutes or unmutes the TV audio.
- **Number Buttons (0-9):** Directly select channels.
- **SOURCE Button:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **CH+/CH- Buttons:** Change channels up or down.
- **VOL+/VOL- Buttons:** Adjust volume up or down.
- **MENU Button:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **EXIT Button:** Exits the current menu or on-screen display.
- **INFO Button:** Displays program information.
- **SLEEP Button:** Sets the TV sleep timer.
- **HDMI Button:** Directly switches to an HDMI input.
- **Color Buttons (A, B, C, D):** Functionality varies by TV model and on-screen prompts.



Image: A person using a remote control to operate a television. This illustrates the typical use case for the remote control.

4. MAINTENANCE

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's performance degrades or it stops responding. Always replace both batteries simultaneously with new AAA batteries. Dispose of old batteries according to local regulations.

5. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
 - Verify that the remote is pointed directly at the TV.
- **Some buttons not working:**
 - This may indicate low battery power; try replacing the batteries.
 - Ensure the button is not stuck or obstructed.
- **Remote works intermittently:**
 - This often points to weak batteries. Replace them.
 - Check for strong light sources (like direct sunlight) interfering with the IR signal.

6. SPECIFICATIONS

Feature	Detail
Model Number	8541713522
Brand	Beyution
Compatible Devices	Seiki Televisions
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7.1 x 3 x 0.9 inches
Item Weight	2.12 ounces
Special Feature	Ergonomic design

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Please refer to the retailer or manufacturer's website for specific warranty details regarding this product. Warranty terms may vary based on purchase location and date.

7.2 Customer Support

For further assistance or inquiries, please contact the retailer from whom the product was purchased or visit the Beyution Inc. official website for support information.

© 2024 Beyution Inc. All rights reserved.