

## FAGOR 71X2615

# FAGOR Oven Thermostat Instruction Manual

Model: 71X2615

## 1. INTRODUCTION

This manual provides essential information for the safe and correct installation, operation, and maintenance of your FAGOR Oven Thermostat, Model 71X2615. This thermostat is an original replacement part designed for specific FAGOR oven models. Please read this manual thoroughly before attempting any installation or repair to ensure proper function and safety.

## 2. SAFETY INFORMATION

**WARNING:** Electrical shock hazard. Always disconnect power to the oven at the circuit breaker or fuse box before attempting any installation, maintenance, or repair. Failure to do so can result in serious injury or death.

- Only qualified technicians should perform installation or repair of oven components.
- Wear appropriate personal protective equipment, such as gloves and eye protection.
- Ensure all connections are secure and correctly wired according to the oven's wiring diagram.
- Do not operate the oven if any parts are damaged or missing.
- Keep children and pets away from the appliance during installation and operation.

## 3. PACKAGE CONTENTS

Verify that your package contains the following item:

- 1 x FAGOR Oven Thermostat (Model 71X2615)

If any items are missing or damaged, please contact your supplier immediately.

## 4. INSTALLATION

The installation of an oven thermostat requires technical knowledge and should ideally be performed by a certified technician. The following steps are general guidelines. Always refer to your specific oven model's service manual for detailed instructions and wiring diagrams.

- Disconnect Power:** Before beginning, ensure the oven is completely disconnected from the main power supply.
- Access Thermostat:** Depending on your oven model, you may need to remove the back panel, top panel, or control panel to access the existing thermostat.
- Document Connections:** Carefully note or photograph the wiring connections to the old thermostat. This will be crucial for correct re-connection.
- Remove Old Thermostat:** Disconnect the wires and carefully remove the old thermostat from its mounting.
- Install New Thermostat:** Mount the new FAGOR thermostat (Model 71X2615) in the same position as the old one.
- Connect Wiring:** Reconnect the wires to the new thermostat exactly as they were connected to the old one. Ensure all connections are tight and secure.
- Reassemble Oven:** Carefully reassemble any panels or components that were removed.
- Test Functionality:** Restore power to the oven. Test the oven's heating functions and temperature control to ensure the new thermostat is working correctly. Monitor for any unusual smells or sounds during the initial test.

If you are unsure about any step, consult a professional appliance repair technician.

## 5. OPERATION

---

The FAGOR Oven Thermostat (Model 71X2615) is an internal component that regulates the oven's temperature. Once installed, its operation is integrated with the oven's control system. Users interact with the thermostat indirectly through the oven's temperature selection dial or digital controls.

- Set the desired temperature using your oven's control panel.
- The thermostat will monitor the internal oven temperature and cycle the heating elements on and off to maintain the set temperature.
- Allow the oven to preheat fully before placing food inside for accurate cooking results.

## 6. MAINTENANCE

---

The FAGOR Oven Thermostat (Model 71X2615) is designed for long-term reliability and typically requires no routine maintenance. However, general oven maintenance can help ensure its longevity:

- Keep the oven interior clean to prevent grease and food debris buildup, which can affect temperature sensing.
- Periodically inspect the thermostat's capillary tube (if visible and accessible) for any signs of damage or kinks.
- Ensure proper ventilation around the oven to prevent overheating of internal components.

Always disconnect power before cleaning or inspecting any internal oven components.

## 7. TROUBLESHOOTING

---

If you experience issues with your oven's temperature control after installing the new thermostat, consider the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Oven not heating at all.	No power to the oven; faulty heating element; incorrect wiring of thermostat.	Check circuit breaker. Inspect heating elements for visible damage. Verify thermostat wiring.
Oven temperature is inaccurate (too hot or too cold).	Thermostat not calibrated; faulty thermostat (unlikely if new); oven sensor issue; door seal leakage.	Use an oven thermometer to verify temperature. Consult oven's user manual for calibration steps. Check oven door seal.
Oven heats continuously without cycling off.	Thermostat contacts stuck closed; faulty thermostat.	Immediately disconnect power. This indicates a potentially dangerous thermostat failure. Professional inspection is required.

For complex issues or if troubleshooting steps do not resolve the problem, contact a qualified service technician.

## 8. SPECIFICATIONS

<b>Brand</b>	FAGOR
<b>Model Number</b>	71X2615
<b>Item Weight</b>	249.48 g
<b>ASIN</b>	B00GXDNUN2
<b>Compliance</b>	CE
<b>Reusability</b>	Reusable

*Note: Applicable oven models include (but are not limited to): 9011111684 - 5H103B, 901112077 - 5H103B1, 90111693 - 5H103X, etc. (Refer to product description for full list).*

## 9. WARRANTY AND SUPPORT

This FAGOR Oven Thermostat is covered by the manufacturer's standard warranty. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, or for technical support, please refer to the official FAGOR website or contact their customer service department.

For further assistance, you may also contact your product retailer.