

[Manuals.plus](#) /

› [GUESS](#) /

› GUESS U0075G5 Men's Diamond Edge Gold Watch Instruction Manual

GUESS U0075G5

GUESS U0075G5 Men's Diamond Edge Gold Watch Instruction Manual

INTRODUCTION

Welcome to your new GUESS U0075G5 watch. This manual provides essential instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your timepiece. Please read this manual thoroughly before using your watch.

PRODUCT OVERVIEW

The GUESS U0075G5 is a men's gold-tone watch featuring a durable stainless steel case and band, a mineral crystal, and a precise quartz movement. It includes a date display and chronograph functionality, and is water-resistant up to 100 meters (330 feet).



Figure 1: Front view of the GUESS U0075G5 watch, showcasing its gold-tone finish, chronograph subdials, and date window.

SPECIFICATIONS

Feature	Detail
Model Number	U0075G5
Dial Color	Gold
Band Material	Stainless Steel
Case Material	Stainless Steel, Mineral Crystal
Case Size	Approximately 43mm
Case Thickness	Approximately 13mm
Band Width	Approximately 22mm
Water Resistance	100 meters (330 feet)
Movement	Quartz
Functions	Date Display, Chronograph
Battery	1 product-specific battery (included)
Product Weight	Approximately 199.58 g

SETUP

1. Unboxing

Carefully remove the watch from its packaging. Inspect for any protective films on the crystal, case back, or band, and gently peel them off.



Figure 2: The GUESS U0075G5 watch presented in its genuine product box.

2. Band Adjustment

The watch band may require adjustment for a comfortable and secure fit. **Please note:** Band size adjustment services are not provided by GUESS directly. It is recommended to have this procedure performed by a qualified watch technician or at a local watch store to prevent damage to the watch or band.



Figure 3: The GUESS U0075G5 watch displayed on a wrist, illustrating its fit and appearance.

OPERATING INSTRUCTIONS

1. Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the **second click position**. The second hand will stop.
2. Turn the crown to set the hour and minute hands to the desired time. Ensure you set the correct AM/PM by observing the date change (the date will change around midnight).
3. Once the time is set, push the crown back to the normal (closed) position. The second hand will resume movement.

2. Setting the Date

1. Pull the crown out to the **first click position**.
2. Turn the crown clockwise or counter-clockwise (depending on the movement) to set the date.
3. **Important:** Avoid setting the date between 9:00 PM and 3:00 AM, as this can interfere with the automatic date change mechanism and potentially damage the movement. If you need to set the date during this period, first set the time outside this window, adjust the date, and then reset the time.
4. Push the crown back to the normal (closed) position.

3. Using the Chronograph

Your watch is equipped with a chronograph function for measuring elapsed time.

1. To **start** the chronograph, press the top pusher (button above the crown). The chronograph second hand will begin to move.
2. To **stop** the chronograph, press the top pusher again. The chronograph hands will stop, indicating the elapsed time.
3. To **reset** the chronograph, press the bottom pusher (button below the crown). The chronograph hands will return to their zero positions.

MAINTENANCE

1. Cleaning

Regularly wipe your watch with a soft, dry cloth to remove dust, dirt, and moisture. For stainless steel components, a slightly damp cloth can be used, followed immediately by a dry cloth to prevent water spots.

2. Water Resistance

Your watch has a water resistance rating of 100 meters (330 feet). This makes it suitable for swimming and snorkeling. However, it is **not** suitable for scuba diving. Always ensure the crown is fully pushed in before any contact with water. Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance.

3. Battery Replacement

When the battery needs replacement, it is highly recommended to have it done by an authorized GUESS service center or a professional watchmaker. This ensures that the correct battery is used, the watch is properly sealed, and its water resistance is maintained.

TROUBLESHOOTING

- **Watch Not Running:**

Ensure the crown is fully pushed in. If the watch still does not run, the battery may need replacement.

- **Date Not Changing:**

Verify that the time is set correctly for AM/PM. Remember to avoid setting the date between 9:00 PM and 3:00 AM.

- **Condensation Inside Crystal:**

If you notice condensation under the watch crystal, it indicates a loss of water resistance. Seek professional service immediately to prevent further internal damage to the movement.

- **Inaccurate Timekeeping:**

A quartz watch should be highly accurate. If your watch is consistently losing or gaining significant time, the battery may be low, or the movement may require servicing.

WARRANTY AND SUPPORT

Your GUESS U0075G5 watch comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover normal wear and tear, accidental damage, damage resulting from improper use, or damage caused by unauthorized repairs or modifications.

For warranty claims, service inquiries, or technical support, please refer to the warranty card included with your watch for specific instructions or contact your original point of purchase. Keep your proof of purchase for warranty validation.

SAFETY INFORMATION

- Avoid exposing the watch to extreme temperatures (above 60°C / 140°F or below 0°C / 32°F), as this can affect battery life and movement accuracy.
- Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones), as these can temporarily affect the accuracy of the quartz movement.
- Avoid dropping the watch or subjecting it to severe impacts.
- Do not attempt to open the watch case yourself. This will void the warranty and may cause damage to the internal components.
- If you experience any skin irritation from wearing the watch, discontinue use and consult a medical professional.