

ROCKTILE Pro ST60-SK-SET

Rocktile Pro ST60-SK Electric Guitar Skull with Accessories User Manual

Model: Pro ST60-SK-SET | Brand: ROCKTILE

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Rocktile Pro ST60-SK Electric Guitar. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your instrument. This electric guitar set is designed for beginners and intermediate players, offering a unique aesthetic combined with reliable performance.

PACKAGE CONTENTS

Your Rocktile Pro ST60-SK Electric Guitar set includes the following items:

- Rocktile Pro ST60-SK Electric Guitar (Black Skull finish)
- Electric Guitar Gig Bag with Front Pocket
- 2.5m Electric Guitar Cable
- 3 Guitar Picks
- 1 Set of Replacement Guitar Strings (009-042 Nickel Wound)
- Guitar School Book including CD & DVD
- Tremolo Arm
- Hex Key for adjustments



Image: The complete Rocktile Pro ST60-SK Electric Guitar Skull Set, including the guitar, gig bag, instructional materials, cable, picks, and replacement strings.

PRODUCT OVERVIEW

The Rocktile Pro ST60-SK features a classic ST-style body with a distinctive skull graphic. It is equipped with a versatile pickup configuration and standard controls for a wide range of tones.

Guitar Components

- **Body:** Basswood with High Gloss Black Skull finish.
- **Neck:** Bolt-on Maple neck.
- **Fretboard:** Rosewood with 22 Jumbo Frets and Dot Inlays.
- **Pickups:** One EMG-HZ Humbucker and two Single Coil pickups for diverse sound options.
- **Controls:** One Volume potentiometer, two Tone potentiometers, and a 5-way Pickup Selector Switch.
- **Bridge:** Vintage String-Through Tremolo system.
- **Tuners:** Die-cast tuning machines for stable tuning.
- **Hardware:** Chrome finish on all hardware components.





Image: Front view of the Rocktile Pro ST60-SK Electric Guitar, showcasing the body shape, pickups, and controls.





Image: Rear view of the Rocktile Pro ST60-SK Electric Guitar, showing the bolt-on neck joint and tremolo spring cover.



Image: Close-up of the guitar's bridge, volume, and tone controls, highlighting the pickup selector switch.



Image: Detailed view of the unique skull graphic design on the lower bout of the guitar body.



Image: Close-up of the Rocktile branded headstock and the chrome die-cast tuning machines.

SETUP

Before playing your new guitar, some initial setup steps are recommended:

1. **Unpacking:** Carefully remove the guitar and all accessories from the packaging. Inspect for any visible damage.
2. **Stringing:** The guitar comes pre-strung, but you may need to fine-tune them. If replacing strings, refer to the maintenance section.
3. **Tuning:** Use an electronic tuner to tune your guitar. Standard tuning is E-A-D-G-B-e (from thickest to thinnest string).
4. **Connecting to an Amplifier:** Insert one end of the included 2.5m guitar cable into the guitar's output jack (located on the side of the body) and the other end into the input jack of your amplifier. Ensure your amplifier is turned off before connecting.
5. **Adjusting Tremolo Arm:** Screw the tremolo arm into its receptacle on the bridge. Adjust its tightness to your preference.

OPERATION

Understanding the controls of your electric guitar is key to shaping your sound:

- **Volume Knob:** Controls the overall output volume of the guitar. Turn clockwise to increase volume, counter-clockwise to decrease.

- **Tone Knobs:** There are two tone knobs. These control the treble frequencies of the pickups. Turning them counter-clockwise will reduce treble, resulting in a warmer, darker sound.
- **5-Way Pickup Selector Switch:** This switch allows you to select different pickup combinations, offering a variety of tonal options:
 - i. **Position 1 (Bridge):** Activates the bridge humbucker pickup for a bright, powerful sound, often used for lead guitar or heavy riffs.
 - ii. **Position 2 (Bridge & Middle):** Combines the bridge humbucker and middle single coil for a slightly thinner, quacky tone.
 - iii. **Position 3 (Middle):** Activates the middle single coil pickup for a balanced, clear tone.
 - iv. **Position 4 (Middle & Neck):** Combines the middle and neck single coil pickups for a warm, rounded tone.
 - v. **Position 5 (Neck):** Activates the neck single coil pickup for a warm, mellow tone, ideal for rhythm playing or blues.
- **Tremolo Arm:** The tremolo arm allows you to vary the pitch of the strings, creating vibrato effects. Push down to lower the pitch, pull up (if set up for it) to raise it.

MAINTENANCE

Regular maintenance will keep your Rocktile guitar in optimal playing condition:

- **Cleaning:** After each use, wipe down the strings and body with a clean, soft cloth to remove sweat and dirt. Use a guitar-specific polish for the body if desired.
- **String Replacement:** Strings should be replaced regularly, depending on how often you play. Refer to the included replacement strings (009-042 Nickel Wound) for gauge. When replacing, change one string at a time to maintain neck tension.
- **Fretboard Care:** Periodically clean the rosewood fretboard with a damp cloth and apply a small amount of lemon oil or fretboard conditioner to prevent drying and cracking.
- **Storage:** Store your guitar in its gig bag when not in use to protect it from dust, humidity changes, and accidental damage. Avoid extreme temperatures and direct sunlight.
- **Hardware Check:** Periodically check all screws and nuts (tuners, bridge, strap buttons) for tightness. Do not overtighten.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
No sound from amplifier	Cable issues, amplifier off, guitar volume down, faulty pickup.	Check cable connections, ensure amplifier is on and volume up, turn guitar volume knob up, try different pickup selections.
Buzzing or humming noise	Grounding issue, single coil hum, faulty cable, nearby electronics interference.	Ensure proper grounding, try different outlets, move away from electronic devices, use a shielded cable. Single coil pickups naturally hum more than humbuckers.

Problem	Possible Cause	Solution
Guitar won't stay in tune	Old strings, improper string winding, faulty tuners, nut friction, tremolo use.	Replace old strings, ensure strings are wound correctly on tuning posts, lubricate nut slots, stretch new strings, use tremolo sparingly if not properly set up.
Fretting out / buzzing strings	Low action, uneven frets, neck relief issues.	This may require professional setup. Minor adjustments can be made to bridge saddle height or neck truss rod (use hex key carefully).

SPECIFICATIONS

Feature	Detail
Model Number	Pro ST60-SK-SET
Body Material	Basswood
Neck Material	Maple (Bolt-on)
Fretboard Material	Rosewood
Number of Frets	22 Jumbo
Pickups	1 EMG-HZ Humbucker, 2 Single Coils
Controls	1 Volume, 2 Tone, 5-Way Pickup Selector
Tuners	Die-cast
Bridge	Vintage String-Through Tremolo
Hardware	Chrome
Strings	009-042 Nickel Wound
Color	Black Skull
Finish	High Gloss
Scale Length	25.0 inches
Number of Strings	6
Hand Orientation	Right

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the retailer where you purchased the Rocktile Pro ST60-SK Electric Guitar. Keep your proof of purchase for any warranty

claims.

For additional resources and product information, you may visit the official Rocktile brand store [Rocktile Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question